



Adhesive Application Solutions | ISO 9001 certified

---

# DYNAMELT SR

## ADHESIVE MELT & SUPPLY UNIT

DM SR5, SR10, SR22, SR45  
with Piston Pump and V6 LCD Controller

Technical Documentation, No. 20-59P, Rev.3.25  
English – Original Instructions

---



---

ITW Dynatec  
An Illinois Tool Works Company  
[www.itwdynatec.com](http://www.itwdynatec.com)

## Information about this manual



**Read all instructions before operating this equipment!**

It is the customer’s responsibility to have all operators and service personnel read and understand this information. Contact your ITW Dynatec customer service representative for additional copies.



**NOTICE:**

Please be sure to include the serial number of your application system each time you order replacement parts and/or supplies. This will enable us to send you the correct items that you need.

**Note: Most common screws, nuts and washers called out in the manual are not for sale and they can be obtained locally at your hardware Store. Specialty fasteners are available by contacting ITW Dynatec’s Customer Service.**

### ITW Dynatec Service Parts and Technical Service:

AMERICAS	EUROPE, MIDDLE EAST & AFRICA	ASIA PACIFIC	
ITW Dynatec 31 Volunteer Drive Hendersonville, TN 37075 USA Tel. +1.615.824.3634 info@itwdynatec.com service@itwdynatec.com	ITW Dynatec Industriestrasse 28 40822 Mettmann Germany Tel. +49.2104.915.0 info@itwdynatec.de service@itwdynatec.de	ITW Dynatec No.2 Anzhi Street SIP, Suzhou, 215122 China Tel. +86.512.6289.0620 info@itwdynatec.cn service@itwdynatec.cn	ITW Dynatec Tsukimura Building 5th Floor 26-11, Nishikamata 7-chome Ota-ku, Tokyo 144-0051, Japan Tel. +81.3.5703.5501 info@itwdynatec.co.jp service@itwdynatec.co.jp

# Index

<b>Information about this manual .....</b>	<b>2</b>
<b>Index .....</b>	<b>3</b>
<b>Chapter 1 Declaration of Incorporation / Conformity .....</b>	<b>9</b>
<b>Chapter 2 Safety Instructions .....</b>	<b>11</b>
2.1 General Considerations.....	11
2.2 Warning Labels .....	11
2.3 Safety Symbols in this Manual .....	12
2.4 Safe Installation and Operation .....	13
2.5 Explosion/ Fire Hazard .....	13
2.6 Choice of Adhesive .....	14
2.7 Eye Protection & Protective Clothing .....	14
2.8 Electrical.....	14
2.9 Lockout/ Tagout.....	15
2.10 High Temperatures.....	15
2.11 High Pressure.....	15
2.12 Protective Covers.....	16
2.13 Servicing, maintenance.....	16
2.14 Cleaning Recommendation.....	16
2.15 Secure transport.....	17
2.16 Treatment for Burns from Hot Melt Adhesives.....	17
2.17 Measures in case of fire .....	18
2.18 Keep attention to environmental protection standards.....	18
<b>Chapter 3 Description and Technical Specs .....</b>	<b>19</b>
3.1 Applicable Safety Regulations .....	19
3.1.1 Intended Use .....	19
3.1.2 Unintended Use, Examples .....	19
3.1.3 Residual Risks .....	19
3.1.4 Technical changes .....	20
3.1.5 Using foreign components .....	20
3.1.6 Setting-up operation.....	20
3.2 Description Dynamelt SR Piston Pump.....	21
3.2.1 Description .....	21
3.2.2 Specifications .....	22
3.2.3 Dimensions .....	24
3.2.3.1 DM SR5 .....	24
3.2.3.2 DM SR10 .....	26
3.2.3.3 DM SR22 & SR45.....	28
3.2.4 Amperage Calculation.....	31
3.2.5 Maximum Wattage Chart .....	32
3.2.6 Calculation Chart for Effective Wattage of Your System .....	33
3.2.7 Model Designation Matrix .....	34
<b>Chapter 4 Installation .....</b>	<b>35</b>
4.1 Typical Installation.....	35
4.1.1 Mounting the Dynamelt SR ASU.....	35
4.1.2 Lifting the ASU .....	35
4.1.3 Pre-Installation .....	35
4.1.4 Components of the Dynamelt ASU.....	36
4.1.5 Installation .....	39
4.1.6 Voltage Configuration Connector Schematics .....	41
4.1.7 Adding Adhesive .....	43
4.1.8 Changing the Adhesive Formula.....	43
4.1.9 Quality of Compressed Air .....	44
4.1.10 Repositioning the HMI (Controller).....	45
4.1.11 Operation and Calibration of Level Sensor.....	46

4.1.12 Field Installation of Controller Options .....	47
4.2 Typical Start - Up and Shut Down .....	48
4.2.1 Operation of the ASU's Piston Pump .....	49
4.2.2 Piston Pump Flow Diagram .....	50
4.2.3 Pneumatic Pressure Relief Valve Operation .....	51
4.3 Storage and Disposal .....	52
<b>Chapter 5 DynaControl V6 Controller .....</b>	<b>53</b>
5.1 Controller Set-Up .....	53
5.1.1 Temperature Control Functions in General .....	53
5.1.2 Defining DynaControl Temperature Control Terms .....	53
5.1.3 DynaControl V6 LCD Display During Normal Operating Mode .....	55
5.1.4 Error Indication Alarms .....	55
5.1.5 Error Indication Alarm Display Examples .....	56
5.1.6 Operator Response to Error Indication Alarms .....	56
5.1.7 Optional System Status (Stack) Lights .....	57
5.1.8 Settings for a Typical Operation .....	57
5.1.9 Helpful Tips for the User .....	58
5.1.10 Controller Features .....	58
5.2 Controller Programming Instructions .....	59
5.2.1 DynaControl (DCL) V6 LCD Interface .....	59
5.2.1.1 In General .....	59
5.2.1.2 Overview Screen Reference .....	60
5.2.1.3 Status Line .....	61
5.2.1.4 System Status .....	61
5.2.1.5 Pump Status .....	61
5.2.1.6 Temperature Zone Symbols .....	61
5.2.1.7 Bar-Graphs .....	62
5.2.1.8 Scan Mode .....	62
5.2.1.9 To Navigate Away from the Overview Screen .....	62
5.2.1.10 Setup Your System's Parameters .....	63
5.2.2 Temperature Zones .....	63
5.2.2.1 Selecting Temperature Zones .....	63
5.2.2.2 Selecting Temperature Setpoints .....	64
5.2.2.3 Turning a Temperature Zone ON or OFF .....	64
5.2.3 Pump Settings .....	64
5.2.3.1 Standard Piston Pump ASU .....	64
5.2.4 Main Menu .....	67
5.2.4.1 Recipe Management (F1) .....	67
5.2.4.2 Standby (F2) .....	68
5.2.4.3 Setpoint Locking (F3) .....	69
5.2.4.4 7-Day Scheduler (F4) .....	69
5.2.4.5 Info Menu (F5) .....	72
5.2.5 System Configuration Menu .....	73
5.2.5.1 Accessing the Parameters .....	73
5.2.5.2 Temperature Unit (P1) .....	74
5.2.5.3 Language Selection (P1) .....	74
5.2.5.4 Zone Configuration (P1) .....	74
5.2.5.5 Pump Configuration (P1) .....	74
5.2.5.6 Setpoint Limitation (P2) .....	74
5.2.5.7 Hi/Lo Tolerance (P2) .....	75
5.2.5.8 Standby Configuration (P2) .....	75
5.2.5.9 Level Detection (P2) .....	77
5.2.5.10 Heat-Up Sequence (Priority) (P3) .....	77
5.2.5.11 Access Code (P3) .....	78
5.2.5.12 Temperature Offset (P3) .....	78
5.2.5.13 Customer Zone Names (P4) .....	79
5.2.5.14 Logbook/ Fault History (P4) .....	80
5.2.5.15 Power-On Configuration (P4) .....	81
5.2.5.16 Global Setpoints (P4) .....	82
<b>Chapter 6 Maintenance and Repair Notes .....</b>	<b>83</b>



6.1 Security advices for maintenance and repair .....	83
6.1.1 Equipment Preparation for Maintenance & Repair .....	84
6.1.2 Re-Assembly Procedures and General Cautions .....	84
6.1.3 Cleaning Recommendation .....	84
6.2 Maintenance plan .....	85
6.3 General Cleaning .....	86
6.4 Purging the Filter Manifold of Adhesive and Pressure .....	88
6.5 Preventive Maintenance .....	90
6.5.1 Preventive Maintenance Schedule .....	90
6.5.2 Output Filter, Checking and Replacement .....	90
6.5.3 Hose Fittings .....	92
6.5.4 Fasteners .....	92
6.5.5 Filter and Shutoff Assembly, Cleaning and Replacement, SR5/10 .....	93
6.5.6 Filter and Shutoff Assembly, Cleaning and Replacement, SR22/45 .....	95
6.5.7 Flushing the System .....	97
<b>Chapter 7 Troubleshooting .....</b>	<b>99</b>
7.1 General Troubleshooting Notes .....	99
7.1.1 Preliminary Checks: Verify the following before proceeding: .....	99
7.1.2 Error Messages: .....	99
7.1.3 Hose/ Applicator Troubleshooting Tip .....	100
7.1.4 Location of Components .....	100
7.1.5 High-Temperature Redundant Overtemp Thermostat .....	101
7.1.6 Lithium Battery on Operator's Panel Printed Circuit Board .....	101
7.1.7 DynaControl V6 Modules .....	101
7.1.8 7-Day Scheduler Use with Pendant Control .....	101
7.1.9 Handling Printed Circuit Boards (PCBs) .....	102
7.2 V6 Base Module PN 115734 .....	103
7.3 V6 Temperature Module PN 115735 .....	107
7.3.1 Standard System Zone Tables .....	108
7.4 V6 Power Module PN 115732 .....	109
7.5 V6 Aux Power Module PN 115733 .....	110
7.6 Optional Printed Circuit Boards .....	111
7.7 Piston Pump Control Board, PN 115801 .....	112
7.8 Heater and Sensor Resistance Values .....	114
7.9 Error Indication Alarm Troubleshooting Guide .....	116
7.10 Controller Messages Troubleshooting Guide .....	121
7.11 Troubleshooting the ASU Pump .....	123
7.11.1 Piston Pump Priming/ Start-Up .....	123
7.11.2 Piston Pump Troubleshooting Guide .....	124
<b>Chapter 8 Disassembly &amp; Re-assembly Procedures .....</b>	<b>129</b>
8.1 Procedures for all SR sizes .....	129
8.1.1 Precautions for Disassembly Procedures .....	129
8.1.2 Precautions for Re-Assembly Procedures .....	129
8.1.3 To Open and Remove the Electronics Cabinet Door .....	130
8.1.4 Overtemp Thermostat Replacement .....	131
8.1.5 Piston Pump Seal Replacement .....	132
8.1.6 Hopper Sensor Replacement .....	132
8.1.7 Note on the Cast-in Heaters .....	132
8.1.8 Filter Manifold RTD Sensor and Heater Replacement .....	133
8.1.9 To Access Electrical Components .....	134
8.1.10 Main ON/OFF (Power) Switch .....	134
8.1.11 Fuse Replacement .....	134
8.1.12 Power Supply Replacement .....	135
8.1.13 Printed Circuit Board or Module Replacement .....	135
8.1.14 Main or Auxiliary Power Board Replacement .....	135
8.1.15 Module Replacement .....	135
8.1.16 Opening Modules .....	136
8.1.17 Control Panel Replacement .....	136
8.2 Procedures for SR5/10 .....	137
8.2.1 Removing the Hopper Lid Assembly, SR5/10 .....	137

8.2.2 Removing the Hopper Cover, SR5/10 .....	137
8.2.3 Removing the Piston Pump, SR5/10 .....	138
8.3 Procedures for SR22/45.....	139
8.3.1 Removing the Hopper Lid Assembly, SR22/45 .....	139
8.3.2 Removing the Hopper Cover, SR22/45 .....	140
8.3.3 Removing the Piston Pump, SR22/45 .....	141
<b>Chapter 9 Available Options &amp; Accessories .....</b>	<b>143</b>
9.1 Service Kits .....	143
9.2 Pressure Relief Valves .....	144
9.3 Analog Pressure Gauge Kit: PN 101175.....	144
9.4 NDSN Compatible ASU.....	144
9.5 ASU Roll Cart: PN 108838.....	144
9.6 Flow Control: PN 104890 .....	144
9.7 Harting Connector Set: PN 115879.....	145
9.8 Piston Pump Line Speed Tracking: PN 117144.....	145
9.9 Swirl Kits.....	145
9.10 400V & 480V Step Down Transformer Kits.....	145
9.11 Controller Options .....	146
9.12 Level Sensor Kits .....	146
9.13 Water resistant hose electrical connector cover kit, PN 111276 .....	146
9.14 Water resistant cover kit for NDSN hose connector, PN 110783 .....	146
9.15 Premelt-Grid Options.....	147
9.15.1 Premelt-grid for SR5/10 .....	147
9.15.2 Premelt-grid for SR22/45, 240/400Y, DCL PN 123658, NDSN PN 123659 .....	148
9.15.3 Premelt-grid for SR22/45, 400D/480D, DCL PN 123660, NDSN PN 123661 .....	149
9.16 Pressure Transducer Kit .....	150
9.17 Air Control Kit PN 100055.....	152
<b>Chapter 10 Component Illustrations and Bill of Materials .....</b>	<b>153</b>
10.1 SR5/10 Melter Drawings and BOMs .....	154
10.1.1 Cabinet Assembly, SR5/10 .....	154
10.1.2 Electronics Assembly, SR5/10.....	156
10.1.3 Hopper (Tank) Assembly, SR5/10 .....	158
10.1.4 Filter Manifold Assembly, Piston Pump, DCL PN 115715 and NDSN PN 117447 ...	160
10.1.5 Filter and Shutoff Asy, SR5/10, PN 115717 .....	162
10.1.6 Level Sensor Kit, SR5/10, PN 150020 (Optional).....	163
10.1.7 Piston Pump Drive, SR5/10, PN 116857 .....	164
10.2 SR22/45 Melter Drawings and BOMs .....	166
10.2.1 Cabinet Assembly, SR22/45 .....	166
10.2.2 Electronics Assembly, SR22/45.....	168
10.2.3 Hopper (Tank) Assembly, SR22/45 .....	169
10.2.4 Piston Pump Manifold Assembly, DCL, SR22/45, PN 123427 .....	171
10.2.5 Filter Manifold Assembly, Piston Pump, DCL, SR22/45 .....	172
10.2.6 Filter and Shutoff Asy, SR22/45, PN 102752 .....	173
10.2.7 Level Sensor Kit, SR22/45, PN 123670 (Optional).....	174
10.2.8 Piston Pump Drive, SR22/45 .....	175
10.3 All SR Melter Drawings and BOMs .....	176
10.3.1 Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499.....	176
10.3.2 Electrical Enclosure Assembly, PN 117204.....	178
10.3.3 Air Regulator Assembly, PN 115865 .....	180
10.4 Piston Pump Line Speed Tracking Kit, PN 117144 .....	181
10.5 Pressure Gauge Kit, PN 101175.....	182
10.6 System Status Lights (Stacklight) Assembly, (optional), PN 116848 Rev.H .....	183
10.7 Recommended Spare Part Lists .....	184
10.7.1 SR5/10 Melter Drawings and BOMs .....	185
10.7.1.1 Electronics Assembly, SR5/10.....	185
10.7.1.2 Hopper (Tank) Assembly, SR5/10.....	186
10.7.1.3 Filter Manifold Assembly, Piston Pump, DCL PN 115715 and NDSN PN 117447 .....	187
10.7.1.4 Filter and Shutoff Asy, SR5/10, PN 115717 .....	188
10.7.1.5 Level Sensor Kit, SR5/10, PN 150020 (Optional).....	189

10.7.1.6 Maintenance-Kits, SR5/10 .....	189
10.7.2 SR22/45 Melter Drawings and BOMs .....	190
10.7.2.1 Electronics Assembly, SR22/45 .....	190
10.7.2.2 Hopper (Tank) Assembly, SR22/45 .....	191
10.7.2.3 Piston Pump Manifold Assembly, DCL, SR22/45, PN 123427 .....	192
10.7.2.4 Filter Manifold Assembly, Piston Pump, DCL, SR22/45 .....	193
10.7.2.5 Filter and Shutoff Asy, SR22/45, PN 102752 .....	194
10.7.2.6 Level Sensor Kit, SR22/45, PN 123670 (Optional) .....	195
10.7.2.7 Piston Pump Drive, SR22/45 .....	196
10.7.2.8 Maintenance-Kits, SR22/45 .....	196
10.7.3 All SR Melters Drawings and BOMs .....	197
10.7.3.1 Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499 .....	197
10.7.3.2 Electrical Enclosure Assembly, PN 117204 .....	199
10.7.3.3 Air Regulator Assembly, PN 115865 .....	200
10.7.4 Piston Pump Line Speed Tracking Kit, PN 117144 .....	201
10.7.5 Other Parts & Kits .....	201
10.7.5.1 Lubricants and Fluids .....	201
10.7.5.2 Filter-Kits .....	201
10.7.5.3 Electrical Parts .....	201
<b>Chapter 11 System Schematics &amp; Engineering Drawings .....</b>	<b>203</b>
11.1 Head Schematic, PN 103117, Rev.B, DynaControl .....	203
11.2 Hose Schematic, PN 101082, Rev.G, DynaControl .....	204
11.3 Schematics DM-SR all sizes, PN 115894 Rev. S .....	205
<b>Chapter 12 Appendix .....</b>	<b>207</b>
12.1 DynaControl V6 / Fieldbus Options .....	207
12.2 Signal Isolator .....	208
12.3 Pressure Transducer .....	209
12.4 Manual Revisions .....	211



# Chapter 1

## Declaration of Incorporation / Conformity

### EC declaration of conformity

according to the Machinery Directive 2006/42/EC, Annex II 1. A

Original

The manufacturer bears the sole responsibility for  
issuing this declaration of conformity

ITW Dynatec

31 Volunteer Drive

37075 Hendersonville, TN

Person established in the Community authorised to compile the relevant technical documentation

Andreas Pahl

ITW Dynatec GmbH

Industriestraße 28

40822 Mettmann

### Description and identification of the machinery

Product / Article	Adhesive supply unit
Project number	Dynamelt SR
Commercial name	Dynamelt SR
Model	SR05, SR10, SR22, SR45; 400V and 480V transformer units included
Function	Melting and delivery of hot melt adhesives

It is expressly declared that the machinery fulfils all relevant provisions of the following EU Directives or Regulations:

2014/30/EU	Directive 2014/30/EU of the European Parliament and of the Council of 26 February 2014 on the harmonisation of the laws of the Member States relating to electromagnetic compatibility (recast) Published in 2014/L 96/79 of 3/29/2014
2014/35/EU	Directive 2014/35/EU of the European Parliament and of the Council of 26 February 2014 on the harmonisation of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits Published in 2014/L 96/357 of 3/29/2014
2006/42/EC	Directive 2006/42/EC of the European Parliament and of the Council of 17 May 2006 on machinery, and amending Directive 95/16/EC (recast) (1) Published in L 157/24 of 6/9/2006
2011/65/EU	Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment Published in 2011/L 174/88 of 7/1/2011

Reference to the harmonised standards used, as referred to in Article 7 (2):

EN ISO 13850:2015	Safety of machinery — Emergency stop function — Principles for design (ISO 13850:2015)
EN ISO 12100:2010-11	Safety of machinery - General principles for design - Risk assessment and risk reduction (ISO 12100:2010)
EN ISO 13854:2019	Safety of machinery - Minimum gaps to avoid crushing of parts of the human body (ISO 13854:2017)
EN 60204-1:2018	Safety of machinery - Electrical equipment of machines - Part 1: General requirements (IEC 60204-1:2016, modified)

Hendersonville, TN, 3/6/2023

Place, Date

  
Signature  
Heidi Rushton  
VP/GM

  
Signature  
Michael Wallner  
Operations Manager EMEA & Asia

This page intentionally left blank.

# Chapter 2

## Safety Instructions

### 2.1 General Considerations



- **All operators and service personnel must read and understand this manual before operating or servicing equipment.**
- **All maintenance and service on this equipment must be performed by trained technicians.**



#### **Read and adhere to the manual!**








1. Read and follow these instructions.  
Failure to do this could result in severe personal injury or death.
2. Keep the binding rules for accident prevention valid for your country and the place of installation. Also keep the approved qualified technical rules for safety-conscious and professional work.
3. Additional safety instructions and/ or symbols are located throughout this manual. They serve to warn maintenance personnel and operators about potentially hazardous situations.
4. Inspect the machine for unsafe conditions daily and replace all worn or defective parts.
5. Keep work area uncluttered and well lit. Remove all material or things not needed for the production from the workspace of the equipment!
6. All covers and guards must be in place before operating this equipment.
7. Subject to technical modifications without notice!
8. To ensure proper operation of the equipment, use specified electrical and/ or air supply sources.
9. Do not attempt to alter the design of the equipment unless written approval is received from ITW Dynatec.
10. Keep all manuals readily accessible at all times and refer to it often for the best performance from your equipment.

### 2.2 Warning Labels

1. Read and obey all of the warning labels, signs and caution statements on the equipment.
2. Do not remove or deface any of the warning labels, signs and caution statements on the equipment.
3. Replace any warning labels, signs and caution statements which have been removed or defaced. Replacements are available from ITW Dynatec.






## 2.3 Safety Symbols in this Manual

### Mandatory signs



	General mandatory sign		Wear foot guard!
	Read and adhere to the documentation!		Wear protective gloves!
	Switch the unit voltage-free before working! Main switch OFF!		Wear protective clothing!
	Wear headgear, protective goggles and ear protection!		

### Warning signs

**NOTE:** The dangers and risks exist if the corresponding instructions are not heeded and the precautionary measures are not taken!

	<b>Caution, danger spot!</b> This sign points to possible dangers for life and physical condition or to possible risks for machine and material or to possible risks for environment.  The word <b>“DANGER”</b> in addition with this points to possible dangers of life  The words <b>“WARNING”</b> and <b>“CAUTION”</b> in addition with this sign point to possible risks of injury.  The word <b>“ADVICE”</b> in addition with this sign points to possible risks for machine, material or environment.		<b>Danger, high voltage!</b> This sign points to possible dangers for life and physical condition caused by electricity. <b>Risk of injury, mortal danger!</b>
			<b>Caution, hot surface!</b> This sign points to possible risks of burns. <b>Risk of Burns!</b>
			<b>Caution, high pressure!</b> This sign points to possible risks of injury caused by high pressure. <b>Risk of injury!</b>
			<b>Caution, rotating rolls!</b> This sign points to possible risks of injury caused by inrunning nip (at rolls). <b>Risk of injury!</b>

### Prohibition signs

	<b>Fire danger!</b> <b>Smoking prohibited!</b>		<b>Fire danger!</b> <b>Fire and open flames prohibited!</b>
---	---	--	--



## 2.4 Safe Installation and Operation



### Read and adhere to the manual!

1. Read this manual before applying electrical power to the equipment. Equipment may be damaged by incorrect electrical connections.
2. To avoid possible failure of hoses, make sure all hoses are routed to avoid kinking, tight radius turns (8" or less) and abrasive contact. Hot-melt hoses should not have prolonged contact with heat-absorbing surfaces such as cold floors or metal troughs. These heat-absorbing surfaces can alter adhesive flow and cause incorrect calibration. Hoses should never be covered with materials that prevent heat dissipation, such as insulation or sheathing. Hoses should be spaced apart from each other, not making direct contact.
3. Do not use adhesive that is dirty or that may be chemically contaminated. Doing so can cause system clogging and pump damage.
4. When adhesive hand-held applicators or other movable applicators are used, never point them at yourself or at any other person. Never leave a hand-held applicator's trigger unlocked when not actually in use.
5. Do not operate the hopper or other system components without adhesive for more than 15 minutes if the temperature is 150° C (300° F) or more. To do so will cause charring of the residual adhesive.
6. Never activate the heads, hand-held applicators and/ or other application devices until the adhesive's temperature is within the operating range. Severe damage could result to internal parts and seals.
7. Never attempt to lift or move the unit when there is molten adhesive in the system.
8. In case of an emergency or exceptional incident, press the emergency stop button in order to stop the unit quickly.
9. Use the unit only as it is intended to.
10. Never let the unit run unattended.
11. Operate the unit only in a faultless and fully functional condition. Check and make sure that all safety devices work in proper form!



#### **Smoking, fire and open flames prohibited! Fire danger!**

Make absolutely sure that there is no smoking and no fire being lit in the work area!

## 2.5 Explosion/ Fire Hazard

1. Never operate this unit in an explosive environment.
2. Use cleaning compounds recommended by ITW Dynatec or your adhesive supplier only.
3. Flash points of cleaning compounds vary according to their composition, so consult with your supplier to determine the maximum heating temperatures and safety precautions.


## 2.6 Choice of Adhesive



### **DANGER! HARMFUL FUMES!**

Substance(s) being processed (e.g., melted, pumped, applied) by ITW equipment is at the discretion of the user and beyond ITW Dynatec's control. Any health effects or other safety-related concerns arising from the melting of those particular substances (e.g., hazardous fumes) is the responsibility of the user to identify and mitigate.

## 2.7 Eye Protection & Protective Clothing



### **WARNING**

### **EYE PROTECTION & PROTECTIVE CLOTHING REQUIRED**

1. It is very important that you PROTECT YOUR EYES when working around hot melt adhesive equipment!
2. Wear a face shield conforming to ANSI Z87.1 or safety glasses with side shields which conform to ANSI Z87.1 or EN166.
3. Failure to wear a face shield or safety glasses could result in severe eye injury.
4. It is important to protect yourself from potential burns when working around hot melt adhesive equipment.
5. Wear heat-resistant protective gloves and long sleeved, protective clothing to prevent burns that could result from contact with hot material or hot components.
6. Always wear steel reinforced safety shoes.

## 2.8 Electrical



### **DANGER HIGH VOLTAGE**

1. Dangerous voltages exist at several points in this equipment. To avoid personal injury, do not touch exposed connections and components while input power is on.
2. Disconnect, lockout and tag external electrical power before removing protective panels.
3. A secure connection to a reliable earth ground is essential for safe operation.
4. An electrical disconnect switch with lockout capability must be provided in the line ahead of the unit. Wiring used to supply electrical power should be installed by a qualified electrician.
5. Notify the maintenance personnel immediately, if cables are damaged. Provide for exchanging the defective components immediately.

## 2.9 Lockout/ Tagout



### Switch the unit voltage-free before working! Main switch OFF!

---

1. Follow OSHA 1910.147 (Lockout/ Tagout Regulation) for equipment's lockout procedures and other important lockout/tagout guidelines.
2. Be familiar with all lockout sources on the equipment.
3. Even after the equipment has been locked out, there may be stored energy in the application system, particularly in the capacitors within the panel box. To ensure that all stored energy is relieved, wait at least one minute after removing power before servicing electrical capacitors.

## 2.10 High Temperatures



### WARNING HOT SURFACE

---

1. Severe burns can occur if unprotected skin comes in contact with molten adhesive or hot application system parts.
2. Face shields (preferred) or safety glasses (for minimum protection), heat-resistant protective gloves and long-sleeved clothing must be worn whenever working with or around adhesive application systems.

## 2.11 High Pressure



### WARNING HIGH PRESSURE PRESENT

---

1. To avoid personal injury, do not operate the equipment without all covers, panels and safety guards properly installed.
2. To prevent serious injury from molten adhesive under pressure when servicing the equipment, disengage the pumps and relieve the adhesive system's hydraulic pressure (i.e. trigger the heads, hand-held applicators, and/or other application devices into a waste container) before opening any hydraulic fittings or connections.
3. IMPORTANT NOTE: Even when a system's pressure gauge reads "0" psi, residual pressure and trapped air can remain within it causing hot adhesive and pressure to escape without warning when a filter nut or a hose or hydraulic connection is loosened or removed. For this reason, always wear eye protection and protective clothing.
4. Either of the two High Pressure symbols shown may be used on ITW Dynatec equipment.
5. Keep the given operating pressure.
6. Notify the maintenance personnel immediately, if hoses or components are damaged. Provide for exchanging the defective components immediately.

## 2.12 Protective Covers



### **WARNING** **DO NOT OPERATE WITHOUT GUARDS IN PLACE**

---

1. Keep all guards in place!
2. To avoid personal injury, do not operate the application system without all covers, panels and safety guards properly installed.
3. Never get your extremities and/or objects into the danger area of the unit. Keep your hands away from running parts of the unit (pumps, motors, rolls or others).

## 2.13 Servicing, maintenance

1. Only trained and qualified personnel are to operate and service this equipment.
2. Before any service work disconnect the external power supply and the pressure air supply!
3. Never service or clean equipment while it is in motion. Shut off the equipment and lock out all input power at the source before attempting any maintenance.
4. Follow the maintenance and service instructions in the manual.
5. Keep the maintenance rates given in this documentation!
6. Any defects in the equipment that impact safe operation have to be repaired immediately.
7. Check screws that have been loosened during the repair or maintenance, if they are tight again.
8. Replace the air hoses in preventive maintenance regularly, even if they have got no viewable damages! Adhere to the manufacturers` instructions!
9. Never clean control cabinets or other houses of electrical equipment with a jet of water!
10. Adhere to the current safety data sheet of the manufacturer when using hazardous materials (cleaning agents, etc.)!

## 2.14 Cleaning Recommendation

- Filters are disposable and need to be replaced regularly. DO NOT boil in mineral oil, solvents or water; the sealant used in filter assembly may become brittle and very likely disintegrate when boiled.
- When cleaning other components in mineral oil, remove all non-metallic items (O-rings, seals, filter cartridge, etc.) away from chemicals before components are subjected to hot mineral oil cleaning.
- If there is not a specific rebuild kit available or directions on how to clean a part, please treat it as a replacement item and do not attempt to clean/rebuild.

## 2.15 Secure transport

1. Examine the entire unit immediately after receipt, if it has been delivered in perfect condition.
2. Let damages in transit certify by the carrier and announce them immediately to the ITW Dynatec.
3. Use only lifting devices that are suitable for the weight and the dimensions of the equipment (see drawing of the equipment).
4. The unit has to be transported upright and horizontally!
5. The unit has to cool down to room temperature before packaged and transported.

## 2.16 Treatment for Burns from Hot Melt Adhesives

### ***Measures after being burned:***

1. Burns caused by hot melt adhesive must be treated at a burn center. Provide the burn center's staff a copy of the adhesive's M.S.D.S. to expedite treatment.
2. Cool burnt parts immediately!
3. Do not remove adhesive forcibly from the skin!
4. Care should be used when working with hot melt adhesives in the molten state. Because they rapidly solidify, they present a unique hazard. Even when first solidified, they are still hot and can cause severe burns.
5. When working near a hot melt application system, always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothes that cover all vulnerable parts of the body.
6. Always have first-aid information and supplies available.
7. Call a physician and/or an emergency medical technician immediately. Let the burns medicate by a medic immediately.

## 2.17 Measures in case of fire

1. Please heed that not covered hot parts of the engine and molten hot melt may cause heavy burns. Risk of burns!
2. Work very carefully with molten hot melt. Keep in mind, that already jelled hot melt can be very hot, too.
3. When working near a hot melt application system, always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothes that cover all vulnerable parts of the body!

### **Measures in case of fire:**

Wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothes that cover all vulnerable parts of the body.

### **Firefighting - burning hot melt:**

Please keep attention to the safety data sheet given by the adhesive manufacturer.



### **EXTINGUISH FIRE**

*Appropriate extinguishing agents:*

Foam extinguisher, Dry powder, Spray, Carbon dioxide (CO<sub>2</sub>), Dry sand.

*For safety reasons not appropriate extinguishing agents: None.*

### **Firefighting - burning electrical equipment:**

*Appropriate extinguishing agents:*

Carbon dioxide (CO<sub>2</sub>), Dry powder.

## 2.18 Keep attention to environmental protection standards



1. When working on or with the unit, the legal obligations for waste avoidance and the duly recycling / disposals have to be fulfilled.
2. Keep attention, that during installations, repairs or maintenance matters hazardous to water, like adhesive / adhesive scrap, lubricating grease or oil, hydraulic oil, coolant and cleaner containing solvent do not pollute the ground or get into the canalization!
3. These matters have to be caught, kept, transported and disposed in appropriate reservoirs!
4. Dispose these matters according to the international, national and regional regulations.

# Chapter 3

## Description and Technical Specs

### 3.1 Applicable Safety Regulations

#### 3.1.1 Intended Use

The Dynamelt SR Adhesive Supply Unit (ASU) may be used only to melt and supply suitable materials, e.g. adhesives. When in doubt, seek permission from ITW Dynatec.



If the unit is not used in accordance with this regulation, a safe operation cannot be guaranteed.

The operator - and not ITW Dynatec - is liable for all personal injury or property damages resulting from unintended use!



Intended use includes, that you

- read this documentation,
- heed all given warnings and safety instructions, and
- do all maintenance within the given maintenance rates.

Any other use is considered to be unintended.

#### 3.1.2 Unintended Use, Examples

**The Dynamelt SR ASU may not be used under the following conditions:**

- In defective condition.
- In a potentially explosive atmosphere.
- With unsuitable operating/processing materials.
- When the values stated under Specifications are not complied with.

**The Dynamelt SR ASU may not be used to process the following materials:**

- Toxic, explosive and easily flammable materials.
- Erosive and corrosive materials.
- Food products.

#### 3.1.3 Residual Risks

In the design of the Dynamelt SR ASU, every measure was taken to protect personnel from potential danger. However, some residual risks cannot be avoided.

**Personnel should be aware of the following:**



- Risk of burns from hot material.
- Risk of burns from hot ASU's components.
- Risk of burns when conducting maintenance and repair work for which the system must be heated up.



- Risk of burns when attaching and removing heated hoses.
- Material fumes can be hazardous. Avoid inhalation. If necessary, exhaust material vapors and/or provide sufficient ventilation of the location of the system.
- Risk of pinching parts of the body at running parts of the unit (pumps, motors, rolls or others).
- The safety valves may malfunction due to hardened or charred material.

### **3.1.4 Technical changes**

Any kind of technical changes having impact to the security or the operational liability of the system should only be done by written agreement of ITW Dynatec. Suchlike changes made without given a corresponding written agreement will lead to immediate exclusion of liability granted by ITW Dynatec for all direct and indirect subsequent damages.

### **3.1.5 Using foreign components**

ITW Dynatec takes no responsibility for consequential damages caused by using foreign components or controllers that have not been provided or installed by ITW Dynatec.

ITW Dynatec does not guarantee that foreign components or controllers used by the operating company are compatible to the ITW Dynatec-system.

### **3.1.6 Setting-up operation**

We recommend asking for an ITW Dynatec-service technician for the setting-up operation, to ensure a functioning system. Let yourself and the people working with or working on the system be introduced to the system on this occasion.

ITW Dynatec takes no responsibility for damages or faults caused by any untrained personal.



## 3.2 Description Dynamelt SR Piston Pump

### 3.2.1 Description

The Dynamelt SR Series adhesive supply unit (ASU) is a computer-controlled hot-melt supply unit designed on metric standards. Its "all-icon" control panel, with choice of display languages, is internationally operator friendly. It is available for 240V (1Ph), 240V (3Ph Delta) or 400V (3Ph Wye) service. A transformer kit is available for 400V (3Ph Delta) and 480V (3Ph Delta).

Available in four hopper sizes and with a choice of piston or gear pump, the Dynamelt SR ASU uses a microprocessor temperature control to closely control the temperature of hot-melt adhesive for up to six hoses and six heads. Temperature setpoints are operator-selected for up to 16 zones and the system automatically provides warnings and alarms for operator errors and system malfunctions.

The Dynamelt system provides accurate, proportionate temperature control for the hopper, filter manifold, hoses and applicators. Sequential heating delays may be programmed to enable hoses and heads. A "standby" temperature may be programmed so that the temperature zones can be maintained at a lower temperature when the ASU is not in active use, enabling rapid return to normal operation. A seven-day scheduler and adhesive level sensor are standard features.

With these flexible temperature programming features, the Dynamelt system increases adhesive life by eliminating prolonged high adhesive temperatures. It reduces energy consumption and brings the system up to normal operating temperatures in the shortest possible time.

The temperature control can interlock with a parent machine using pre-selected adhesive temperatures so that production automatically begins when adhesive temperatures are correct for the application. All system temperature values can easily and quickly be programmed.

Digital readout of system conditions is provided. Optional external audible signals or lights which alert the operator to alarm conditions may be wired in. A security code can restrict access to system programming and parameters. The CPU monitors the electronic circuitry and provides alarms for error conditions.

The Dynamelt SR ASU uses an extremely dependable, constant-pressure piston pump. This air-operated pump ensures a high-pressure adhesive output from a low pressure, compressed air input. Piston pumps are available for either hot-melt or lotion applications.

The Dynamelt's hopper accepts adhesive in all popular forms, including pellets, slugs and blocks. The ASU can accommodate air-actuated automatic applicators (heads), electric applicators, hand-held applicators and/or special applicators. Among the available options are pressure gauge, pendant control, stack lights and line speed tracking.

### 3.2.2 Specifications

**Environmental:**

Storage/ shipping temperature .....	-40°C to 70°C (-40°F to 158°F)
Ambient service temperature .....	-7°C to 50°C (20°F to 122°F)
Noise emission .....	< 60 dbA (at 1 meter)

**Physical:**

Dimensions .....	see dimensional layouts on following pages
Number of hoses/ applicators .....	2, 4 or 6 hoses/ applicators
Number of hopper temperature zones .....	1 or 2
Number of piston pump .....	1
Piston pump ratio .....	12:1
Enclosure .....	styled, durable metal and high temp polymer, dust and splatter resistant
Hose connections .....	standard = universal 15-pin Amphenol connectors at ASU wrench-secured fluid fittings (#6 JIC) optional NDSN = 12-pin rectangular electrical connectors
Hopper (tank) capacity .....	DM SR5 = 4.7 kg (10 lbs) DM SR10 = 9.5 kg (20 lbs) DM SR22 = 22 kg (48 lbs) DM SR45 = 45 kg (100 lbs)
Hopper lid openings .....	DM SR05 / SR10 = 135.6 mm x 135.6 mm DM SR22 / SR45 = 235.6 mm x 235.6 mm
Hopper construction .....	welded aluminum, cast-in heaters
Hopper coating .....	ceramic nano-composite
Filtration .....	hopper: Filter and shutoff assembly filter manifold: large pleated pump outlet filter
Weight, empty .....	DM SR5 = 58.5 kg (129 lbs) DM SR10 = 62.6 kg (138 lbs) DM SR22 = 80 kg (177 lb) DM SR45 = 90 kg (198 lbs)
	(These are approximate values because the weight depends on the number of premelt grids, the size of the pump, etc. Each premelt grid weighs ca. 5kg.)
Adhesive form .....	accepts most forms

**Electrical:**

Service requirements .....	230-240 VAC ASUs = 50-60 Hz, see also Wattage Chart 240/ 400 VAC ASUs = 50-60 Hz, see also Wattage Chart
Power consumption, system maximum .....	Single Phase 230-240 VAC system: DM SR5/10/22/45 = 7200 W 3-Phase 240/400 VAC system: DM SR5/10 = 9650 W 3-Phase 240/400 VAC system: DM SR22/45 = 12200W
Hopper heater type .....	cast-in tubular
Temperature control .....	microprocessor-based proportional integral derivative (PID)
Temperature sensors .....	100 Ohm Platinum RTD standard 120 Ohm Nickel RTD optional
Electrical connectors .....	durable, latching connectors
Motor .....	Air motor, Piston pump

**Pressurized Air (Piston Pumps Models):**

Air pressure supply (optional pneumatic pressure relief valve) .....	0.7 to 7.0 bar (10 to 100 psi)
Maximum recommended pump speed .....	60 pump cycles per minute
Air consumption at 60 pump cycles per minute ....	90 normal liters/ minute (3.2 SCFM at 100 psi)

**Performance:**

Maximum operating temperatures .....	218°C (425°F)
Over-temperature cutoff (thermostat) for hopper .....	232°C (450°F)
Adhesive temperature control range .....	10°C to 232°C (50°F to 450°F)
Adhesive temperature control accuracy .....	±1°C (1°F)
Standby adhesive temperature range .....	up to 80°C (150°F) lower than setpoint
Hopper ready adhesive temperature deviation (factory set/ field adjustable) .....	+ 20°C (36°F) from setpoint
Low-temperature cutoff for piston pump (factory set/ field adjustable) .....	135°C (275°F)

Adhesive viscosity .....	500 to 50.000 centipoise
Warm-up time, full hopper .....	approximately 30-40 minutes
Adhesive delivery rate, open line * .....	up to 0.91 kg/min (2 lbs/min) (piston pump 12:1)
Typical adhesive melt rate * .....	DM SR5 & SR10 = up to 10.7 kg/h (23.6 lbs/h)
	DM SR10 with premelt grid = up to 15.4 kg/h (34 lbs/h)
	DM SR22 = up to 22.6 kg/h (50 lb/h)
	DM SR22 w. premelt grid = up to 41.3 kg/h (91 lb/h)
	DM SR45 = up to 23.1 kg/h (50.9 lb/h)
	SR45 w. premelt grid = up to 45.6 kg/h (100.4 lb/h)
Adhesive pressure.....	up to 68 bar (1000 psi) maximum

\* depends on adhesive used

**DynaControl V6 Temperature Controller:**

Power board .....	5 zones per board, modular construction
Auxiliary board .....	5 zones per board, modular construction
Display type.....	liquid crystal (LCD)
Temperature control zones .....	5-15 triac-output
Fuses .....	13 on main power board, 10 on each auxiliary power board: 10/12AF / 6.3 AT


**Other**

Display languages .....	English, German, Spanish, French, Japanese, Chinese, Hungarian
Operator interface .....	LCD graphic display with rotary-knob controller, with simple icons
Temperature stand-by .....	yes
High and low temperature alarms .....	yes
Ready interlock.....	yes
Password protection.....	yes
Sequential heating.....	yes (hopper, hose, head staged heating)
Sensor open alarm.....	yes
EtherNet/ IP communications capable.....	yes
Seven-day scheduler .....	yes
Adhesive level sensor .....	yes
CE approval .....	yes

### 3.2.3 Dimensions


#### 3.2.3.1 DM SR5

Dimensions are expressed as “mm [inch]”.




Installation & Clearance Dimensions: DM SR5: 5 kg (10 lb) Hopper Capacity

DM SR5




Installation & Clearance Dimensions: DM SR5: 5 kg (10 lb) Hopper Capacity

**3.2.3.2 DM SR10**



*Installation & Clearance Dimensions: DM SR10: 10 kg (20 lb) Hopper Capacity*




DM SR10



Installation & Clearance Dimensions: DM SR10: 10 kg (20 lb) Hopper Capacity

### 3.2.3.3 DM SR22 & SR45



Dimensions are expressed as “mm [inch]”.





## DM SR22 & SR45



Dimensions are expressed as "mm [inch]".



DM SR22 & SR45

Dimensions are expressed as "mm [inch]".

Table		
Size	Dimension "A"	Dimension "B"
SR22	918 mm [36.1 in]	642 mm [25.3 in]
SR45	1324 mm [52.1 in]	1048 mm [41.3 in]



### 3.2.4 Amperage Calculation

The Amperage Calculation chart assumes standard ITW Dynatec equipment. Applicator head/ air heater width is typically equal to the applicator's service block width. For non-standard equipment, read the amperage from the equipment's data tag or consult with ITW Dynatec's Customer Service Dept. Wire gauge calculation assumes wire rating of 75°C.



#### CAUTION

The customer is responsible for providing appropriate over-current protection.

Amperage Calculation Chart DM-SR (V6)															PN 117249 Rev. B			
<b>ASU Size</b>															Amps	<b>STEP 1</b>		
Model	SR5/10				SR 22/45				1 premelt grid			2 premelt grids					Select	Enter Amps
Amp	9.5 (with premelt grid 12.6)				10.4				20.8			31.2			→			
<b>Total Length of All Hoses</b>															+	<b>STEP 2</b>		
Feet	12	24	36	48	60	72	84	96	108	120	132	144	156	168			180	Add up all hoses Enter Amps
m	3.7	7.3	11	14.6	18.3	22	25.6	29.3	33	36.6	40.3	43.9	47.6	51.2			54.9	
Amp	1.5	3	4.5	6	7.5	9	10.5	12	13.5	15	16.5	18	19.5	21			22.5	
<b>Total Width of All Applicator Heads</b>															+	<b>STEP 3</b>		
Inches	4	8	12	16	20	24	28	32	36	40	44	48	52	56			60	Add up all applicators Enter Amps
mm	102	203	305	406	508	610	711	813	914	1016	1118	1219	1320	1422			1524	
Amp	2	4	6	8	10	12	14	16	18	20	22	24	26	28			30	
<b>Total Width of All Air Heaters</b>															+	<b>STEP 4</b>		
Inches	0	2	4	6	8	10	12	14	16	18	20	22	24	26			28	Add up all air heaters Enter Amps
mm	0	51	102	152	203	256	305	356	406	457	508	559	610	660			711	
Amp	0	2.5	5	7.5	10	12.5	15	17.5	20	22.5	25	27.5	30	32.5			35	
<b>Total Current for SINGLE PHASE AC Input Voltage</b>															=	<b>STEP 5</b>		
																Add up total Amps		
<b>Recommended Wire Gauge and Over-Current Protection for Your Power Source</b>																<b>STEP 6</b>		
<b>SINGLE PHASE AC INPUT VOLTAGE SPECIFICATIONS</b>																		
Amp	20	23	26	29	32	35	38	41	44	47	50	53	56	59	62	← Amp @ Single PH 240V	Find the column with your total single phase amperage in chart at left	
AWG	10	10	8	8	8	8	8	8	6	6	6	6	Contact Dynatec					→ Wire Gauge
mm <sup>2</sup>	2.5	2.5	4	4	4	6	6	10	10	10	10	10				→ Wire Gauge		
<b>3- PHASE, 240VAC INPUT VOLTAGE SPECIFICATIONS</b>																	<b>STEP 7</b>	
Amp	12	13	15	17	18	20	22	24	25	27	29	31	32	34		36		→ Amp @ 3PH 240V
AWG	12	12	12	10	10	10	10	10	10	8	8	8	8	8	8	→ Wire Gauge	Find the corresponding maximum amperage and wire gauge	
mm <sup>2</sup>	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	4.0	4.0	4.0	4.0	6.0			6.0
<b>3- PHASE, 400VAC INPUT VOLTAGE SPECIFICATIONS</b>																<b>STEP 7</b>		
Amp	7	8	9	10	11	12	13	14	15	16	17	18	19	20			21	→ Amp @ 3PH 400V
AWG	12	12	12	12	12	12	12	12	12	12	10	10	10	10	10	→ Wire Gauge		
mm <sup>2</sup>	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5			

### 3.2.5 Maximum Wattage Chart

The power consumption of a system is maximum:

- 230-240 VAC, 1ph, DM SR5/ SR10 = 7200 W,
- 240/ 400 VAC, 3ph, DM SR5/ SR10 = 9650 W.

This chart is assuming maximum loads. If actual loads are lower, refer to calculation on previous page.

The Wattage Chart shows the maximum current of the power service. Use the chart to determine the adequate max. power service for your ASU.

Model	Required Voltage Service			Available Power for Hoses/Heads			
	Single Phase 230 V	Three Phase 240 V	Three Phase 400 V	2 Hoses & 2 Heads (# 1 & 2)	2 Hoses & 2 Heads (# 3 & 4)	2 Hoses & 2 Heads (# 5 & 6)	Total for all Hoses & Heads
<b>SR5/10</b> w. 2 Hoses & 2 Heads	5600 W 24 A	5600 W 14 A	5600 W 8 A	2400 W *	n.a.	n.a.	2400 W
<b>SR5/10</b> w. 4 Hoses & 4 Heads	7200 W 32 A	8000 W 20 A	8000 W 12 A	2400 W *	2400 W *	n.a.	1PH: 4000 W 3PH: 4800 W
<b>SR10</b> w. 6 Hoses & 6 Heads	7200 W 32 A	9650 W 26 A	9650 W 15 A	2400 W *	2400 W *	2400 W ***	1PH: 4000 W 3PH: 7200 W
<b>SR22/45</b> w. 2 Hoses & 2 Heads	5600 W 24 A	5600 W 14 A	5600 W 8 A	2400 W *	n.a.	n.a.	2400 W
<b>SR22/45</b> w. 4 Hoses & 4 Heads	7200 W 32 A	7600 W 18 A	7600 W 11 A	2400 W *	2400 W *	n.a.	1PH: 4000 W 3PH: 4800 W
<b>SR22/45</b> w. 6 Hoses & 6 Heads	7200 W 32 A	10000 W 24 A	10000 W 14 A	2400 W *	2400 W *	2400 W ***	1PH: 4000 W 3PH: 7200 W

#### DM SR22/45 with one Premelt grid:

<b>SR22/45</b> w. 2 Hoses & 2 Heads	7200 W 32 A	5600 W 14 A	5600 W 8 A	2400 W *	n.a.	n.a.	1PH: 2200 W 3PH: 2400 W
<b>SR22/45</b> w. 4 Hoses & 4 Heads	7200 W 32 A	10000 W 24 A	10000 W 14 A	2400 W *	2400 W *	n.a.	1PH: 2200 W 3PH: 4800 W
<b>SR22/45</b> w. 6 Hoses & 6 Heads	7200 W 32 A	12200 W 30 A	12200 W 17 A	2400 W *	2400 W *	2400 W ***	1PH: 2200 W 3PH: 7200 W

#### DM SR45 with two Premelt grids:

<b>SR45</b> w. 2 Hoses & 2 Heads	n.a.	10000 W 24 A	10000 W 14 A	2400 W *	n.a.	n.a.	1PH: n.a. 3PH: 2400 W
<b>SR45</b> w. 4 Hoses & 4 Heads	n.a.	12200 W 30 A	12200 W 17 A	2400 W *	2400 W *	n.a.	1PH: n.a. 3PH: 4800 W
<b>SR45</b> w. 6 Hoses & 6 Heads	n.a.	14600 W 36 A	14600 W 21 A	2400 W *	2400 W *	2400 W ***	1PH: n.a. 3PH: 7200 W

n.a. = not available.

\* The 2400 W is the max. power available for 2 hoses and 2 heads; the power for 1 hose and 1 head is in average 1200 W.

\*\* If a premelt grid (750 W) is installed in a SR10 with 6 hoses & 6 heads, it reduces the available power on hoses no. 5 & 6 from 2400 W to 1650 W.

### 3.2.6 Calculation Chart for Effective Wattage of Your System


Enter the component's wattage values and calculate the effective wattage of your system.

**NOTES:**

- The wattage and quantity of **hopper, filter block, motor** and **premelt grid** are fixed.
- The wattage of **hoses** may vary according to the length, size and quantity. Refer to the hose manual and hose identification plate for the specific wattage.
- The wattage of **applicators** and **auxiliary zones (e.g. air heater)** may vary according to the size and quantity. Refer to the applicator manual and applicator identification plate for the specific wattage.

Component		Quantity	Wattage each	Wattage total
Hopper (tank)	SR5/10:	1	1500 W	
	SR22/45:	1	2500 W	
Filter Block (only on SR5/10)		0 or 1	775 W	
Motor (only on SR gear pump unit)		1	200 W	
Premelt Grid	SR10:	0 or 1	750 W	
	SR22:	0 or 1	2500 W	
	SR45:	0, 1 or 2	2500 W	
Hose 1				
Hose 2				
Hose 3				
Hose 4				
Hose 5				
Hose 6				
Applicator 1				
Applicator 2				
Applicator 3				
Applicator 4				
Applicator 5				
Applicator 6				
<b>Total Wattage</b>				

### 3.2.7 Model Designation Matrix



H.A.\* = High-Accuracy version.

# Select for higher melt rate requirement applications. Depending on adhesive, the melt rate is increased to around plus 5 kg/h. Note that tank capacity is reduced when this grid is installed.

## Select for higher melt rate requirement applications. 1st Layer Premelt grid is required.

Depending on adhesive, the melt rate is increased to around plus 5 kg/h. Note that tank capacity is reduced when this grid is installed. Capacity and melt rates noted do not include the effect of 1st layer premelt grid. Add these numbers to those from 1st layer premelt grid to see the overall impact.

**EXAMPLE:** SR1N2P1212-A = Dynamelt SR ASU with 10-liter hopper, no drop-in grid, 2 hoses, piston pump 12:1, 100 mesh filter, voltage 240VAC 1 PH, controller V6 with LCD local display and includes pneumatic pressure relief valve.

# Chapter 4

## Installation

### 4.1 Typical Installation



#### CAUTION

- Before setting up, please read this documentation carefully.
- Pay attention to all the installation and connecting advices.
- Heed all safety instructions mentioned in Chapter 2.
- All installation and start-up work must be carried out by qualified and trained technical personnel.

#### 4.1.1 Mounting the Dynamelt SR ASU

The Dynamelt SR SERIES ASU can be mounted on most flat surfaces, on either an open or a solid frame. Four mounting thru-holes have been provided in the base of the unit.

Electrical power and serial communications may be routed through the wire raceway under the unit from either the left or right side of the unit.

For installation dimensions and required clearances, see illustrations in Chapter 3.

#### 4.1.2 Lifting the ASU



#### WARNING

The unit must be lifted by two persons, using proper lifting technique, one person at either end. Securely hold the unit under its base plate. No belts or hooks should be used. Never allow anyone to stand on the ASU.

#### 4.1.3 Pre-Installation




#### CAUTION

An appropriate power cord and overload protection must be provided by the customer as part of the ASU installation.


To determine if your electrical system has the correct circuit breaker size and wire gauge for the installation of this hot-melt system, including the ASU, hoses, applicator heads and air heaters, see the Amperage Calculation chart in Chapter 3 before proceeding.

### 4.1.4 Components of the Dynamelt ASU

#### Front View SR5/10 Melter:




#### Back View SR5/10:







Front view SR22/45 Melter:



Back View SR22/45:



### 4.1.5 Installation

**NOTE:** Re-read Chapter 2 "Safety Precautions" before performing any installation procedures. All installation procedures must be performed by qualified, trained technicians.

After the Dynamelt SR series ASU has been properly mounted, the following general sequence should be followed for installation. Refer to the component drawings on previous pages for orientation and location of described items.


1. Make sure that incoming line power to the ASU is disconnected and the unit's Main Power Switch is turned OFF.



#### **DANGER HIGH VOLTAGE**

Disconnect and lock out input power to the application system before starting any installation procedures. Make sure there is no electrical power on the leads you will be connecting.

2. Loosen the latch screws on the top and bottom of the electrical cabinet access door. Select a power cord sized correctly for your ASU's amperage. Run the power cord through the wireway to the hole in the bottom of the base plate. Attach the power cord at the main switch's connectors. Secure the cord with a strain relief. Attach a ground wire to the ground lug provided in the base plate.



*Main Power Installation & Internal Components*



**CAUTION**

Grounding conductors never carry electrical current. The use of a neutral conducting wire as earth ground is incorrect and may cause damage to the Dynamelt controller.

3. A voltage configuration connector (plug), appropriate for your order, has been installed in your ASU. Before proceeding, verify that this connector is correct for your operating voltage.



**CAUTION**


Using the incorrect power configuration connector may cause serious damage to the unit.

The voltage configuration connector is installed on the DynaControl V6 Power Module (see module illustration below). For location of the module, see Main Power Installation & Internal Components illustration on preceding page.

There are three different voltage configuration connectors available:


- P/N 115724 (Black) for 240VAC single phase and 400/480VAC three phase Δ (2 hose)
- P/N 115725 (Violet) for 240VAC three phase
- P/N 115726 (Yellow) for 400VAC three phase + N and 400/480VAC three Phase Δ (4/6 hose)

For reference, the schematics of each voltage configuration connector is printed on the next page.






DynaControl V6 Power Module

### 4.1.6 Voltage Configuration Connector Schematics



- At installation, the customer must make the following terminal connections into the ASU's main power (ON/OFF) switch and modules. The modules do not need to be removed from the ASU in order to make connections.

Refer to the detailed layout drawings of these components in Ch. 7, if needed.

Terminal	Circuit	Location
<b>Required connections for standard 240 VAC, 1 phase ASU:</b>		
--	Input Power from Main Power 240VAC	Main ON/OFF Switch/ L1, L2
PE	Ground	Ground Lug
<b>Required connections for 240 VAC, 3 phase Delta ASU:</b>		
--	Input Power from Main Power 240VAC	Main ON/OFF Switch/ L1, L2, L3
PE	Ground	Ground Lug
<b>Required connections for 400 VAC, 3 phase, WYE ASU:</b>		
--	Input Power from Main Power, 400 VAC	Main ON/OFF Switch/ L1, L2, L3
N	Neutral, 400 VAC	Terminal on Main Switch
PE	Ground	Ground Lug
<b>Non-essential connections; connect if feature is installed:</b>		
RELAY OUTPUT 1	Ready Output Signal (contact closes when ready)	V6 BASE Module, top side:  
RELAY OUTPUT 2	Alarm Output Signal (contact opens when alarm)	
RELAY OUTPUT 3	Hopper Low Level Signal (contact closes when adhesive level is low)	
ST.BY IN2 IN3 IN4 PU.ST. IN-C.	Standby Input Recipe Selection 1 Recipe Selection 2 Reserved External Pump Start/Stop (activate to start pump) Common for Inputs	V6 BASE Module, bottom side:  
LINE COM	Line Speed Tracking Voltage (0-10V)	V6 BASE Module, bottom side:  
G+I or L+I	Line Speed Tracking Signal with Signal Isolator (option)	Installed at the left of the Base Module. Refer to schematic for details.

5. The air pressure regulator, gauge and solenoid valve assembly (located in the base frame on the front of the unit) are pre-installed.

Connect a one-quarter inch (1/4") air line to the female 1/4 NPT fitting on the right side of the unit, located in the base frame. Air supplied to the unit must be regulated, clean and dry (refer to advices under chapter Quality of Compressed Air on next page). Recommended supply pressure is 10 to 100 psi (0.7 to 6.8 bar).

To increase pressure, use a flat tip screw driver to turn the regulator valve clockwise. To decrease pressure, turn the regulator counter-clockwise. The recommended pressure is 0.7 to 6.8 bar (10 to 100 psi).

6. Nine hydraulic hose connection ports are located on the filter manifold. These ports are positioned to allow for up to six hoses to be routed either from the back of the unit, or from the right-hand side. It is recommended that you use a 45° fitting (available from ITW Dynatec) when using the three ports located on the corner of the filter manifold. ITW Dynatec recommends that hoses be connected to the bottom ports first, then the middle ports, and finally the top ports.
7. The hydraulic pressure gauge can be installed either in one of the hose ports or in the dedicated gauge port. The gauge port is not filtered by the unit's secondary filter.



#### **WARNING HOT ADHESIVE**

Do not remove the high-temperature insulating foam cover from the filter manifold. This cover should remain in place during operation in order to prevent burns and maintain the temperature of the filter manifold. Replace the foam cover if it becomes damaged or dirty.

#### **4.1.7 Adding Adhesive**



#### **CAUTION**

Using adhesive with viscosity over 50,000 centipoise could cause motor stall and/or pump failure.

The adhesive level in the melt tank should be maintained at 25mm to 100mm (1" to 4") from the top of the hopper. Where applications demand a high output volume of adhesive, add small amounts of adhesive frequently. Adding large amounts of adhesive to an almost empty hopper will lower the temperature of the adhesive in the hopper and may cause the ASU to fall below its READY setpoint.

#### **4.1.8 Changing the Adhesive Formula**

If a different adhesive formulation from the one being currently used is needed, the system will have to be flushed if the two formulations are incompatible. See Chapter 6 of this manual for the proper flushing procedure. When in doubt about adhesive compatibility, flush your system.

### 4.1.9 Quality of Compressed Air



#### CAUTION

- In any case, the air has to be clean and dry!
- The min. requirement for compressed air supply to solenoids to control automatic Applicators is ISO 8573-1:2010 class 2:4:3.  
We recommend installing the ITW Dynatec's Air Control Kit PN 100055.
- The min. requirement for compressed air supply to solenoids to control Adhesive Supply Unit is ISO 8573-1:2010 class 7:4:3.

#### Compressed air quality classes according to ISO 8573-1:2010 class 7:4:3:

ISO 8573-1: 2010	Solid particles			Mass concentration mg/m <sup>3</sup>	Water		Oil
	0.1-0.5 µm	0.5-1 µm	1-5 µm		Vapor pressure dew point °C	Liquid g/m <sup>3</sup>	
0	As stipulated by the equipment user, stricter requirements than class 1.						
1	≤ 20,000	≤ 400	≤ 10	-	≤ -70	-	0.01
2	≤ 400,000	≤ 6,000	≤ 100	-	≤ -40	-	0.1
3	-	≤ 90,000	≤ 1,000	-	≤ -20	-	1
4	-	-	≤ 10,000	-	≤ +3	-	5
5	-	-	≤ 100,000	-	≤ +7	-	-
6	-	-	-	≤ 5	≤ +10	-	-
7	-	-	-	5-10	-	≤ 0.5	-
8	-	-	-	-	-	0.5 - 5	-
9	-	-	-	-	-	5 - 10	-
X	-	-	-	> 10	-	> 10	> 10



### 4.1.10 Repositioning the HMI (Controller)

The control panel (HMI) may be rotated 90° from its standard location for the convenience of the operator.




#### **DANGER HIGH VOLTAGE**

Disconnect and lock out input power to the application system before starting repositioning procedures.

**Procedure:**

1. Remove the top cover from the unit:
  - a. Open the electronics cabinet door.
  - b. Release the top latch and open the top cover.
  - c. Loosen and remove the four screws that attach the top cover to the hinges (see illustration).
2. Remove the HMI by removing the four screws holding it in place.
3. Drill four 1/4" holes in the locations shown below and re-attach the HMI at these holes.
4. Re-install the top cover and close the cabinet door.
5. Plug the three visible holes on the top cover with hole plugs.



### 4.1.11 Operation and Calibration of Level Sensor

The level of adhesive in the hopper is monitored by a sensor, mounted in the wall of the hopper and accessed from within the electronics cabinet, which informs the operator of a low adhesive level via a system status message (illustrated below) on the controller's Overview Screen.



After a Hopper Empty message is displayed, the operator must press the controller's RETURN button to acknowledge the message and then replenish the adhesive in the hopper. If the adhesive is not replenished within ten minutes, the alarm will repeat.


#### Calibration

1. Open the electronics cabinet door as described in Chapter 8. Locate the level sensor housing with its calibration button on the side of the hopper.
2. If empty, fill the hopper with adhesive.  
*OPTION for units with premelt grid:* If empty, fill the hopper with adhesive to just below the premelt grid. Turn the ASU On. Allow the adhesive to become molten.
3. Pump adhesive out of the hopper until the molten adhesive reaches a level between the top and the center of the sensor probe. This is the level that will activate the Hopper Empty message.

*OPTION for units with premelt grid (if the view of the low level is blocked by an extra premelt grid in the hopper):* Pump adhesive out of the hopper until the molten adhesive reaches a level at the center of the sensor probe. The probe is not visible so this is accomplished by placing a straightedge on the flat surface of hopper collar across the hopper opening and setting the adhesive level at below the straightedge (see table below). This is the level that will activate the Hopper Empty message.

4. On the level sensor housing, press and hold the calibration button for five seconds.
5. Turn Off the ASU, close the cabinet and re-fill the hopper. Allow sufficient time for the sensor to recognize the level of adhesive.

**Note:** in the event removal of the hopper shroud is required, the level sensor housing will need to be removed also (it is attached by two screws/ ground wire). Afterwards, the level sensor must be re-calibrated.



#### **4.1.12 Field Installation of Controller Options**

Customers who choose to modify their adhesive supply unit with ITW Dynatec manufactured options should assure that only qualified technicians perform such installations. The installation of options that require specific procedures and/ or calibration are outlined in this chapter.

Before controller options are installed, always turn the controller's main power switch OFF. In most cases, turning the controller OFF will assure that the controller will retain its programmed parameters and configuration. Re-booting is not necessary.

## 4.2 Typical Start-Up and Shut Down

The following simplified sequence assumes that the LCD HMI DynaControl V6 Controller has been programmed.

### Start Up Procedures

1. Fill the ASU's hopper with clean hot-melt adhesive to within a couple of centimeters (inches) of the top of the hopper. Close the hopper lid immediately to prevent contaminants from falling in. (Cover your bulk supply of adhesive to prevent contaminants also.)
2. Switch ON the Main Switch. The controller display will come on and the ASU will begin to heat up.
3. Allow adequate time (approximately 20-30 min.) for the adhesive to melt and the temperatures of the heated zones to stabilize. The display will indicate when the unit reaches operating temperature:

The LCD panel will display "READY" in the upper left-hand corner when all zones are within their hi-lo tolerance range of the setpoint temperature. More information about the display can be found in Chapter 5.


4. When temperatures are ready, the piston pump is enabled to pump adhesive and will begin pumping.

### Shut Down Procedures

1. Turn OFF the Main Switch.

*If 7-Day Scheduler is in use:* Turn the unit ON and OFF with the Scheduler On/Off:

- a. Press Menu
- b. Press 7-Day Scheduler (F4)
- c. Press F2 for Sleep Mode (Off). (To cancel Sleep Mode, press the Input knob.)




### 4.2.1 Operation of the ASU's Piston Pump

The pump is double-acting and provides constant pressure. However, the pump does not provide the same volume of adhesive with each piston stroke. When operating, the pump shaft will move more slowly during the forward stroke (into the pump body) and more quickly during the reverse stroke out of the pump body.

During the forward stroke of the pump, the piston's movement forces the input check valve to close. The pressure generated by the piston opens the output check valve. During the forward stroke, the adhesive pressure is uniform within the pump and in the output.

During the reverse stroke, the piston moves to the left and low-pressure adhesive pushes the input check valve open and fills the cylinder. At the same time, the higher back-pressure from the pump output holds the output check valve closed.




### 4.2.2 Piston Pump Flow Diagram

The illustrations below demonstrate how adhesive flows through the piston pump.


**Step 1, upper drawing:**

On the first (priming) upstroke of the piston pump, the upper check valve closes and the lower check valve opens, allowing the plunger to pull adhesive into the lower pump cavity at full volume.




**Step 2, lower left drawing:**

On the downstroke of the piston pump, the upper check valve opens and the lower check valve closes, forcing adhesive up into the shaft cavity and causing it to escape through the outlet in the shaft. The adhesive then spills into the upper pump chamber at half volume.



**Step 3, lower right drawing:**

Once both chambers are full, the adhesive pressure is constant on both the upward and downward strokes, with the downward strokes having approximately half the volume of the upward stroke.



### 4.2.3 Pneumatic Pressure Relief Valve Operation

For location of the pneumatic pressure relief valve, see the exploded-view drawing in Chapter 10.

#### Valve Operation

The Dynamelt SR ASU is equipped with a pneumatic pressure relief valve that has two functions. It controls output adhesive pressure during pump operation and also lowers adhesive pressure when the pump is switched off.

The pneumatic pressure relief valve regulates adhesive pressure proportional to air pressure supplied to the pump. The relief valve operates at a 14:1 adhesive to air pressure ratio. Ten psi (0,68 bar) of air pressure will regulate the adhesive pressure to a maximum of 140 psi (9,7 bar). The valve is designed to deliver a maximum adhesive pressure of 1000 psi (68 bar).

When air pressure is cut off from the relief valve, the valve will open and dump adhesive pressure by relieving adhesive back to the hopper. Air pressure may be cut off from the relief valve by performing any or all of the following actions:

- Turning Off the pump at the ASU's control panel,
- Switching the ASU's main power Off, or
- Shutting Off air supply to the ASU.

#### Adjustment

Air pressure supplied to the pneumatic relief valve is adjusted by turning the pressure regulator built into the front of the ASU with clockwise (to increase pressure) or counter-clockwise (to decrease pressure).

Maximum adhesive pressure can be determined by reading the air pressure from the built-in gauge and multiplying by 14. For example, if the air pressure gauge reads 25 psi (1,7 bar), then adhesive pressure will be limited to 350 psi (24 bar).

## 4.3 Storage and Disposal

Instruction for the Dynamelt SR Application System:

### Temporary Storage of the Unit

1. Flush the adhesive application system with flushing fluid (PN L15653), following the instructions detailed in Chapter 6 of this manual.
2. Relieve residual adhesive pressure.
3. Clean or replace both the outlet filter and the filter and shutoff assembly, following the instructions detailed in Chapter 6.
4. Shut OFF all pressure and power sources.
5. Release residual air pressure.
6. Remove all residual adhesive and wipe components clean.
7. Remove all air lines and all power supply cables.
8. Pack the unit in a corrosion-proof manner.
9. Store the unit in such a way that it is protected from damage.

### Disposal of the Unit

1. Shut OFF all pressure and power sources.
2. Relieve residual adhesive pressure.
3. Release residual air pressure.
4. Remove all residual adhesive.
5. Remove all air and adhesive supply hoses and all power supply cables.
6. Dismantle all components and sort into mechanical and electrical components.
7. Arrange for all components to be recycled.



# Chapter 5

## DynaControl V6 Controller

---

### 5.1 Controller Set-Up

#### 5.1.1 Temperature Control Functions in General

The DynaControl microprocessor-based proportional temperature control in the ASU performs a number of functions that help to maintain adhesive setpoints in all temperature zones of the Dynamelt system. It maintains permanent system values such as the maximum temperature setpoint. It enables the user to program temperature settings and heater on/off sequencing that are appropriate to a specific application. It displays all programmed values, and it includes self-diagnostic malfunction alerts and failure alarms.

**Note:** Some DynaControl functions are direct temperature conversions between degrees Celsius and Fahrenheit. Other parameters are independently selected values.

#### 5.1.2 Defining DynaControl Temperature Control Terms

##### Adhesive Temperature Control Range

The temperature limits within which the ASU, hoses and applicators may be programmed and maintained.

##### Default Settings

The factory-set programmable system values that will be in effect if the user does not enter new values. See Chapter 5 for the controller's defaults.

##### Error Indication Alarms

Controller alarms which indicate that the programmed over-temperature values have been exceeded for one or more hopper, hose or head zones or that a zone temperature has fallen beneath its hi-lo tolerance. Alarms may also indicate an open or short-circuited sensor.

##### Main Power & Aux Power PCBs

The Power printed circuit board (PCB) and Auxiliary PCBs provide power to all the temperature zones in the ASU's system. The standard unit's hopper, hoses and applicators are controlled by the Power PCB. Additional hoses and applicators are controlled by the Aux PCB(s).

##### Mechanical High-Temperature Protection

A mechanical, redundant thermostat located on the hopper which turns OFF the system at 232°C (450°F) [or 246°C (475°F) for optional high temperature units].

##### Microprocessor-based Proportional Temperature Control

The built-in control system that controls, monitors and displays all system temperature values.

##### Over-Temperature Setpoint

The programmable temperatures that will cause alarms to occur when those temperatures are exceeded (over-temp icon is shown at right).



Power is not disconnected, the READY contact opens and the alarm contact opens. If an external alarm has been connected, it will activate. The over-temp setpoint is the upper limit of the ready temperature range of each zone.

**Pump Enable Temperature**

The pump enable temperature protects the pump, pump shaft, motor and motor control from damage by not allowing the pump to activate until a low limit (the programmed pump enable temperature) is achieved.

**RTD Sensors**

The standard Dynamelt system uses 100-ohm platinum resistance temperature detector sensors for all temperature controls.

**Ready Temperature**

The programmable temperature which allows the ASU pump to turn ON. The default ready temperature range is a deviation of + 20°C (+ 36°F) from the setpoint. The setpoint minus the deviation is the low limit of the range, and the setpoint plus the deviation is the high limit of the range.

**Sequential Heating**

The heating sequence which allows the slower-heating hopper to reach operating temperature without unnecessary use of electricity for faster-heating hoses and applicators. Sequential heating is the time period during which the hoses and applicators remain OFF while the hopper (and optional drop-in grid) heats up. Hoses and applicators may be independently programmed. If hopper temperature is above ready temperature when the ASU is turned ON, the hose and applicator sequence is bypassed and they will be turned ON. Sequential heating is restored after Standby is turned from ON to OFF. Sequential heating is not needed for most applications and can delay total system warm-up time.

**Setpoints**

The temperatures that you have selected and programmed for each of the temperature zones.

**Setpoint Limitation**

This is a universal maximum temperature for all zones. The programmer cannot program a temperature setpoint higher than the setpoint limitation. If the actual temperature of any zone climbs higher than the setpoint limitation, all heaters will shut down.

**Standby Condition**

The system condition where the ASU, hose and head temperatures are maintained at predetermined reduced temperature values. Standby temperatures are set lower than setpoint temperatures in order to reduce adhesive degradation and energy consumption when the system is temporarily inactive, and to permit rapid system warm-up when run condition is selected. When standby mode is activated, the controller will display STANDBY.

**Temperature Zone Enable**

The temperature zone enable allows the operator to disable unused temperature zones in such a way that they do not appear on the controller's display and heating is switched OFF.


**V6 Base Module**

The main control module of the system. It controls and communicates with the temperature control module, the operator interface and all auxiliary modules and I/O devices.

**V6 Temperature Module**

Monitors temperature signals from all heated zones and provides control signals to the Power and Auxiliary PCBs (modules).

### 5.1.3 DynaControl V6 LCD Display During Normal Operating Mode




### 5.1.4 Error Indication Alarms

The following illustration shows the display screens that will be activated when one or more error indication alarm conditions occur. The conditions that will trigger an alarm are:

- When a hopper, hose or head has exceeded its selected over-temperature setpoint, which is the setpoint plus its Hi/Lo alarm setting, or when it is below its selected under-temperature setpoint, which is the setpoint minus its Hi/Lo alarm setting .
- When a hopper, hose or head sensor has an open circuit.

When an alarm condition occurs, the current display will be interrupted only if a sensor failure occurs. If more than one alarm condition occurs simultaneously, all alarm conditions will be displayed sequentially.

### 5.1.5 Error Indication Alarm Display Examples



### 5.1.6 Operator Response to Error Indication Alarms

If an alarm occurs during operation, the controller will switch off the internal power to the heaters and an appropriate error indication display will appear.

Pressing the RETURN button resets the error. If several zones display alarms, each must be acknowledged by pressing RETURN. The alarm display is switched off. The operator must either switch OFF the indicated temperature zone(s) (via the DynaControl keypad) or troubleshoot to correct the problem.

Low temperature alarms will not open the main contactor and are only indicated on the bar-graph display and auxiliary alarm output contacts.


A sensor failure is displayed as a "?" on the bar-graph and power is switched off to the zone.

When the actual temperature exceeds the setpoint limitation plus a tolerance of a few degrees, a "!" is displayed on the bar-graph and heater power is switched off.

### 5.1.7 Optional System Status (Stack) Lights

Stack lights ease remote monitoring of the system's status. On the basic, four-color stack light, the lower, clear light illuminates when the system is turned ON. The green light indicates that the system has warmed up to temperature setpoints ("ready"). The upper, red light illuminates only in an alarm condition and is accompanied by an audible alarm. The audible alarm is housed within the upper (black) section of the stack. The blue light is user configurable.

Other setups are possible, for example, the alarm may be wired to indicate low adhesive level, standby or open/shorted sensor.



**Black:**  
audible alarm

**Red:**  
alarm

**Blue:**  
user configured

**Green:**  
system ready

**Clear:**  
system On

### 5.1.8 Settings for a Typical Operation

Note: The values given here are approximate settings for a typical packaging application. The values you choose will be based on the type of equipment and adhesive you are using and the nature of your particular operation.

#### If Application Temperature is 177°C (350°F):

- Hose and head temperature: 177°C (350°F).
- Hopper setpoint temperature: 163°C (325°F).
- Hi/ Lo limit deviation: 12°C (20°F).
- ASU operating range: 149°C to 177°C (300°F to 350°F).
- Standby condition temperature (deviation): 30°C (50°F).
- Hopper over-temperature setpoint : 177°C (350°F)
- Mechanical thermostat (for the hopper) over-temperature: 219°C (425°F)

For most operations, temperature fluctuations will be very small and of short duration. For these reasons, the settings above are recommended.

#### System Values That Are Factory Programmed (not customer programmable)

- Minimum setpoint value: 10°C (50°F).
- Maximum setpoint value (setpoint limitation): 218°C (425°F).
- Maximum alarm deviation: 50° (C or F).
- Minimum alarm deviation: 5° (C or F).
- Maximum standby temperature: 150° (C or F) less than setpoint.
- Minimum standby temperature: 30° (C or F) less than setpoint.
- "Actual" temperature indication range: 0°C to 260°C (32°F to 500°F).

#### Customer Programmable System Values Preset At The Factory

ITW Dynatec can set the controller's system values to customer's specs, if provided.

If customer's specs are not provided, the following values will be entered into the DynaControl controller at the factory. They may be changed by reprogramming through the controller. (These are not the "default" settings, see following section).

- Applicator (head) and hose setpoints: 177°C (350°F).
- Hopper setpoint: 150°C (300°F).
- All zones are switched off, except for the hopper and the manifold.
- Motor rpm: 0 in the "Manual" mode.
- Standby: 66°C (150°F) under setpoint.
- Hi and low alarms: + 20°C (36°F) from setpoint.
- Pump enable temperature: 135°C (275°F).

**Default Settings of the DynaControl V6 Controller**

- Language: English
- Setting for Customer Access Code: "1111".
- Standby temperature for all zones: 66°C (150°F) lower than programmed setpoints.
- Hi/ lo limit deviation for all temperature zones: + 20°C (36°F).
- Temperature zone offset: 0°C (0°F).
- Setpoint limitation: 218°C (425°F).
- Pump enable temperature: 135°C (275°F).
- Automatic sleep mode: Off.
- Sequential heat-up: Off.
- Power-On motor Stop: No.
- Power-On heater start: Yes.
- Global setpoints: No.

**Piston Models Equipped with Optional Line Speed Following:**

- Minimum pump speed: 0% of full speed.
- Maximum pump speed: 100% of full speed.

**5.1.9 Helpful Tips for the User**

- When the ASU is turned ON, all temperature setpoints and other operating parameters will be exactly where they were when the ASU was turned off.
- When the ASU is turned ON, all system heaters go ON unless they have previously been de-activated (in which case they will be turned OFF) or if sequential heatups have been set. However, if hopper temperature is above ready temperature when the ASU is turned on, all hose and head sequential heatups will be bypassed and hoses and heads will be turned ON.

**5.1.10 Controller Features****One-button Shortcuts**

Press the "F" buttons to go to:

F1 = the Hopper temperature zone

F2 = the Hose temperature zone

F3 = the first Applicator temperature zone


F5 = toggle On/ Off

**Shortcut to Advance to System Configuration Parameters**

Press the System Configuration button (wrench button) on the Overview Screen once to advance to the System Configuration parameters. Press it again, repeatedly, to advance through the pages of parameters.

**Initial Heat-up Progress Bar**

During heat up from a cold start, press the Input Wheel/ Knob for 5 seconds to see a progress bar which graphically tracks heat-up until Ready status is attained and production can start. The scale shown is 0% to 100% fully heated.



The ASU illustrated above is one-quarter heated.


If you would like to display the controller's Scan Mode in order to watch the active temperature zones scroll while the unit is heating, press the Input Knob once more.

## 5.2 Controller Programming Instructions

DynaControl CONTROLLER, for PISTON PUMP MODELS 5/10, V.6.00 and Up

### 5.2.1 DynaControl (DCL) V6 LCD Interface


DynaControl V6 controller technology is available as a liquid crystal display (LCD), which allows an instant overview of temperature zone and pump status, and with a combination Input Wheel/Enter Knob to facilitate fast programming.



#### 5.2.1.1 In General

- Press the Return button to return to the Overview Screen (shown above).
- This controller utilizes the graphics  (indicating YES or ON or selected) and  (indicating NO or OFF or not-selected).
- When there is no operator activity on a screen for approximately 30 seconds, the controller will automatically return to the Overview Screen.

### 5.2.1.2 Overview Screen Reference



The Overview Screen gives a comprehensive view of the status of each of the temperature zones and the system as a whole. It gives the status, mode and speed of the pump.

The pump may be started or stopped by pressing the F5 button.



### 5.2.1.3 Status Line

The status line is the top line of the display. It always lists the System Status, the Time-of-Day and the Pump Status. It can also include the status of the Keypad (if locked) and the 7-Day Scheduler (if active). An example of an Overview Screen status line is seen below.



### 5.2.1.4 System Status

The status of the “system”, i.e. the ASU (Melter) and its hoses and applicators, is listed as one of the following:

HEAT-UP	No faults present, zones are heating but haven't reached their setpoint window.
READY	No faults present and all zones are within the setpoint window.
ALARM	At least one zone is outside the setpoint window (over or under temp).
STANDBY	The system is in standby mode.
OVER-TEMP	The hopper is in over temperature condition, all power circuits are shut off.
FAULT	A temperature zone has a fault and all power circuits are shut off.
HOPPER EMPTY	Adhesive in the hopper is low and must be replenished.


### 5.2.1.5 Pump Status

The status of the adhesive pump is listed as one of the following:

RUN	Pump has start signal and is actually running.
STOP	Pump is in Stop mode.
HOLD	Pump is in Run mode but a low temperature condition prevents it from running.


### 5.2.1.6 Temperature Zone Symbols

Each temperature zone is represented by a symbol on the display, as follows:



### 5.2.1.7 Bar-Graphs

The temperature status of each zone is shown by a bar-graph. A solid bar-graph indicates that the temperature zone is activated. An outlined bar-graph indicates a temporarily de-activated temperature zone. A question mark indicates that the zone's RTD sensor is not valid. An exclamation mark inside a solid bar-graph means that the temperature of the zone is significantly outside its setpoint window.



### 5.2.1.8 Scan Mode

Scan Mode allows the operator to watch the currently active temperature zones scroll one at a time on the Overview Screen. Each zone is displayed with its name, programmed setpoint, actual temperature and bar graph.

- *To activate Scan Mode:* On the Overview Screen, push the input knob.
- *To hold Scan Mode on one particular zone:* Push the input knob again.
- *To exit Scan Mode:* Turn or push the input wheel.

### 5.2.1.9 To Navigate Away from the Overview Screen

Press this button...	To:
<b>System Configuration</b>	Go to the System Configuration Menu to program the temperature unit, language, setpoint limitation, hi/ low tolerance, setback temperature, level control, heat-up sequence, pump enable temperature, access code, temperature offset, customer zone names, power-on configuration or view the logbook.
<b>Menu</b>	Go to the Main Menu screen to program recipes, set-back mode, keypad locking and the 7-day scheduler or to go to the Help Screen.
<b>Pump</b>	Go to the Pump Stroke Counter Screen.
<b>Return</b>	Return to the previous screen.
<b>F1, F2, F3, F4</b>	Go to the temperature zones (use as shortcuts).
<b>F5</b>	Start/Stop the piston pump.

### 5.2.1.10 Setup Your System's Parameters

System Parameter Setup refers to the process of programming the controller to meet the specific temperature requirements of your production. Temperature setpoints for each temperature zone must be programmed as well as a standby temperature and high/ low alarm tolerances. Choices must be made for program selection and pump. If desired, temperature zone offsets and/ or a temperature zone enable may be selected.

The following is a step-by-step procedure for setting up the DynaControl with your system's parameters.


## 5.2.2 Temperature Zones

### 5.2.2.1 Selecting Temperature Zones

From the Overview Screen, turn the Input Wheel slowly to view each temperature zone. As the wheel is turned, you will see the names of the individual temperature zones on the top line of the display.

To select a zone, simply stop turning the wheel when the desired zone's name appears (example below: HEAD 1). To the right, displayed on the top line, is this zone's programmed setpoint (ex. SET: 320°F) and the actual current temperature of the zone (ex. ACT: 319°F).

Below the zone's name is the bar-graph with the selected zone highlighted. Below the bar-graph you can see that this zone is #1 of the system's applicators. At the far right of the display, you can see that this zone is turned ON.



### 5.2.2.2 Selecting Temperature Setpoints


After selecting a temperature zone, press the Enter Knob to highlight the setpoint. Turn the Input Wheel to your desired setpoint value. To enter the new value, press the Enter Knob. Continue programming by entering a setpoint for each zone.

### 5.2.2.3 Turning a Temperature Zone ON or OFF

When a temperature zone is not used, it can be de-activated (turned OFF). A zone that is turned off no longer heats and is not monitored by the controller for over or under temperatures.

Even when a zone is turned off, the controller remembers its temperature setpoint and it will be restored when the zone is turned back on.

To toggle a temperature zone ON or OFF, press the Enter Knob. Then press F5. You will see the ON/ OFF switch change position. Press the Enter Knob.



## 5.2.3 Pump Settings

Return to the Overview Screen if necessary, by pressing the RETURN button.

### 5.2.3.1 Standard Piston Pump ASU

On a standard piston pump-equipped ASU, the pump is either turned ON (RUN) or OFF (STOP). There are no other pump selections.

To start or stop the pump, toggle the F5 button on the Overview Screen or the F5 button on the Pump Stroke Counter & Adhesive Usage Screen.

#### ASUs with Optional Line Speed Tracking

On units utilizing the line speed tracking option, adhesive output is adjusted automatically through a parent machine. The Dynamelt SR Pump Screen allows you to change the pump mode (Manual, Stop or Automatic) and the pump scaling factor (a minimum and maximum percentage of full pump speed).


#### Selecting Pump Mode

- AUTO Mode = the pump will be started and stopped by a parent machine (production line).
- MANUAL (MANU) Mode = the pump will be started and stopped manually by an operator.
- STOP Mode = the pump is stopped, until AUTO or MANUAL is selected.


To select a pump mode:

1. Use the function buttons:  
F2 = MANUAL Mode, F3 = STOP or F4 = AUTO Mode, or
2. Use the Input Wheel.  
If Auto or Stop modes are desired, simply turn the Input Wheel to highlight that function.

However, to select Manual mode, press the Input Wheel before turning the wheel. Pressing the Input Wheel here toggles between mode selection and percentage-of-full-speed selection. Once you are in Manual mode and you have highlighted the percentage selection, turn the Input Wheel to your desired percentage value.



MANUAL Mode is selected  
speed is 45 % of maximum pump speed



AUTO Mode is selected  
speed is 80 % of maximum pump speed

### Manual Mode Adjustments

In Manual Mode, turn the Input Wheel to increase or decrease the pump speed percentage.

Or press F5 to scroll through the pre-set speed shortcuts. The presets are 30%, 60% or 90%. Press F5 again until desired pre-set is selected. No entry confirmation is necessary.

### Auto Mode Adjustments

The ASU's pump must be programmed with a minimum and maximum percent of full (maximum) speed when Auto mode is used. The maximum speed is used as a scaling factor between the input signal (for example, a PLC) and the percent of full speed value of the pump.

The minimum speed is necessary to keep the pump moving in order to maintain a minimum amount of adhesive pressure through the hose and applicator head.

For instance, if the input signal is 10VDC at 100 meters per minute and the pump percent of full speed is 100% (maximum speed), but the system is putting out too much adhesive, adjusting the MAX value to 50 will allow the pump to slow down and adhesive output will decrease by 50%.

To Adjust: Press the F5 button once to open the minimum percent (of speed) input field. Turn the Input Wheel to select desired minimum speed. Press the Enter Knob to confirm.

Press F5 again to open the maximum percent (of speed) field. Turn the Input Wheel to select desired maximum speed. Press the Enter Knob to enter the value.

Press the RETURN button to return to the Overview Screen.


**Piston Pump Stroke Counter and Adhesive Usage Screen**

The Piston Pump Stroke Counter and Adhesive Usage screen is a feature of the controller that allows the operator to monitor the total number of strokes that the unit's piston pump has performed (the Lifetime Counter). This counter is not resettable.

The screen also allows the operator to start or reset a Current Stroke and Usage Counter, in order to monitor the number of strokes the pump has performed and the amount of adhesive used during a defined time or for a defined project.

Note: The Stroke Counter/Usage feature is not functional when the piston pump line speed tracking kit is in use.

The pump may be toggled On/Off by pressing F5 on the screen.




**Stroke Counter and Adhesive Usage Set-up Screen**

Press F1 to go to the Set-up Screen.

On the Set-up Screen:

- a. Press F1 to select the Scale Factor, then turn the Input Wheel to program its value.
- b. Press F2 to toggle between weight units: g (grams) and oz (ounces).

Examples: 24.25g/ Stroke or 1.54oz./ Stroke. (Note: the controller cannot convert between the two weight units.)




### 5.2.4 Main Menu

Press the Main Menu button on the Overview Screen to go to the following functions:


- F1: Recipe Management
- F2: Standby Mode
- F3: Setpoint Locking
- F4: 7-Day Scheduler
- F5: Info Menu

To select a function, press its “F” button (or turn the Input Wheel to highlight the desired function and then press the Enter Knob to select).



#### 5.2.4.1 Recipe Management (F1)

A recipe (or “program”) is a set of temperature setpoints and parameters which the user has programmed and stored in the controller for future use. Up to four recipes may be stored in the DynaControl controller.



**To Save a Recipe (SAVE TO PROG):**

1. Program the controller as you wish it to be setup for a recipe. Program the following parameters: temperature setpoints, zone On/Off settings and motor mode and speed.
2. Press the Main Menu button, then press F1: Recipe Management. Turn the Input Wheel to SAVE TO PROG. Press the Enter Knob to enter. Turn the Input Wheel to select a program number (up to four recipes may be created and stored). Press F5 to confirm.

**To Load a Stored Recipe (LOAD FROM PROG):**


1. Press the Main Menu button, then press F1: Recipe Management. Turn the Input Wheel to LOAD FROM PROG. Press the Enter Knob to enter.
2. Select the desired recipe by turning the Input Wheel until its recipe number is highlighted. Press F5 to confirm the selection.

**Notes:**

1. Recipes that contain temperature zones that do not show valid RTD sensors (i.e., zones with "?" in their bar-graphs) will be turned Off after re-loading, because the controller assumes those zones will not be used.
2. If you have loaded a recipe, any changes you make to the temperature or motor settings are not automatically stored in that recipe. If your changes need to be stored, go to the Recipe Management Screen and follow the steps to SAVE TO PROG.

**5.2.4.2 Standby (F2)**

In Standby mode, the temperatures of all active temperature zones will decrease by a pre-defined amount and the pump will stop (Note: the pre-defined amount is programmed on page 2 of the System Configuration Menu).



Press the Main Menu button, then press F2 to toggle between Normal mode (setpoints and pump are active) and Standby mode (setpoints are lowered and pump is stopped.) Confirm Standby mode by pressing F2 again. After making a change, a screen message will indicate, "Standby ON" or "Standby Off".

**Notes:**


Standby can also be activated via an external contact closure or via the 7-Day Scheduler, Pump Stop Mode or when the piston pump is not moving.

See also Standby Configuration in this chapter.



### 5.2.4.3 Setpoint Locking (F3)


When Setpoint Locking is on, temperature and motor setpoints and the System Configuration Menu are locked and cannot be changed. But even when locked, the pump can be stopped and the setpoints can be monitored.

When Setpoint Locking is on, a small key symbol  can be seen on the Overview Screen, near the time-of-day display.

If setpoints are unlocked and you desire to lock them, press the Main Menu button, then press F3 twice.


The controller's access code must be keyed-in to unlock setpoints. To do so, press the Main Menu button, press F3, then enter your access code using the F1 thru F5 buttons. For example, if your access code is 2453, press the sequence "F2, F4, F5, F3" (Note: setup an access code on page 3 of the System Configuration Menu).

The Dynamelt SR ASU is shipped from ITW Dynatec with a default access code of "1111".



### 5.2.4.4 7-Day Scheduler (F4)

The 7-Day Scheduler allows the user to program the ASU to automatically switch on or off at pre-programmed times and days of the week. Up to three daily programs may be setup. Each daily program can have two "on" periods with a standby period between them.



**Programming Sequence:**

Set-up each Daily Program entirely before moving on to the next Daily Program. Up to three Daily Programs may be setup. All time selections are based on a 24-hour clock.

**To Program Active Days of the Week:**

Turn the Input Wheel to the Days-of-the-Week (Note: if you can no longer see the cursor when turning the wheel, turn the wheel in the opposite direction). The Days-of-the-Week may be toggled Active (registers as "selected" on the display) or Inactive by pressing the Enter Knob.

Each day of the week can only be assigned to one program.

**To Program On/ Off Times:**

Turn the Input Wheel to select the first Switch-On time; press the Enter Knob to highlight the time. Turn the Input Wheel to program your desired Switch-On time (in hours and minutes) and press the Enter Knob.

Turn the Input Wheel to select a Switch-Off time or a Standby time, then press the Enter Knob to highlight it. As above, turn the Input Wheel to program your desired time (in hours and minutes), then press the Enter Knob.

In the same manner, if desired, program another Switch-On time and/or Switch-Off time.


**To Program Additional Daily Programs:**

Turn the Input Wheel to the second or third set of Days-of-the-Week to program Switch-On and Switch-Off times for Daily Program #2 or #3. Program in the same manner as above.

**To Choose Activate, Deactivate or Sleep Mode:**


Once the 7-Day Scheduler's Daily Programs are setup, press F5 to Activate. This is indicated by the clock symbol in the status line. To deactivate the scheduler, press F5 again.


Press F2 to put the ASU into SLEEP MODE (indicated below). In this state, the ASU will be activated at the next programmed Switch-On time of the scheduler or it can be manually started.

**7-Day Scheduler Examples (as shown on the illustration on the previous page):**

- Daily Program #1: On Mondays, Tuesdays, Wednesdays and Thursdays, the ASU will Switch-On at 6:00am. It will go into Standby at 12:00 noon. It will come out of Standby at 1:00pm and Switch-Off at 6:00pm.
- Daily Program #2: On Fridays, the ASU will Switch-On at 5:30am. It will go into Standby at 12:30pm. It will come out of Standby at 1:00pm and will Switch-Off at 4:30pm.
- Daily Program #3: On Saturdays, the ASU will Switch-On at 8:15am and Switch-Off at 12:15pm.

### Set Current Time-of-Day and Day-of-Week

While in the 7-Day Scheduler Set Up screen, press the Configuration button (  ) to set the current time and day.



↑  
Press F5 to confirm  
your changes

Turn the Input Wheel to select the item to be changed. Press the Enter Knob. Turn the Input Wheel to the desired time/ day and press F5 to confirm your entry.

Once all 7-Day Scheduler programming is completed, press the return button twice to return to the Overview Screen.


### 5.2.4.5 Info Menu (F5)

The info screens contain details about the hot melt system and can aid in troubleshooting.

**Info Screen #1:**

The first Info Screen lists temperature zone and pump configuration. It also provides the revision level of the controller's modules and the elapsed time on the Dynamelt SR ASU's controller.

Press F5 to go to the next Info Screen.



Press F5 to go to the next Info Screen


**Info Screen #2:**

The second Info Screen lists each temperature zone individually. Scroll through the zones using the Input Wheel. The zone's description (i.e., HOPPER) and zone # (i.e., Z 2), actual temperature, heat-up priority (i.e., PR 1) and location of its corresponding RTD sensor is given.

The screen also shows the physical location of the RTD connectors of the temperature module. This information can help in troubleshooting errors in wiring.

All zones are shown here, even those that are not in use on the ASU.

CV in %: CV (Control value) indicates how much power is currently applied to the corresponding heater zone.



**Info Screen #3:**

The next Info Screen provides set-up information for the unit's optional communication module. If that module is installed on your ASU, the set-up info is provided on a supplemental CD. If the module is not installed, the Info Screens end here.

Press RETURN to exit the Info screens and press RETURN again to return to the Overview Screen.

## 5.2.5 System Configuration Menu



Press the System Configuration Menu button on the Overview Screen to program the following parameters:

- Temperature/ Pressure Conversion: Fahrenheit or Celsius/ PSI or BAR
- Language Selection: English, German, Spanish, French, Japanese, Chinese and Hungarian
- Zone Configuration: typically configured by ITW Dynatec
- Pump Configuration: typically configured by ITW Dynatec
- Setpoint Limitation: sets a limit on the maximum setpoint
- Hi/Low Tolerance: the high and low temperature window which defines the Ready temperature
- Standby Configuration: amount of temperature difference, time delay, activation method and sleep mode for the standby function
- Level Detection: activates or de-activates the low adhesive level detector
- Heat-up Sequence (Priority): simultaneous or sequential heat-up of temperature zones
- Access Code: setup an access code to prevent un-authorized programming
- Temperature Offset: fine-tuning allows compensation for temperature gradients
- Customer Zone Names: allows personalization of the temperature zone's names
- Logbook/ Fault History: records the time and date of controller events and faults
- Power-On Configuration: allows custom settings for pump/motor and heaters at startup
- Global Setpoints: allows easy one-temperature programming of setpoints

### 5.2.5.1 Accessing the Parameters

There are four pages of configuration parameters. Four parameters are on each page.

Turn the Input Wheel to select the parameter to be programmed. The slider graph (on the left) indicates the page # of the System Configuration Menu. Once you select (highlight) your desired parameter, many parameters can be changed simply by pressing the Enter Knob.



You may also progress through the pages by using the Configuration button ().

When in the System Configuration Menu pages, you may return to the Overview Screen at any time by pressing the RETURN button twice.

### 5.2.5.2 Temperature Unit (P1)

After turning the Input Wheel to select the Temperature/ Pressure parameter, toggle between Fahrenheit with PSI or Celsius with BAR readouts by pressing the Enter Knob.

### 5.2.5.3 Language Selection (P1)

After turning the Input Wheel to select the Language parameter, press the Enter Knob. The current language will flash. Turn the Input Wheel to select a language from the ones listed. Confirm your choice by pressing the Enter Knob.

### 5.2.5.4 Zone Configuration (P1)

This menu configures the controller's temperature zones by listing the number of each type of zone. Zone configuration is typically done at the ITW Dynatec factory and does not require programming by the user.

### 5.2.5.5 Pump Configuration (P1)

This menu configures the ASU's pump by listing pump type. Most pump parameters are setup at the ITW Dynatec factory. The only user serviceable pump parameter is the pump enable temperature.

#### ***Pump Enable Programming:***

The Pump Enable Temperature serves as a low limit value. The controller will not allow the pump to come on until its enable temperature is achieved. By doing so, it protects the pump and pump shaft.

After pressing the Enter Knob to select the Pump Enable parameter, turn the Input Wheel to increase or decrease the pump enable temperature. Confirm your choice by pressing the Enter Knob.

### 5.2.5.6 Setpoint Limitation (P2)

This parameter sets the maximum temperature zone setpoint. The setpoint limitation is useful for an adhesive with a low melt temperature. In this case, the maximum selectable setpoint could be lowered in order to avoid over-heating the adhesive.


After turning the Input Wheel to select the Setpoint Limitation parameter, press the Enter Knob and then turn the Input Wheel to select your desired setpoint limitation value. Confirm your choice by pressing the Enter Knob.

### 5.2.5.7 Hi/Lo Tolerance (P2)

The high and low temperature tolerances can be set for each temperature zone. During operation, those tolerances activate the alarm which alert the operator to overtemp and under-temp conditions.

The hi/lo tolerances are a range (+ and -) from the setpoint. Thus, a setpoint of 150°C which has been programmed with a 10°C hi/ lo tolerance will activate an under-temp message when the zone's temperature falls below 140°C and will activate an over-temp alarm when the zone's temperature rises above 160°C. When this zone's temperature is within the tolerances (140°C and 160°C), it is considered "Ready".

Tolerances can be set individual for each zone. After turning the Input Wheel to select the Hi/Lo Tolerances parameter, press the Enter Knob to access the set-up screen:




On this screen, use the Input Wheel to select the zone and buttons F4/F5 to change the tolerance for the selected zone. Picture above shows the hopper zone is selected and the tolerance is +/-30°F. It is not necessary to confirm with the Enter Knob. After all zones have been programmed, leave this screen by pressing the Return button.

### 5.2.5.8 Standby Configuration (P2)

There are five ways to activate standby mode:

1. Manually, at the Main Menu's F2,
2. Automatically, via the 7-Day Scheduler,
3. Remotely, via an external contact (program as described below),
4. Automatically, after pump stop mode (program as described below), or
5. Automatically, after the piston pump is inactive for the programmed time delay.

Standby Configuration allows you to select #3, #4 or #5 and program other standby parameters.



Note: Automatic Standby Mode requires at least a 1-minute time delay.

### **Standby Temperature Difference**

In Standby mode, the temperatures of all active temperature zones decrease by a programmed amount and the pump(s) stop pumping adhesive.

The programmed decrease in zone temperatures is the standby temperature difference. The standby temperature difference applies to all zones once standby is activated. For example, if the difference temperature is 80°F, and setpoints are 300°F, then all zones will reduce to 220°F (300 - 80 = 220) when standby is activated.

After turning the Input Wheel to select Standby Configuration, press the Enter Knob to advance to the screen. Press the Enter Knob to select the first parameter, i.e., temperature difference. Press the Enter Knob again to highlight the temperature difference value. Then turn the Input Wheel to program your desired value. Confirm your choice by pressing the Enter Knob.

### **Standby Time Delay and Activation**

The standby time delay is the programmed number of minutes until standby takes place after activation by either an external contact (for example: a PLC or an external switch) or by a pump stoppage. The default time delay is 0 minutes (immediately!). The programmable range of the standby time delay is 0-150 minutes. For Automatic Standby Mode there is a 1 minute minimum.

Turn the Input Wheel to select the time delay parameter (i.e. Standby X min. After...). Press the Enter Knob. Turn the Input Wheel again to select your desired minutes value. Confirm your choice by pressing the Enter Knob.

Now turn the Input Wheel to select the After Ext Contact/ After Pump Stop field. Press the Enter Knob and then turn the Input Wheel to highlight your choice of activation. Confirm your choice by pressing the Enter Knob.

### **Sleep Mode After Standby**

Sleep mode shuts the ASU off after it has been in standby for a programmed length of time. This length of time can be from one hour to 99 hours. Or you can choose to program the unit to have no sleep mode by programming " - ". When the unit is in sleep mode, the Main Screen displays "System Off, Switch On with Enter Knob".

Turn the Input Wheel to select the Sleep Mode After # Hrs In Standby field. Press the Enter Knob to highlight the hours value. Turn the Input Wheel to select your desired hours value. Confirm your choice by pressing the Enter Knob.

Press the RETURN button to return to the System Configuration Menu.



### 5.2.5.9 Level Detection (P2)

The level detection sensor triggers an alarm when the liquid adhesive level in the hopper falls below a certain level. The delay time of the alarm is 10 minutes. Hopper Empty is the alarm message displayed on the controller's status line. The level detection parameter allows the user to turn the level sensor function On or Off.

After turning the Input Wheel to select the level detection parameter, press the Enter Knob to change the function from activate or deactivate (or vice versa).


### 5.2.5.10 Heat-Up Sequence (Priority) (P3)

The controller allows you to choose the heating order of the various temperature zones, so that zones requiring more time to heat up to temperature can be programmed to begin heating before others. This is done by programming each zone with a sequential heating priority.

A "Priority 1" designation means the temperature zone will begin to heat immediately after the ASU is powered on. Zones with higher priority numbers (Priority 2 through Priority 6) do not begin heating until all zones with lower priority values have reached the low limit of their setpoints. Zones which are switched OFF are not applicable.

The most common heating sequence is first hopper, then hose/ head and auxiliary zones. This allows the larger mass of adhesive in the hopper to begin heating first. This sequence (hopper, then hose/ heads and aux zones) is also the controller's default heating sequence.

After turning the Input Wheel to select the Heat-Up Sequence parameter, press F1. On the Heat-Up Sequence screen, turn the Input Wheel to select a desired zone. Press the F4 button to assign a priority number to the selected zone. Turn the Input Wheel to select another zone, if desired, and program its priority by pressing F4. Continue until all zones are programmed. Press the Enter Knob to confirm, then press the RETURN button to return to the System Configuration Menu.



Hose 1 (Z 4) has been programmed as a Priority 2 zone

### 5.2.5.11 Access Code (P3)

An active access code prevents unauthorized programming of setpoints and other configuration parameters. To utilize the Setpoint Locking feature of the controller, your access code must be keyed in at the Main Menu, F3.

The Dynamelt SR is shipped from ITW Dynatec with a default code of 1111. To re-program the access code, the current access code must be entered. All access codes must be 4-digit numbers using the digits 1, 2, 3, 4 and 5 only.

After turning the Input Wheel to select the Access Code parameter, enter the current access code using the F1 thru F5 numerals. Press the Enter Knob. Then enter your desired access code using the F1 thru F5 numerals. Confirm your choice by pressing the Enter Knob.

### 5.2.5.12 Temperature Offset (P3)

Temperature Zone Offsets are mathematical factors which compensate for differences in temperature within components. Each temperature zone may be programmed with an offset, if desired. Standard equipment does not usually require temperature offsets.

Note: Entering a positive-numbered offset will raise the temperature reading of that zone. Since the controller attempts to equate setpoint and actual temperature, this actually lowers the actual temperature by the amount of the offset.

For example: Setpoint and actual temperature both equal 300°F. An offset of +10°F is programmed. Initially the display will read 310°F, but the controller will lower the output power until the actual temperature value is back to 300°F.

After turning the Input Wheel to select the Temperature Offset parameter, press the Enter Knob to display a list of all temperature zones. Turn the Input Wheel to select a zone for programming and press the Enter Knob. Turn the Input Wheel to program the desired temperature offset for that zone. Press the Enter Knob to confirm your selection.

If desired, turn the Input Wheel to select another zone for programming. Program this zone as outlined above.


When all desired zones are programmed, press RETURN to go to the System Configuration Menu (page 1), then press RETURN again to go to the Overview Screen.

### 5.2.5.13 Customer Zone Names (P4)


With this configuration parameter, the user may personalize the names of the temperature zones with names that are more descriptive for his application. That is, instead of the factory-set zone names of Z01, Z02, Z03, etc., the customer may prefer temperature zone names such as “TANK”, “HEAD 1”, “FILTER BLOCK”, “SUPPLY HOSE - LEFT”, etc.

After turning the Input Wheel to select the Customer Zone Names parameter, press the Enter Knob to display YES. To enter programming mode, press F3 (Change Text).

Now, by turning the Input Wheel, you can scroll through the zones and see their current zone names (or numbers). These names can be re-programmed one at a time. Each new name may consist of two lines, with a maximum of 12 characters in each line. Note: the factory-set numeric “names” correspond to RTD inputs.



Customer Zone Name Programming Screen




“Supply Hose - Left Side” = Zone #6 (highlighted zone indicator)

**Using F2, F3, F4 & F5 Programming Keys:**

- F5 = press to Clear the entire zone name.
- F2 = press to select upper- or lower-case letters, to select numbers or to select special characters.
- F3 & F4 = press to Copy (F4) and Paste (F3) the name of one zone into another.

**Programming the Zone Names**

After selecting the Customer Zone Names parameter and pressing the Enter Knob to display YES, press F3 (Change Text) to begin programming.

1. Turn the Input Wheel to select desired temperature zone (refer to corresponding RTD). The selected zone is highlighted.
2. Press the Input Knob to confirm zone.
3. Turn the Input Wheel to select the character to be re-programmed.
4. Press the Input Knob to confirm selection. The cursor highlights the selected character.
5. Turn the Input Knob to select the new character.
6. Press the Input Knob to confirm the new character.
7. Repeat steps 3 through 6 to spell desired zone name.
8. Press the Return button  to select another zone to program. Repeat steps 1 through 6 for each zone desired.
9. Press Return again when all temperature zone name programming is completed.

**5.2.5.14 Logbook/ Fault History (P4)**

The Logbook provides a read-only history of the last 65 (maximum) controller faults and events. Controller faults include sensor or temperature errors or motor faults. Examples of an event include switching the ASU on/off or System Ready. The most recent event is recorded at the top of the list (No. 1).

Day, Time and Event are listed for each item in the Logbook. This information can be valuable when troubleshooting controller problems.

After turning the Input Wheel to select the Logbook parameter, press the Enter Knob to display the Logbook. Turn the Input Wheel to scroll through the list.

#1 is most recent entry →

LOGBOOK / FAULT HISTORY			
NO	DAY	TIME	EVENT
1	FRI	9:36	SYSTEM READY
2	FRI	12:05	RTD ERROR Z.4
3	THU	7:10	MOTOR FAULT
4	TUE	12:03	SYSTEM READY
5			

F1
F2
F3
F4
F5

### 5.2.5.15 Power-On Configuration (P4)

Two start-up parameters are programmed at the Power-On Configuration screen, and they are set by choosing YES or NO:

#### **Power-On Motor Stop**

At the Power-On Motor Stop parameter, you decide if you prefer the motor to be stopped when the ASU is turned on (if so, choose YES) or if you prefer that the motor remain in its previous mode when the ASU is turned on (choose NO).

#### **Power-On Heater Start**


At the Power-On Heater Start parameter, you decide if you prefer that the temperature zones start heating automatically when the ASU is turned on (if so, choose YES) or if the heaters should require a manual start when the ASU is turned on (choose NO). NOTE: If you choose NO, the heaters will not begin to heat until the Enter Knob is pressed at start-up.

From the System Configuration Menu: after turning the Input Wheel to select Power-On Configuration, press the Enter Knob. The first parameter (Power-On Motor Stop) will be highlighted (see illustration below). Press the Enter Knob to choose YES or NO.

Turn the Input Wheel to highlight the second parameter (Power-On Heater Start). Press the Enter Knob to choose YES or NO.

After programming, press RETURN twice to return to the Overview Screen.

Parameter is activated (programmable).  
Press Enter Knob to make selection.




This parameter may not be programmed until it is activated. To activate, turn the Input Wheel.


### 5.2.5.16 Global Setpoints (P4)

Setpoint programming may be simplified by programming Global Setpoints. With this parameter, the user programs a hopper setpoint and the controller configures all of the other zones. However, to do so, it must be appropriate for all your hoses to be programmed to one setpoint, and for all your applicator heads to be programmed to one setpoint.

After turning the Input Wheel to select the Global Setpoints parameter, press the Enter Knob to turn Global Setpoints On/Off.



Then press F3 to open the Global Setpoints menu.



On the Global Setpoints menu, you set up simple mathematical relationships (increases) between the hopper setpoint and the setpoints of the hoses and applicator heads. Pressing the Input Knob increases the temperature of the hose (or head) by 5 degrees, or, if you press again, by 10 degrees (press again for 15 degrees, and press again for 20 degrees). Once setup, all of the hoses will increase over the hopper setpoint by the same amount (0, 5, 10, 15 or 20 degrees) and likewise, all of the heads will increase over the hopper setpoint by the same amount as you program here.

Once Global Setpoints are setup, you simply program the hopper (as described in this chapter) and your hoses and heads will automatically be programmed to the increases you specified on the Global Setpoints menu.

For example: If you setup a Global Setpoint increase of 10 degrees for Hoses and 15 degrees for Heads, and you program your Hopper setpoint to 290 degrees, then the controller will automatically program all of the hoses to 300 degrees and all of the heads to 305 degrees.

When Global Setpoints are turned On and a temperature setpoint is changed, the display will not show the selected zone's name. Instead it will display GLOBAL SET:.

You can still turn individual zones Off and On while using Global Setpoints.

## Chapter 6

# Maintenance and Repair Notes

### 6.1 Security advices for maintenance and repair



Heed all security advices given in Chapter 2.

Use only original parts from ITW Dynatec, otherwise ITW Dynatec's warranty is void!

Maintenance and repair work is only permitted for skilled personnel!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or heavy burns!

#### High Voltage! Risk of injury and mortal danger!

- All electrical connections must be made by qualified electrical personnel.
- Care must be taken to assure proper grounding prior to any disassembly.
- Lockout and tag the electrical sources as required.
- Make sure there is no electrical power on the leads you will be connecting.
- When covers are removed, high voltage sources create an electrocution hazard.
- Wear appropriate safety equipment when working with high voltage sources.

#### Parts and surfaces of the unit get very hot. High temperatures! Risk of heavy burns!

#### High adhesive temperature and adhesive pressure! Risk of injury or heavy burns!

Always assume that the system is under pressure, proceed with caution.

Keep a cool-pack, or bucket of clean water near the work area.

Place a heat-resistant catchment container/underlay under the components. Hot adhesive may come out.

CAUTION: At working temperature, molten adhesive could cause heavy burns. Let spilled out adhesive cool down first, before removing it!

CAUTION: Use only lint-free cleaning cloth and suitable cleaner for cleaning! Do not damage surfaces! Do not scratch above them with sharp-edged tools, otherwise the components will get leaky and inoperable!

#### All maintenance and repair work has to be done at working temperature, except as noted otherwise. Else there is a risk of damaging the unit components!

#### Before any service work disconnect the external power supply and switch the unit voltage-free:

1. Switch off the main switch and the controller.
2. Disconnect the power supply respectively remove the plug / cable.
3. Guard the unit against unauthorized restarting!

#### Before any service work the adhesive pressure must be relieved throughout the system. Switch the unit pressureless:

1. Disconnect the pressure air supply.
2. Turn the pressure regulator to zero bar, if necessary. Wait approximately 1 minute until the pressure is relieved.
3. Open the applicators purge valve or open the modules by activating the solenoids to relieve any adhesive pressure.

### 6.1.1 Equipment Preparation for Maintenance & Repair

- Adhesive processing equipment must be worked on while hot enough to soften any material residue within the assembly. This depends on the type of adhesive used with the equipment. This may require the system to be up to operating temperature before disassembled, to prevent damage to fasteners and components.
- Once disassembled, the individual parts may be cleaned by immersion in approved solvent. Surface deposits may be removed by lightly scrapped with a brass device or scrapper. Care must be taken not to damage sealing surfaces with sharp objects or sand paper.
- Components such as O-rings, fasteners and relief valves should be discarded and replaced by certified ITW Dynatec replacement parts.

### 6.1.2 Re-Assembly Procedures and General Cautions

Unless noted, the re-assembly is simply the reverse sequence of the disassembly procedures. However, the following “cautions” should be followed (whenever they apply) for proper re-assembly:



#### CAUTION

In general, all O-RINGS AND SEALS must be replaced whenever hot-melt equipment is re-assembled. All new O-rings must be lubricated with O-ring high-temp lube,(PN 001V078).

TAPERED PIPE THREADS are found on air pipe fittings used with the pump air supply and on the outlet filter manifold. Apply thread sealant (PN N02892) whenever tapered pipe threaded parts are re-assembled.

SOME FITTINGS used for adhesive on hot melt equipment have straight threads and O-ring seals. Use of thread sealant is not necessary with these parts, but the O-ring seals should be clean and lubricated. Tighten straight-threaded parts and fittings until their shoulders are firmly seated. Excessive torque may damage straight-threaded parts and the use of power wrenches is not recommended.

HOT-MELT RESIDUE must be cleaned from parts before they are re-assembled, particularly from threaded parts. As a precaution against adhesive residue preventing proper re-assembly, threaded parts must always be re-tightened at operating temperature.

### 6.1.3 Cleaning Recommendation

- Filters are disposable and need to be replaced regularly. DO NOT boil in mineral oil, solvents or water; the sealant used in filter assembly may become brittle and very likely disintegrate when boiled.
- When cleaning other components in mineral oil, remove all non-metallic items (O-rings, seals, filter cartridge, etc.) away from chemicals before components are subjected to hot mineral oil cleaning.
- If there is not a specific rebuild kit available or directions on how to clean a part, please treat it as a replacement item and do not attempt to clean/rebuild.



## 6.2 Maintenance plan



### CAUTION

Heed all security advices given in Chapter 6.1.

Use only original parts from ITW Dynatec, otherwise ITW Dynatec's warranty is void!

Please use only the indicated lubricants and keep the prescribed maintenance intervals. Consider in addition the enclosed regulations of manufactures.

Punctual and conscientious maintenance of the unit secures not only a trouble free function, but prevents also for expensive repair costs.

Remove all materials and tools used during the repair or maintenance from the workspace of the unit.

Place a heat-resistant catchment container/underlay under the components. Hot adhesive may come out.

Use only lint-free cleaning cloth and suitable cleaner for cleaning! Do not damage surfaces! Do not scratch above them with sharp-edged tools, otherwise the components will get leaky and inoperable!

#### Maintenance plan:

Operating time/ frequency	Inspection point / maintenance notes
Continuous	<ul style="list-style-type: none"> <li>Remove dropped out adhesive and scrap adhesive and search for the cause of that, eliminate the cause.</li> <li>Listen for abnormal sounds of the unit, e. g. from the motors, pumps, etc.</li> </ul>
Once a day	<ul style="list-style-type: none"> <li>Clean the ASU and components from dirt.</li> </ul>
Once a week	<ul style="list-style-type: none"> <li>Check pump and their seals for wearing and leaks and replace if necessary.</li> <li>Check output filter for clogging and replace if necessary.</li> <li>Check pressure relief valves for function and replace if necessary.</li> <li>Check air supply connections for leaks and tighten if loose or replace if necessary.</li> <li>Check the solenoid valves for proper function and replace it if necessary.</li> <li>Check for adhesive residue in the manifold drip tray. If residue is found, inspect and replace the pump seal, as required.</li> </ul>
Every 3 months	<ul style="list-style-type: none"> <li>Inspect filter and shutoff assembly. Clean or replace the assembly if necessary.</li> <li>Check pump mounting screws for tightness and tighten if necessary.</li> <li>Check all hose fittings for tightness and tighten if necessary.</li> <li>Due to temperature differences a loosening of threads (threaded connections) is possible. Check all parts with threads, all screw fittings and fasteners for tightness and tighten them if necessary.</li> </ul>
Once a year	<ul style="list-style-type: none"> <li>Clean the ASU.</li> <li>Complete check-up for wearing.</li> </ul>
Every two years	<ul style="list-style-type: none"> <li>Complete maintenance.</li> </ul>

## 6.3 General Cleaning

Follow the manufacturer's directions when using industrial cleaners on the enclosure.


The enclosure is comprised of both injection-molded nylon and epoxy powder-coated steel panels. The painted steel panels may be cleaned with a variety of industrial cleaners following manufacturers' directions. The polymer panels may be cleaned with mineral spirits.

For easy cleaning, the hopper collar, lid liner and manifold drip tray are coated with the same PTFE release coating used in the adhesive hopper.


The manifold insulator is replaceable in the event it becomes dirty or is damaged. The unit should not be operated without this insulator in place.

The ASU was designed to channel adhesive overflow out the back of the unit and down the rear panel.

View DM SR5/10:






View SR22/45:



## 6.4 Purging the Filter Manifold of Adhesive and Pressure

As a safety precaution, purge the filter manifold of pressure and adhesive before changing the output filter or before removing any of the hoses or applicators from their manifold port.

### WARNING

Heed all security advices given in Chapter 6.1.

Maintenance and repair work is only permitted for skilled personnel!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!

**During the purging procedure, hot adhesive can come out of the manifold under high pressure. Avoid splashing hot adhesive. Stand clear of the ASU until all pressure is relieved.**


Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.

### Purging Adhesive Pressure from a Piston Pump Unit


The piston pump-equipped Dynamelt SR uses an air-controlled pressure relief valve that dumps adhesive pressure back into the unit's hopper whenever the pump or the ASU is turned OFF.

To ensure operator safety, ITW Dynatec recommends that the following procedure for relieving adhesive pressure be utilized in conjunction with the air-controlled relief valve.

SR5/10 Melter:



SR22/45 Melter:



1. The system should be at operating temperature.
2. Turn the pump/ motor OFF.
3. Switch the unit voltage-free and pressureless.

4. Guard the unit against unauthorized restarting.
5. Place a heat-resistant catchment container/underlay under the manifold's purge drain. Hot adhesive may come out!
6. Locate the purge valve (screw) on the side of the filter manifold. The purge valve is the bottom-most port on the manifold.
7. With a 5mm Allen wrench, slowly loosen the purge screw. Do not attempt to remove the purge screw. Allow the adhesive and pressure to drain. All the adhesive will flow into the heat-resistant container.
8. After adhesive pressure has been relieved, re-tighten the purge screw.

**After finishing the maintenance or repair works:**

- Remove all materials and tools used during the repair or maintenance from the workspace of the unit.
- Connect the voltage supply and the compressed air supply. Heat the unit up. Wait until all temperatures are within the tolerances and the adhesive in the hopper is molten completely.
- Continue production.

## 6.5 Preventive Maintenance

### 6.5.1 Preventive Maintenance Schedule


The Dynamelt SR requires periodic maintenance to function reliably. The Elapsed Hours feature of the controller (on Info Screen #1, see Chapter 5) can aid in determining a maintenance schedule. Refer to 6.2 Maintenance Plan.

The ASU parts that require regular, periodic maintenance are as follows:


### 6.5.2 Output Filter, Checking and Replacement

The output (pump) filter cartridge should be replaced monthly during the first few months of operation. After you gain experience with your system, you can determine how often you need to replace it. The output filter is located on the output filter manifold on the hose connection panel of the ASU. See illustration.








#### SR5/10 Melter:



#### SR22/45 Melter:




Use the following procedure to replace the output filter:

      	<b>WARNING</b>
	Heed all security advices given in Chapter 6.1.
	Maintenance and repair work is only permitted for skilled personnel!
	Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!
	<b>Use the output filter manifold's purge valve to relieve adhesive pressure before performing any pump filter maintenance. See the section titled "Purging the Filter Manifold of Adhesive and Pressure" for detailed instructions.</b>


**During the purging procedure, hot adhesive can come out of the manifold under high pressure. Avoid splashing hot adhesive. Stand clear of the ASU until all pressure is relieved.**

**The filter cartridge will be covered with hot adhesive and must be handled with proper tools.** Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.


	<b>NOTE:</b> The <b>filter nut</b> has <u>right-hand thread</u> and the <b>filter cartridge</b> has <u>left-hand thread</u> .
--	--

To replace the Output Filter:

1. The system should be at operating temperature.
2. Turn the pump/ motor OFF.
3. Switch the unit voltage-free and pressureless.
4. Guard the unit against unauthorized restarting.
5. Place a heat-resistant catchment container/underlay under the purge valve drip tray. Hot adhesive may come out!
6. Open the applicators/modules by activating the solenoid to relieve adhesive pressure.
7. Wearing insulated gloves, arm guards and a face shield, use a 5mm Allen wrench to open the purge screw within the purge valve. A small amount of adhesive will pop out of the drain valve, relieving stored pressure in the manifold. Allow the adhesive to drain into the container.

	<ul style="list-style-type: none"><li>• <b>During the purging procedure, hot adhesive can come out of the manifold under high pressure.</b></li><li>• <b>Avoid splashing hot adhesive.</b></li><li>• <b>Stand clear of the Melter until all pressure is relieved.</b></li></ul>
---	---

8. After all pressure has been drained from the manifold, remove the filter nut with a 25mm (1") wrench. All the O-rings and the filter cartridge are attached to the filter nut.

	<b>The filter will be covered with hot adhesive and must be handled with proper tools.</b>
---	--

9. Inspect the filter nut and O-rings for damage and replace, as necessary. When replacing O-rings, lubricate the new O-ring with O-ring lubricant prior to installation.

10. Install a new filter cartridge onto the filter nut.
11. Re-install the filter assembly into the manifold.  
Tighten the filter nut to 15-20 ft.-lbs (20-27 Nm) being careful not to damage the O-ring seal.  
**Note:** when correctly installed, the filter nut sits below the top surface of the manifold.
12. Close the drain valve purge screw, return the equipment to service and check for leaks.
13. If leaking, it may be necessary to replace the filter nut O-rings.

**After finishing the maintenance or repair works:**

- Remove all materials and tools used during the repair or maintenance from the workspace of the unit.
- Connect the voltage supply and the compressed air supply. Heat the unit up. Wait until all temperatures are within the tolerances and the adhesive in the hopper is molten completely.
- Continue production.

**6.5.3 Hose Fittings**


All hose fittings should be checked for tightness after every three months of operation.

**6.5.4 Fasteners**

Check that all fasteners are tight after the first ten hours of operation. Re-check all fasteners after every three months of operation.



### 6.5.5 Filter and Shutoff Assembly, Cleaning and Replacement, SR5/10




Maintenance and repair work is only permitted for skilled personnel!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!

**Use the output filter manifold's purge valve to relieve adhesive pressure before performing any pump filter maintenance. See the section titled "Purging the Filter Manifold of Adhesive and Pressure" for detailed instructions.**

**During the purging procedure, hot adhesive can come out of the manifold under high pressure. Avoid splashing hot adhesive. Stand clear of the ASU until all pressure is relieved.**


**The filter cartridge will be covered with hot adhesive and must be handled with proper tools.** Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.



**NOTE on Function:**


- This assembly is installed in the hopper (tank) in the adhesive channel to the pump. It functions as a pre-filter and filters debris and it prevents them from entering into the adhesive system. During production it must always be turned ON (open, to right position).
- Turn this assembly to the OFF (close, to left position), for example during pump replacement, to prevent that the adhesive flows out of the tank (shutting-off the adhesive flow).


*Knob of the filter and shutoff assembly:*



Above: Open position

Below: Closed position






Access Cover

Filter and shutoff assembly:  
Turn knob to left position = closed/ OFF  
Turn knob to right position = open/ ON (shown)

1. Pump all adhesive out of the hopper.
2. Turn the pump OFF.
3. Switch the unit pressureless.
4. Lower the temperature of the application system to the adhesive's softening point.



**WARNING HOT SURFACE**


**The ASU will still be hot during this procedure. Use insulated gloves and protective clothing when removing the filter and shutoff assembly.**

5. Remove the orange access cover by loosening the captive screw and lifting the panel off of the base rail.
6. Wearing gloves, unscrew the filter retaining nut and pull the filter and shutoff assembly out of the hopper.
7. Immerse the clogged filter in flushing fluid (PN L15653) to loosen contaminants. Remove filter from fluid and use a hot air gun (if necessary) and rags to clean all contaminants from the filter.  
**NOTE:** If the filter cannot be cleaned, replace the entire assembly.
8. Install a new o-ring PN N00210 on the filter and shutoff assembly. Apply a coat of anti-seize compound onto the threads of the filter retaining nut and re-install the filter and shutoff assembly into the hopper.
9. Position the filter knob in the OPEN position (see illustration) and install the M6 set screw until it bottoms. Do not overtighten!
10. Replace the orange access cover and restore the ASU to normal operation.

**After finishing the maintenance or repair works:**

- Remove all materials and tools used during the repair or maintenance from the workspace of the unit.
- Connect the voltage supply and the compressed air supply. Heat the unit up. Wait until all temperatures are within the tolerances and the adhesive in the hopper is molten completely.
- Continue production.

### 6.5.6 Filter and Shutoff Assembly, Cleaning and Replacement, SR22/45




Maintenance and repair work is only permitted for skilled personnel!

Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!

**Use the output filter manifold's purge valve to relieve adhesive pressure before performing any pump filter maintenance. See the section titled "Purging the Filter Manifold of Adhesive and Pressure" for detailed instructions.**

**During the purging procedure, hot adhesive can come out of the manifold under high pressure. Avoid splashing hot adhesive. Stand clear of the ASU until all pressure is relieved.**


**The filter cartridge will be covered with hot adhesive and must be handled with proper tools.** Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.




**NOTE on Function:**

- This assembly is installed in the hopper (tank) in the adhesive channel to the pump. It functions as a pre-filter and filters debris and it prevents them from entering into the adhesive system. During production it must always be turned ON (open, to vertical position).
- Turn this assembly to the OFF (close, to horizontal position), for example during pump replacement, to prevent that the adhesive flows out of the tank (shutting-off the adhesive flow).

Knob of the filter and shutoff assembly:




Open (ON) Position



Closed (OFF) Position

M6 Set screw



1. Pump all adhesive out of the hopper.
2. Turn the pump/ motor OFF.
3. Switch the unit pressureless.
4. Lower the temperature of the application system to the adhesive's softening point.

**WARNING HOT SURFACE**

**The ASU will still be hot during this procedure.  
Use insulated gloves and protective clothing when removing the filter and shutoff assembly.**





5. Remove the front access cover by loosening the captive screw and lifting the panel off of the base frame.
6. Remove the M6 set screw.  
Wearing gloves, unscrew the filter retaining nut and pull the filter and shutoff assembly from the hopper.
7. Immerse the clogged filter in flushing fluid (PN L15653) to loosen contaminants. Remove filter from fluid and use a hot air gun (if necessary) and rags to clean all contaminants from the filter.  
**NOTE:** If the filter cannot be cleaned, replace the entire assembly.
8. Install a new o-ring PN N00210 on the filter and shutoff assembly. Apply a coat of anti-seize compound onto the threads of the filter retaining nut and re-install the filter and shutoff assembly into the hopper.
9. Position the filter knob in the OPEN position (see illustration) and install the M6 set screw until it bottoms. Do not overtighten!
10. Replace the orange access cover and restore the ASU to normal operation.

**After finishing the maintenance or repair works:**

- Remove all materials and tools used during the repair or maintenance from the workspace of the unit.
- Connect the voltage supply and the compressed air supply. Heat the unit up. Wait until all temperatures are within the tolerances and the adhesive in the hopper is molten completely.
- Continue production.

### 6.5.7 Flushing the System

Contaminated adhesive, accumulation of residue in the system and hopper, or changing the adhesive formulation may require the system to be flushed. To flush the system, have at least 6 liters (1.5 gallons) of flushing fluid on hand (PN L15653).

	<b>WARNING</b>
	Heed all security advices given in Chapter 6.1. Maintenance and repair work is only permitted for skilled personnel!
	<b>The flushing fluid will splash easily.</b> Always wear safety shoes, heat-resistant protective gloves, safety goggles and protective clothing that cover all vulnerable parts of the body while working on the heated unit! Risk of injury or severe burns!
	Components and adhesive are hot. Take every precaution to prevent the material and hot surfaces from contacting the skin.

1. Pump out as much of the molten adhesive as possible.
2. Reduce the pump pressure to zero.

Note: the hose used in the following process is merely for the convenience of depositing flushing fluid. This procedure does not have to be repeated for each hose in the system.

3. Disconnect one of the supply hose's adhesive feed from its applicator head. Do not disconnect the electrical power to the head (since that would disable the pump). Put the hose in a secured position within a heat-resistant container, which will catch the used flushing fluid.
4. Add flushing fluid to the hopper and allow approximately fifteen minutes for it to reach hopper temperature. Carefully stir the flushing fluid to mix with any adhesive remaining in the hopper.
5. Slowly increase the pump pressure. Pump as much of the flushing fluid through the hopper, pump and adhesive supply hose into the flushing container.

	<b>WARNING HOT ADHESIVE</b> Avoid splashing the flushing fluid from the end of the hose.
---	---

6. Reduce the pump speed to zero.
7. Add new adhesive to the hopper and allow it to reach application temperature.
8. Slowly increase air pressure to the pump.
9. Actuate each of the heads until all the flushing fluid is removed and a steady stream of new adhesive flows. Reduce the pump speed to zero.
10. Remove the output filter and replace the filter cartridge. Install a new O-ring on the filter nut (lubricate the new O-ring with O-ring lubricant prior to installation) and tighten the filter nut.
11. Re-adjust the pump air pressure for the desired flow.
12. Re-fill the hopper with adhesive. The system is now ready for production.



# Chapter 7

## Troubleshooting

### 7.1 General Troubleshooting Notes



**NOTE:** Please re-read all security advices given in Chapter 2 before performing any troubleshooting or repair procedures.

All troubleshooting or repair procedures must be performed by qualified, trained technicians.



#### DANGER HIGH VOLTAGE

The Dynamelt ASU uses electrical power that can be life threatening and hot-melt adhesives that can cause serious burns. Only qualified persons should perform service on the ASU.



#### WARNING HOT SURFACE

Severe burns can occur if unprotected skin comes in contact with molten adhesive or hot application system parts.

Some of the procedures in the following Troubleshooting Guide require working near hot adhesive.

Face shields (preferred) or safety glasses (for minimum protection), heat-resistant protective gloves and long-sleeved clothing must be worn whenever working with or around adhesive application systems.

Use proper tools for handling hot melt components.



#### CAUTION

Printed circuit boards (PCBs) are prone to damage from static electrical charges during handling. Read the section on “Handling Printed Circuit Boards” before handling or attempting service on Dynamelt’s PCBs.

The Dynamelt’s DynaControl includes malfunction self-diagnostics, alerts and error indication alarms. The error indication alarms (the alarms displayed on the DynaControl readout) are triggered whenever there is a sensor failure and whenever there is an over-temperature condition. The operation of the error indication alarms is described in Chapter 5 of this manual.

#### 7.1.1 Preliminary Checks: Verify the following before proceeding:

1. The ASU is switched on.
2. The ASU is supplied with power.
3. The ASU is supplied with pneumatic air (if applicable).
4. Pneumatic and electrical connections are correct.
5. Adhesive is in the hopper.
6. The temperature controller is in operation. The setpoints are correct for the Melter, Heated Hoses and Applicators. All components are heating properly.

#### 7.1.2 Error Messages:

The controller indicates an error by displaying the word FAULT or ALARM in either the System Status or the Pump Status fields of the HMI.




See examples of controller error messages in the Troubleshooting Guides section of this chapter.

### 7.1.3 Hose/ Applicator Troubleshooting Tip

Hose or Applicator problems can be isolated by electrically connecting the Applicator and hose to an alternate socket on the ASU. If the malfunction goes with the Applicator and hose, the problem will usually be in the Applicator or hose that was moved. If the malfunction does not move with the Applicator and hose, the problem is probably in the ASU.

Before disconnecting a hose or Applicator, always turn its temperature zone OFF at the controller. This will avoid controller alarms and possible system shutdown.

### 7.1.4 Location of Components





### 7.1.5 High-Temperature Redundant Overtemp Thermostat

The Dynamelt SR Series ASU includes a mechanical (redundant) Overtemp thermostat that acts as a safety backup. If the ASU's hopper temperature should exceed 232°C (450°F), the thermostat will cause the ASU's power relays to open and power to the hopper and all hoses and heads will be cut off. The mechanical thermostat must be manually re-set after the hopper temperature falls below 204°C (400°F).


The Overtemp thermostat is located on the front side of the hopper, behind the access cover (see illustration on previous page). To reset: turn OFF the ASU's main power switch; loosen the captive screw to remove the access cover; push the center of the thermostat's insulator to re-set; restart the ASU.

### 7.1.6 Lithium Battery on Operator's Panel Printed Circuit Board

The operator display panel's printed circuit board contains a lithium battery which powers the seven-day scheduler's clock. The normal life of this battery is about ten years. When the battery needs replacement, the scheduler's clock does not function, but other controller features remain intact. Return the board to ITW Dynatec for battery replacement.

### 7.1.7 DynaControl V6 Modules

The DynaControl V6 control package is built from encapsulated modules that snap onto the DIN rail within the ASU. The modules communicate via a proprietary serial communication. Each module has a status LED (ON/ERR). This LED shows the module's status, as follows:



- Blinking green = Everything o.k. Communication is working
- Solid red = Communication fault
- No Light = Module is defective or no voltage supply

### 7.1.8 7-Day Scheduler Use with Pendant Control

Units, which are controlled via the optional pendant controller, must remain connected to the pendant if the 7-Day Scheduler feature is employed. The 7-Day Scheduler will not function when the pendant controller is disconnected.

### 7.1.9 Handling Printed Circuit Boards (PCBs)

The Dynamelt ASU and DynaControl controller utilize several modules and printed circuit boards (PCBs). These boards are extremely sensitive to electrostatic charges. When working near or with these components, the following procedures must be followed to avoid damage to them.



#### **DANGER HIGH VOLTAGE**

**Before unplugging connectors from the modules or I/O PCBs, ground yourself to the ASU by touching any available unpainted cool metal surface, mounting screws, etc. This will avoid electrical discharge to the assembly when you are removing and replacing connectors.**



#### **CAUTION**

**Modules and printed circuit boards (PCBs) should be handled using the following procedures:**

1. Wear a wrist grounding strap. If a grounding strap is not available, frequently touch a bare metal part of the ASU (unpainted frame, mounting screw, etc.) to safely discharge any electrostatic buildup on your body.
2. Handle a PCB by its edges only. Don't grip a PCB across its surface.
4. When removed from the ASU, each PCB must be individually packaged inside a metalized, static drain envelope. Do not place the removed PCB on a table, counter, etc. until it has first been placed in or on a static drain envelope.
5. When handing a PCB to another person, touch the hand or wrist of that person to eliminate any electrostatic charge *before* you hand the PCB to him.
6. When unwrapping a PCB from its static drain envelope, place the envelope on a *grounded, nonmetallic* surface.
7. To cushion modules or PCBs for shipment, use only static-drain bubble pack. Do not use foam peanuts or bubble pack not known to be static draining.


The following pages detail the Dynamelt SR Series modules and PCBs.

## 7.2 V6 Base Module PN 115734

The V6 Base Module is the main control module of the DynaControl V6 controller. Most of the internal and external components are connected to the Base module. The Base module is always the left-most module on the DIN-rail.



ITW Dynatec recommends using dry contacts for connecting to DynaControl V6!



**V6 Base Module, cont.****Description of Components**

The following items are referenced to the illustration on previous page:

- **Item #1** The controller runs on standard 24VDC. The supply voltage, coming from the 24VDC power supply, is connected to this terminal. The input is polarity sensitive.
- **Item #2** The operator's panel connects to this header via a ribbon cable. There are several types of operator's panels available. They are interchangeable.
- **Item #3** This connector provides customer accessible relay contacts. There are three pairs of dry contacts which are designed for maximum 240 VAC/1A.

The default functions of the relays are:

**Relay 1: Ready Signal**

This contact closes once the system is in ready condition (ready condition = all active temperature zones are within their tolerances and there is no other alarm message pending). Normally open.

**Relay 2: Alarm Signal**

This contact opens whenever a critical situation arises. A critical situation could be a defective temperature sensor, an over or under temperature situation, a motor driver fault, etc. Normally closed.


**Relay 3: Hopper Empty Signal**

This contact closes when the adhesive level in the hopper drops below a certain level. It can be used to indicate this situation via an external light or an audible alarm. Normally open.

Note: Depending on the controller's settings, one or more of the relay outputs may be re-programmed for different purposes. In this case, refer to corresponding set-up instructions.


- **Item #4** This connector is used for a module-to-module connection. It provides the power-on signal to the power board through the TEMP board. In the case of a critical alarm, this 24 VDC signal will drop, cutting off the heater power on the power boards.
- **Item #5** This connector accepts external signals that can be used to control the ASU. The inputs require 24VDC signals. Although the internal 24VDC can be used to provide voltage for the inputs, it is recommended to use external 24VDC. For this purpose, the common of the signal inputs is available on terminal IN-C. and is isolated from the internal 24VDC.


All inputs are not polarity sensitive. That means the common (IN-C.) can either be positive or negative.



**V6 Base Module, cont.**

Alternatively, it is possible to use the external inputs via 'dry' contacts:





**WARNING:**  
The ASU's internal 24VDC is grounded. It is not recommended to connect external 24VDC with the internal. If this cannot be avoided, it is important that the ground potential of the external and that of the ASU is equal. If this is not the case, damage to the V6 control modules is possible.

Inputs ST.BY, PU.ST. IN2 and IN3 are dedicated for default functions.  
Input 4 is for future use.

**Input ST.BY: External Standby/ Setback**

Activating this input sets the ASU in Standby Mode. In standby mode, all temperature zones will lower their temperatures by a programmed amount. Opening that contact will return to normal mode.

**Input IN2 & IN3: External Program/ Recipe Selection**

By activating these inputs, it is possible to load one of four programs (recipes) into the controller.


- The two inputs (IN) are coded in the following way:
- Activate IN2 while IN3 is not activated: Load Program 1
  - Activate IN3 while IN2 is not activated: Load Program 2
  - Activate IN2 while IN3 is activated: Load Program 3
  - Activate IN3 while IN2 is activated: Load Program 4

Notes: the controller loads the new program when the corresponding input is activated. Deactivating an input does not affect the process.

It is possible to load a new program manually, independent from the input situation.

- **Item #6** This output signal provides 24VDC for the piston pump enable solenoid. The solenoid valve activates the piston pump when all temperature zones are within tolerance and the customer has switched the pump into run mode.
- **Item #7** This input is connected to the over-temperature thermostat on the hopper. In the unlikely event that that hopper temperature exceeds 450°F (232°C), the thermostat will open and cause the power to all the heaters to be cut off. A corresponding alarm message will appear on the controller's display. The thermostat must be manually re-set after the hopper temperature falls below 400°F (204°C).
- **Item #8** This connects to the motor driver. It is used on gear pump models only.  
MB / MC: Alarm contact indicating driver fault.  
SC / S1: Pump start signal.  
A1 / AC: 0-10V pump speed signal.

• **Item #9**



If the ASU is equipped with a digital pressure read-out, it connects to this terminal. The transducer type is two-wire 4-20mA.

In order to monitor the actual speed, an RPM reading device (gear pumps) or stroke counter (piston pumps) can be connected to this terminal.

In order for a gear pump to follow the line speed of a parent machine, a 0-10VDC voltage is required. This input voltage is connected to these terminals. The input is polarity sensitive. When an optional signal isolator is installed, the line speed input is located on the signal isolator.


**Warning:** The line speed input is grounded. If the line tracking voltage has a different ground potential, it is recommended to use a signal isolator. Otherwise, damage to the V6 modules is possible.

### 7.3 V6 Temperature Module PN 115735

The V6 TEMP module is mounted to the right of the V6 base Module on the Din-rail. It requires 24VDC supply voltage. It is responsible for the temperature control of all heated temperature zones. The RTD temperature sensors connect to this module and the TEMP module provides corresponding output signals to the power boards. Depending on the configuration of the ASU, the RTDs may be PT100 (DynaControl) or NI120 (NDSN). Configuration is determined by a jumper located within the module (see below, to left of module illustration).

Each of the maximum 15 zones has a status LED which shows its heating status in the following manner:

- if the zone is switched off, the LED is Off,
- if the zone is heating, the LED is On,
- if the zone is near or at the setpoint temperature, the LED blinks.



Dynacontrol RTD ASU:  
Jumper positioned horizontally, as above.

Approx. location of the jumper inside the module.

NDSN RTD ASU: Jumper positioned vertically, as above.

Heater Control output.

### 7.3.1 Standard System Zone Tables


#### Dynamelt SR5/10/22/45

Zone 1	Premelt Grid (not available on SR5)
Zone 2	Hopper
Zone 3	Filter on SR5/10; Premelt Grid #2 on SR45
Zone 4	Hose 1
Zone 5	Head 1
Zone 6	Hose 2
Zone 7	Head 2
Zone 8	Hose 3
Zone 9	Head 3
Zone 10	Hose 4
Zone 11	Head 4
Zone 12	Hose 5
Zone 13	Head 5
Zone 14	Hose 6
Zone 15	Head 6
Zone 16	n/a



## 7.4 V6 Power Module PN 115732

The V6 POWER module provides controlled power to the heater of the first five zones. It receives its control signals from the V6 TEMP module. The Power Module also has protected outputs for the DC power supply and motor drive.



### Fuses

The fuses of the POWER Module are located underneath a protective cover. The cover should only be removed after the ASU is switched Off and disconnected from the main power supply. After checking or replacing fuses, the cover must be re-installed.

Heater fuses are fast-acting (10AF/12AF). For fuse sizes see picture above.

Always replace fuses with the same type of fuse.

### Voltage Configuration Connector


The appropriate voltage configuration plug must be installed for the machine to operate properly. Three different connectors (plugs) are available:

- PN 115724 - 230/240V single phase (black)
- PN 115725 - 240V three phase, Delta (violet)
- PN 115726 - 400V three phase, Wye (yellow)

## 7.5 V6 Aux Power Module PN 115733

The V6 AUX module provides controlled power to the heater of the additional five zones. It receives its control signals from the V6 TEMP module. Depending on the configuration of the ASU there could be one or two of these modules in the system.

The fuses of the AUX Module are located underneath a protective cover. The cover should only be removed after the ASU is switched Off and disconnected from the main power supply. After checking or replacing fuses, the cover must be re-installed. All heater circuits are fused on both legs with 10AF/12AF fuses. Always replace fuses with the same type of fuse.



## 7.6 Optional Printed Circuit Boards


Wiring diagrams and other details on the following optional PCBs can be found on the main ASU schematic (PN 115894) in Chapter 11:

- Adhesive Level Sensor (hopper low level detection)
- Stack Light (system status lights)
- Signal Isolator (gear pump models/ auto mode)/ Line Speed Following (piston pump models/ line speed tracking)
- Trigger Switch Pump Enable (hand-held applicators/ swirl kits)
- EtherNet/ IP (communications protocol)

## 7.7 Piston Pump Control Board, PN 115801

The PN 115801 printed circuit board controls the air motor/ piston pump via an electronic shifting mechanism. Its electronics are factory calibrated and normally do not need service. However, if the PCB or other parts of the air motor assembly are replaced, it may be necessary to re-adjust the board. The board is located within the top compartment of the piston pump.

Based on the position of the piston inside the air motor cylinder, the control board activates one of the two solenoid valves that control the up and down movement of the piston. The position of the switching points can be adjusted using the two trim potentiometers R1 and R2.



Before starting, be sure there is pressurized air connected to the ASU and that the ASU and the pump are switched On. Open the electronics cover.

Depending on the status of the pump, follow these procedures:

### 1. Pump is not stroking

Check the pump status in the display.

#### a. If status shows STOP:

<ul style="list-style-type: none"> <li>the pump is switched off</li> </ul>	Go to the pump screen and switch the pump On.
--	---

#### b. If status shows HOLD:

<ul style="list-style-type: none"> <li>the ASU may not be ready</li> </ul>	Wait for the temperature zones to reach setpoint, lower the setpoint, or widen the temperature tolerance.
<ul style="list-style-type: none"> <li>Hopper zones are below the pump enable temperature</li> </ul>	Wait for hopper to reach pump enable temperature, lower the pump enable temperature, or raise the hopper setpoint and wait.

#### c. If status shows RUNNING:

<ul style="list-style-type: none"> <li>no LED is lit</li> </ul>	The PCB has no power. Check connection to the Base module.
<ul style="list-style-type: none"> <li>UP LED is lit</li> </ul>	Perform Calibration Procedure 1.
<ul style="list-style-type: none"> <li>DN LED is lit</li> </ul>	Perform Calibration Procedure 2.

## 2. Pump is stroking, but may need calibration

Check the UP and DN LEDs.

<p><b>a. UP LED is lit</b></p>	<p>The controller is attempting to move the piston to the uppermost position, but has not reached the upper shift point. Perform Calibration Procedure 1 and then Procedure 2.</p>
<p><b>b. DN LED is lit</b></p>	<p>The controller is attempting to move the piston to the lowermost position, but has not reached the lower shift point. Perform Calibration Procedure 2 and then Procedure 1.</p>

### Calibration Procedure #1

1. Turn the R2 trim potentiometer ten turns counter-clockwise.
2. Turn the R2 trim potentiometer clockwise until the pump strokes downward without hitting the upper mechanical end stop.

Notes: Turning R2 clockwise lowers the top switching point and also decreases the total stroke length. Turning R2 counter-clockwise raises the top switching point to the point where the upper stop is reached or the pump stalls.

If you cannot make the pump stroke downward:

1. Check the air pressure and the air supply tubes.
2. Check the UP solenoid valve:
  - a. Listen for the solenoid to go on and off,
  - b. Check the voltage (24V),
  - c. Manually shuttle the solenoid valve (push the poppet) and see if the pump moves.
3. Replace the pump controller PCB.

### Calibration Procedure #2

1. Turn the R1 trim potentiometer ten turns clockwise.
2. Turn the R1 trim potentiometer counter-clockwise until the pump strokes upward without hitting the lower mechanical end stop.

Notes: Turning R1 counter-clockwise raises the bottom switching point and decreases the total stroke length. Turning R1 clockwise lowers the bottom switching point until the bottom stop is reached or the pump stalls.

If you cannot make the pump stroke upward:

1. Check the air pressure and air supply tubes.
2. Check the DOWN solenoid valve.
  - a. Listen for the solenoid to go on and off,
  - b. Check the voltage (24V),
  - c. Manually shuttle the solenoid valve (push the poppet) and see if the pump moves.
3. Replace the pump controller PCB.

## 7.8 Heater and Sensor Resistance Values



### DANGER HIGH VOLTAGE

Before unplugging connectors from the PCBs, ground yourself to the ASU by touching any available unpainted cool metal surface, mounting screws, etc. This will avoid electrical discharge to the PCB assembly when you are removing and replacing connectors.

The resistance values given in the four tables will aid in troubleshooting when a sensor or heater malfunction is suspected.

**Note:** Resistance is measured at ambient temperature (20°C/ 68°F).

The “**Temperature Sensor Resistance**” table gives values for various temperatures. If you know the approximate temperature of the suspected sensor, you can check to see if the sensor resistance approximates the value given in the table by unplugging the affected head or hose connection and measuring resistance across the affected pins (see wiring diagram in Chapter 11 for pin numbers).

*Temperature Sensor Resistance (PT 100 RTD):*

Temperature °F	Temperature °C	Resistance in Ohms
32	0	100
50	10	104
68	20	108
86	30	112
104	40	116
122	50	119
140	60	123
158	70	127
176	80	131
194	90	135
212	100	139
230	110	142
248	120	146
268	130	150
284	140	154
302	150	157
320	160	161
338	170	164
356	180	168
374	190	172
392	200	176
410	210	180
428	220	183

The “**Nominal Hose Heater Resistance**” table gives the heater resistance for hoses. A suspected hose heater problem can be quickly isolated by measuring hose heater resistance and comparing it to the correct resistance for your hose length and voltage as shown.

*Nominal Hose Heater Resistance (for #6 DynaFlex-Hoses):*

Hose Length		Resistance in Ohms (240V)
Meter	Feet	
1.2	4	466-544
1.8	6	279-326
2.4	8	236-275
3	10	189-221
3.7	12	155-181
4.9	16	118-137
7.3	24	77-90

The “**Nominal Head Heater Resistance**” table gives values for several different head wattages. A suspected head heater problem can be isolated by measuring head heater resistance and comparing it to the resistance for the appropriate wattage of your system.

*Nominal Head Heater Resistance:*

Watts	Resistance in Ohms (240V)
200	288
270	213
350	165
500	115
700	82

The “**Nominal Hopper Heater Resistance**” table gives heater resistance for the hopper heaters of each Dynamelt SR Series model and for the (optional) drop-in grids.

*Nominal Hopper Heater Resistance:*

ASU’s Heaters	Hopper	Filter Manifold	Drop-in grid
<b>Quantity Heaters</b>	2	1	1
<b>Resistance in Ohms for each Heater</b>	<b>SR5/10:</b> 72 - 81	66.3 – 82.3	<b>SR10:</b> 72 - 81
	<b>SR22/45:</b> 43 - 49	--	<b>SR22/45:</b> 21 - 25

## 7.9 Error Indication Alarm Troubleshooting Guide

The operation of error indication alarms is described in Chapter 5. When checking for correct equipment operation in the following guide, be aware that all heaters will go off immediately after an error indication alarm occurs if the operator takes no action. With the exception of the fuses, there are no user-replaceable parts on the printed circuit boards. If there is a non-fuse failure on any of the PCBs, the PCB must be replaced.





**NOTE:** The temperatures measured on the outer surface may deviate significantly from the temperatures set and displayed. This can lead to a false conclusion (e.g. defective heating). Such a difference is normal and depends also largely on the materials used.






### DANGER HIGH VOLTAGE

Some of the procedures in the following Troubleshooting Guide require potentially dangerous electricity to be present. Only qualified service personnel should perform these procedures.


Problem	Possible Cause	Solution
<p>Hopper (Tank) Overtemp</p>  <p>Sensor</p>	<ol style="list-style-type: none"> <li>1. Setpoints have been programmed without enough deviation.</li> <li>2. Hopper sensor inoperative.</li> <li>3. Hopper control triac on V6 Power Module is inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>1. Re-program setpoints, allowing a larger deviation between the high and low limits.</li> <li>2. Replace hopper sensor if resistance does not comply with the resistance table in this manual.</li> <li>3. If the hopper status LED on the Temperature Module is Off and the hopper temperature continues to rise, the triac on the power module has failed. The module must be replaced.</li> </ol>
<p>Hopper/ Filter Block Sensor Open</p>  <p>Sensor</p>	<ol style="list-style-type: none"> <li>1. Sensor cable has become unplugged from V6 Temperature Module.</li> <li>2. Hopper sensor inoperative.</li> <li>3. Filter block sensor inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>1. Verify that hopper and filter block sensor cable is properly connected at X3 on the V6 Temperature Module.</li> <li>2. Replace hopper sensor if resistance does not match resistance table.</li> <li>3. Replace filter block sensor if resistance does not match resistance table.</li> </ol>




Problem	Possible Cause	Solution
<p>Hopper/ Filter Block Sensor Short</p>  <p>Cartridge Heater Sensor Gasket Ceramic Terminal Blocks</p>	<ol style="list-style-type: none"> <li>1. Short-circuit caused by debris where sensor plugs into the V6 Temperature Module.</li> <li>2. Pinched sensor lead wire.</li> <li>3. Hopper/ Filter Block sensor inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>1. Verify that sensor connector is clean and correctly connected at X3 on the V6 Temperature Module.</li> <li>2. Visually inspect sensor lead wire for break, kink, damage, etc. If no obvious damage, use an ohmmeter to measure continuity from the sensor lead to the plug at the V6 Temperature Module. Repair or replace any damaged wire.</li> <li>3. Replace hopper sensor if resistance does not comply with resistance table.</li> </ol>
<p>Hopper/ Filter Block Heater Open</p>  <p>Heater 72-81 Ohms</p>	<ol style="list-style-type: none"> <li>1. Disconnection in hopper heater circuit.</li> <li>2. Disconnection between Power Module and the Temperature Module.</li> <li>3. Open hopper or filter block heater element.</li> </ol>	<ol style="list-style-type: none"> <li>1. Inspect hopper heater wiring for proper connections.</li> <li>2. Verify that all connections are properly made between the Power Module and V6 Temperature Module.</li> <li>3. Remove all lead wires from both hopper and filter block heater elements. Use an ohm meter to measure resistance across each element. Infinitely high resistance values indicate an open heating element which must be replaced.</li> </ol>

Problem	Possible Cause	Solution
<p>Hose/ Head (No.)* Overtemp</p>	<ol style="list-style-type: none"> <li>Hose/ Head setpoints incorrectly programmed.</li> <li>Hose/ Head triac on Power or Aux Power Module is inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>Re-program setpoint to allow a larger deviation.</li> <li>If a hose or head status LED on the Temperature Module is OFF, and the corresponding temperature continues to rise, the corresponding triac on its Power Module has failed. The module must be replaced.</li> </ol>
<p>Hose/ Head (No.)* Not Heating</p> 	<ol style="list-style-type: none"> <li>Disconnection between Power and/ or Aux Power Module and the Temperature Module.</li> <li>Hose/ Head sensor circuit inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>Verify that Power and Aux Power Module are properly connected to the V6 Temperature Module.</li> <li> <ol style="list-style-type: none"> <li>Visually examine hose/ head socket connections. Verify that pins are properly seated. If pins or plug housings are damaged, repair or replace hose. If socket is damaged, repair or replace harness.</li> <li>If hose-to-ASU plug and socket are okay, hose may have intermittent short or open circuit. Repair or replace hose, hose harness, Power Module or Aux Power Module as appropriate. Alternately, problem can be isolated by connecting the affected hose to a different ASU hose socket to determine if the problem is in the hose or in the Power or Aux Power Module.</li> <li>If head-to-hose and hose-to-ASU plugs and sockets are okay, head sensor may have an intermittent short or open circuit. Examine connections inside the service block area of the head and monitor head sensor resistance with an ohmmeter while flexing sensor leads. Repair or replace an inoperative sensor.</li> </ol> </li> </ol>

\* Check each Hose/ Head circuit on the system.

Problem	Possible Cause	Solution
<p>Hose/ Head (No.)* Not Heating (Sensor Circuit Open)</p> 	<ol style="list-style-type: none"> <li>1. Disconnection between hose and ASU.</li> <li>2. Hose sensor harness unplugged from Power or Aux Power Module.</li> <li>3. Disconnection between Power or Aux PCB and the Temperature Module.</li> <li>4. Hose/ Head sensor circuit inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>1. Visually examine connector for proper contact and seating. If pins or housings are damaged, repair or replace hose or hose harness (in ASU).</li> <li>2. Verify that affected hose is properly connected to Power or Aux Power Module. Replace or repair damaged hose harness, as necessary.</li> <li>3. Verify that all PCBs are properly inserted in their connections on the Temperature Module.</li> <li>4. Replace head sensor if resistance does not comply with resistance table. Use hose schematic to check hose sensor resistance at ASU socket, repair or replace hose, hose harness, Power or Aux Power Module as appropriate.</li> </ol>
<p>Hose/ Head (No.)* Not Heating (Sensor Circuit Shorted)</p>	<ol style="list-style-type: none"> <li>1. Debris at connection between hose/ head and ASU.</li> <li>2. Debris at connection between hose/ head harness and Power or Aux Power Module.</li> <li>3. Hose/ Head sensor circuit inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>1. Visually inspect hose connector and ASU socket for cleanliness and proper contact and seating of pins.</li> <li>2. Visually inspect that the affected hose connector at Power or Aux Power Module is clean and properly installed.</li> <li>3. Using the hose schematic, check hose sensor resistance at ASU socket. An ohmmeter can also be used to isolate a pinched wire in the hose harness. When cause is isolated, repair or replace sensor, hose, hose harness, Power or Aux Power Module as appropriate.</li> </ol>

\* Check each Hose/ Head circuit on the system.

Problem	Possible Cause	Solution
<p>Hose/ Head (No.)* Not Heating (Heater Circuit Open)</p>  <p>* Check each Hose/ Head circuit on the system.</p>	<ol style="list-style-type: none"> <li>1. Disconnection between hose/ head and ASU.</li> <li>2. Disconnection between hose/ head harness and Power or Aux Power Module.</li> <li>3. Disconnection between cartridge heater and cable assembly inside head.</li> <li>4. Open head heater element.</li> <li>5. Head fuse on Power Module or Aux Power Module inoperative.</li> <li>6. Open wiring inside ASU.</li> </ol>	<ol style="list-style-type: none"> <li>1. Visually examine affected hose/ head plug and ASU socket for cleanliness and proper contact and seating. Refer to wiring diagram for pin identification. The problem can be isolated by plugging the affected hose/ head into another ASU socket. If the new hose number is then displayed as malfunctioning, the problem is in the hose that was moved. Repair or replace hose or head or ASU hose/ head harness as appropriate.</li> <li>2. Verify that the hose harness is properly inserted into its Power or Aux Power Module plug. Check for loose leads, debris and proper contact.</li> <li>3. Visually inspect wiring inside head. Verify that cartridge heater leads are properly connected in the service block area.</li> <li>4. Use an ohmmeter to measure resistance of head cartridge heater. Refer to resistance table for resistance values. Infinitely high resistance indicates an open heater. Replace cartridge heater as appropriate.</li> <li>5. If a fuse is found to be blown, do not replace it without first finding cause. Look for a short circuit to ground in the head heater circuit, particularly inside the head at the connections in the service block area. If replaced fuse also blows, Power or Aux Power Module may be the cause. However, fuse failure is usually due to a problem in the head heater circuit, not the Power or Aux Power Module.</li> <li>6. Visually inspect ASU wiring and use an ohmmeter and the wiring diagram to locate an open wire in head heater circuit. Repair or replace ASU hose harness or other ASU wiring, as necessary.</li> </ol>

## 7.10 Controller Messages Troubleshooting Guide

The following are examples of System Status or controller display error messages and solutions.

1.

**READY**      4:00      **HOLD** EXT CON

The jumper connection from IN6 to COM (or IN6 to 24V) is not made on the Base Module.

---

2.

**MOTOR FAULT**

This fault could be caused by one of the following problems:

- there may be a motor short circuit (solution = replace the motor),
- there may be a faulty motor drive (solution = replace the motor drive),
- there may be a motor overload (contact ITW Dynatec, Technical Service).

---

3.

**SYSTEM FAULT !**

This fault, seen on the controller display, will result if the V6 modules on the din-rail are not connected properly. A bus connector, near the rail, connects one module to the next. Modules can become disconnected during transport or during repair procedures.

---

4.

**FAULT CONFIRM WITH**

A fault such as this indicates an over-temperature or an RTD sensor fault. The solution is not simply to press the RETURN button to confirm. The solution is to troubleshoot and solve the problem which caused the fault, and then confirm with the RETURN button.

---

5.

**TEMP ALARM**


**PRESS**

← Press to return to production AFTER problem is solved.

Alarm

The alarm shown above can occur on any screen. Its question mark indicates a problem with the RTD sensor in the Head #1 zone.

After about 20 seconds, the following display is shown:



The image shows a control panel display with two main sections. The top section displays the message "HEAD 1 SWITCH ZONE OFF ?" with a question mark. The bottom section displays "HEAD 1 TEMP. SENS. FAULT" with a question mark. Below these messages are two rows of four status indicators each, labeled 1, 2, 3, and 4. The first indicator in the second row has a question mark above it. To the right of the display are two status indicators, each with a question mark and the word "Status". Below the display are five function buttons labeled F1, F2, F3, F4, and F5. A legend indicates "F5 = Zone Off".

Advance to the temperature zones display to see which zone is affected. The two status lines shown above will alternate in this mode. As seen above, the question mark is placed on the zone with the faulty sensor (i.e., Head #1). After troubleshooting the fault (reference the Error Indication Alarm Troubleshooting Guide on the previous pages of this chapter) and solving the problem with the sensor, press the RETURN button.

Or, if Head #1 is not in use, press F5 to turn the zone Off.

## 7.11 Troubleshooting the ASU Pump

No special tools are needed for working on the ASU pump. See Chapter 8 of this manual for disassembly/ assembly procedures for the ASU pump, and Chapter 10 for locating pump parts on the component illustrations (exploded-view drawings).

### 7.11.1 Piston Pump Priming/ Start-Up



#### **WARNING HIGH PRESSURE**

To avoid accidental splashing of hot melt adhesive, always relieve pressure by opening the filter drain on the pump manifold before working on the pump.



#### **WARNING**

Observe manufacturer's procedures for selecting and using cleaning solvents. Be sure to read and comply with the safety procedures outlined in Chapter 2 of this manual before proceeding, particularly the section entitled, "Preventing Explosions and Fire".




#### **WARNING HOT ADHESIVE**

Use a heat-resistant, stable and deep container to collect hot-melt adhesive while priming the pump.

- The pump is self-priming. Before starting the pump, make sure a hose is attached with an open line.
- Begin with ASU electrical power OFF and the Air Control/ Filter Unit adjusted to zero air pressure.
- Turn the ASU power switch ON and slowly increase air pressure to the pump and the Air Control/ Filter Unit.
- Increase air pressure until the pump begins to stroke very slowly. By allowing the pump to stroke very slowly it will gradually purge itself of air. As the pump begins to run smoothly, gradually increase the air pressure to normal operating pressure (1.4 to 5.4 bar or 20 to 80 psi).

### 7.11.2 Piston Pump Troubleshooting Guide




**WARNING HOT SURFACE & HOT ADHESIVE**

Severe burns can occur if unprotected skin comes in contact with molten adhesive or hot application system parts.


Some of the procedures in the following Troubleshooting Guide require working near hot adhesive.

Face shields (preferred) or safety glasses (for minimum protection), heat-resistant protective gloves and long-sleeved clothing must be worn whenever working with or around adhesive application systems.


Use proper tools for handling hot melt components.

Problem	Possible Cause	Solution
<p><b>Pump Will Not Stroke</b></p> 	<ol style="list-style-type: none"> <li>1. No air pressure.</li> <li>2. Hopper or filter block temperature is below ready setpoint</li> <li>3. 2-way solenoid valve is closed.</li> <li>4. Fault in compressed air fitting on ASU.</li> <li>5. Pump is switched Off at the control panel.</li> <li>6. ASU has not reached setpoint temperature.</li> </ol>	<ol style="list-style-type: none"> <li>1. Verify system has been provided with at least 0.5 SCFM of air at 10-100 psi (.014 std. cubic meters/minute at 6.8 bar).</li> <li>2. Air valve cannot pass air until hopper has reached ready condition. Verify that hopper has reached ready. Reprogram hopper operating setpoint</li> <li>3. Verify that valve is properly connected (electrically) inside ASU. Verify that valve is properly connected to Air Control/ Filter Unit. Disconnect valve electrical leads and verify that air is passed through when 24VDC is applied to the valve terminals. Replace valve if defective.</li> <li>4. Inspect the system for improper connections, loose tubing or fittings, or kinked tubing. Repair or replace tubing or fittings, as necessary.</li> <li>5. If pump status shows STOP, the pump is switched off. Go to the Pump Screen to switch the pump on.</li> <li>6. Wait for the ASU to reach setpoint temperature or increase temperature tolerance.</li> </ol>




	<p>7. If pump status shows RUN, then - -</p> <p>8. One of the internal pump solenoid valves has failed.</p>	<p>7. Remove the electrical cover from the top of the piston pump assembly, and</p> <p>a. If neither LED is illuminated, the pump is not receiving power. Check the electrical connection with the ASU.</p> <p>b. If the UP LED is illuminated, run Calibration Procedure #1 (see Chapter 7.7 Piston Pump Control Board).</p> <p>c. If the DOWN LED is illuminated, run Calibration Procedure #2 (see Chapter 7.7 Piston Pump Control Board).</p> <p>8. Replace failed solenoid valve.</p>
<p>Pump Quick-Strokes in Both Directions</p> 	<p>1. No adhesive in hopper.</p> <p>2. Adhesive is too cold to flow into pump.</p> <p>3. Adhesive used is too viscous.</p> <p>4. Problem with pump shaft piston.</p> <p>5. There is a large opening in the system downstream of the pump.</p>	<p>1. Verify that hopper has an adequate level of hot melt adhesive.</p> <p>2. Check ready temperature of the pump enable to make sure there has been enough time for the adhesive to rise to the hopper setpoint temperature.</p> <p>3. Verify that adhesive selection and hopper setpoint temperature are compatible and that both are appropriate for your application.</p> <p>4. Remove the shaft and piston from the pump. See Chapter 8 for disassembly/ assembly procedures. Verify that piston diameter is correct: 19.63mm to 19.66mm (0.773" to 0.774") and that piston is tightly assembled to end of shaft.</p> <p>5. Inspect system for open filter drain, disconnected or ruptured hose, or disconnected head. Repair, as necessary.</p>

Problem	Possible Cause	Solution
Pump Quick-Strokes on the Forward-Stroke Only (shaft moving into pump body)	<ol style="list-style-type: none"> <li>Inlet check valve is blocked open.</li> <li>Pump is out of calibration.</li> </ol>	<ol style="list-style-type: none"> <li>Clean inlet check valve. This may be possible without removing the pump by cleaning debris through the pump inlet hole at bottom of hopper.</li> <li>Run Calibration Procedure #2, then Calibration Procedure #1. See Chapter Piston Pump Control Board.</li> </ol>
Pump Motion on the Forward Stroke (shaft moving into pump) is very slow or stopped.	<ol style="list-style-type: none"> <li>Outlet check valve is blocked closed.</li> </ol>	<ol style="list-style-type: none"> <li>Clean outlet check valve.</li> </ol>
Pump Quick-Strokes on the Reverse Stroke (shaft moving out of pump)	<ol style="list-style-type: none"> <li>Outlet check valve is blocked open.</li> </ol>	<ol style="list-style-type: none"> <li>Clean outlet check valve.</li> </ol>
Low or inconsistent adhesive output.	<ol style="list-style-type: none"> <li>Outlet filter is clogged.</li> <li>Adhesive used is too viscous.</li> <li>Blocked hose.</li> <li>Blocked applicator heads.</li> <li>Pressure relief valve in outlet block is opening.</li> </ol>	<ol style="list-style-type: none"> <li>Remove and inspect outlet filter. Clean or replace, as necessary. See Chapter 6 "Preventive Maintenance" for procedure.</li> <li>Verify that system components are at proper temperature and that selected adhesive is correct for your application.</li> <li>Inspect hose for kinks, internal plugs of debris or char (degraded adhesive). Clean or replace hoses as required.</li> <li>Inspect heads for plugged nozzles, proper air valve operation or plugged filters. Clean or repair heads as needed.</li> <li>Verify that air supplied to pump is less than 6.8 bar (100 psi). If relief valve is opening with air pressure less than 6.8 bar (100 psi), adjust or replace pressure relief valve.</li> </ol>



Problem	Possible Cause	Solution
Adhesive Leak at Filter Drain	<ol style="list-style-type: none"> <li>1. Filter drain valve not tightly closed.</li> <li>2. Filter drain valve blocked open.</li> </ol>	<ol style="list-style-type: none"> <li>1. Close and tighten filter drain valve.</li> <li>2. Remove filter plug assembly from pump. Disassemble plug assembly, clean and re-install.</li> </ol>
Adhesive leak at pump shaft seal.	<ol style="list-style-type: none"> <li>1. Pump seal out of proper Shaft Seal position inside seal and bearing assembly.</li> <li>2. Seal inoperative.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove seal and bearing assembly from pump. Verify that all components are correctly assembled.</li> <li>2. Remove seal from pump and inspect it. Replace worn or damaged seal. Be sure there are no burrs or other sharp edges on pump shaft or on installation tools that could damage the new seal.</li> </ol>





# Chapter 8

## Disassembly & Re-assembly Procedures

### 8.1 Procedures for all SR sizes

#### 8.1.1 Precautions for Disassembly Procedures



**NOTE:** Please re-read all security advices given in Chapter 2 before performing any troubleshooting or repair procedures.

All Disassembly & Re-assembly Procedures must be performed by qualified, trained technicians.



#### **DANGER HIGH VOLTAGE**

Once the system is up to temperature, disconnect and lockout all incoming power before proceeding.

Dynamelt systems use electrical power that can be life threatening and hot-melt adhesives that can cause serious burns. Only qualified persons should perform service on the ASU.



#### **WARNING HOT SURFACE**

Severe burns can occur if unprotected skin comes in contact with molten adhesive or hot application system parts.

Some of the procedures in this chapter require working near hot adhesive.

Face shields (preferred) or safety glasses (for minimum protection), heat-resistant protective gloves and long-sleeved clothing must be worn whenever working with or around adhesive application systems.

Use proper tools for handling hot melt components.



When needed, cross-reference the exploded-view component drawings in Chapter 10 with each procedure in addition to the instructions and illustrations given in this chapter. Read the “Cautions” under point Precautions for Re-Assembly Procedures before re-assembling the ASU.

#### 8.1.2 Precautions for Re-Assembly Procedures

Unless noted, the S Series ASU’s re-assembly is simply the reverse sequence of the disassembly procedures. However, the following “cautions” should be followed (whenever they apply) for proper re-assembly:



#### **CAUTION:**

In general, all *O-RINGS AND SEALS* must be replaced whenever hot-melt equipment is re-assembled. All new O-rings must be lubricated with O-ring silicone lube (PN 108689).

*TAPERED PIPE THREADS* are found on air line fittings used with the pump air supply and on the outlet filter manifold. Apply thread sealant (PN N02892) whenever tapered pipe threaded parts are re-assembled.

*SOME FITTINGS* used for adhesive on the ASU have straight threads and O-ring seals. Use of thread sealant is not necessary with these parts, but the O-ring seals should be clean and lubricated. Tighten straight-threaded parts and fittings until their shoulders are firmly seated against the pump body (or other surface). Excessive torque

may damage straight-threaded parts and the use of power wrenches is not recommended.

**HOT-MELT RESIDUE** must be cleaned from parts before they are re-assembled, particularly from threaded parts. As a precaution against adhesive residue preventing proper re-assembly, threaded parts must be re-tightened at operating temperature.


### 8.1.3 To Open and Remove the Electronics Cabinet Door



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Turn the unit off. Loosen the upper and lower door latch screws, located below the control panel, with a flat-blade screwdriver. Turn counter-clockwise until the latches stop turning.
2. Open the door.
3. Press the release button under the top cover to release the main top cover. Open the main top cover all the way.
4. Open the door 45° and lift it up and off of the unit.



### 8.1.4 Overtemp Thermostat Replacement



#### **CAUTION**

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Remove the orange access cover of the filter and shutoff assembly, located on the front of the unit.
2. Remove the two screws and slip the terminals off of the thermostat.
3. Remove the old thermostat.
4. Apply thermal paste to the back side of the new thermostat.
5. Install the new thermostat. Tighten the screws and re-attach the terminals.
6. Close the orange access cover of the filter and shutoff assembly.

### 8.1.5 Piston Pump Seal Replacement



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

A piston pump seal kit is available from ITW Dynatec. See details in Chapter 9. Remove the upper and lower O-rings from the piston pump's snout and replace.

### 8.1.6 Hopper Sensor Replacement



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

A Hopper Sensor Repair Kit is available from ITW Dynatec. See details in Chapter 9.

1. Remove the hose/ head electrical connection plate via four screws. The sensor is located behind the hole in the sheet metal panel.
2. Pull the sensor out and disconnect it from the terminal block. Discard the old sensor.
3. Crimp ferrules onto the two wires of the replacement RTD sensor and insert them into the terminal block.
4. Plug the new sensor into the hole in the hopper.
5. Re-assemble the hose/ head electrical connection plate.

### 8.1.7 Note on the Cast-in Heaters

The two cast-in heaters installed in the base of the hopper are not replaceable and will last for the life of the ASU.



### 8.1.8 Filter Manifold RTD Sensor and Heater Replacement



#### CAUTION


Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Turn the unit Off. Wait for the unit to cool, or handle wearing protective gloves and sleeves.
2. Remove the cap from the top of the filter manifold by removing two M4 socket head cap screws.
3. Gently remove the two ceramic terminal blocks from a pocket located at the top of the manifold block.
4. Check the heater's and/or sensor's resistance to determine which component has failed.

Disconnect the failed component from the terminal block and remove it from the manifold.

**Note:** the heater cavity has a knockout hole bored through the bottom of the manifold block.

5. Coat the replacement component with thermal paste and install.
6. Gently re-insert the terminal blocks into the receptacle pocket.
7. Ensure that the gasket is in place and that wires are not pinched, then secure the cap to the manifold using the two M4 screws.



*Filter Manifold*

### 8.1.9 To Access Electrical Components



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Turn the unit Off.
2. Open the electrical cabinet door.
3. Press the release button under the top cover to release the main top cover. Open the main top cover all the way.  
**Note:** the electrical cabinet door may be removed by opening it 45° and lifting it straight up and off of the unit.

#### 8.1.10 Main ON/OFF (Power) Switch

The switch body is mounted to the center divider panel with two M4 Phillips-head screws.


#### 8.1.11 Fuse Replacement



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

There are several fuses on both the Main Power PCB and the Auxiliary Power PCB. All fuses are beneath a protective cover (see below). To access the fuses, lift the fuse cover up off the retaining standoffs, then slide the cover out of the unit.



### 8.1.12 Power Supply Replacement

The power supply is attached to the center panel with two M3 screws.

### 8.1.13 Printed Circuit Board or Module Replacement



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

When removing the unit's PCBs or modules, all connectors must be removed, therefore it is important to label or use the illustrations in Chapter 7 to note the re-connection points.

**Note:** the only replaceable components on the PCBs are the fuses. There are no replaceable components on the modules. For any other failure, the PCB or module must be replaced.

### 8.1.14 Main or Auxiliary Power Board Replacement



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

#### To Remove:

1. Unplug all connectors on the PCB, noting re-connection points.
2. Loosen the two M4 screws at the front of the board.
3. Tilt the board up approximately 5 degrees and pull it straight back out of the unit.

#### To Replace:

1. Engage the lip on the heat sink plate to the hold-down bar in the back of the unit.
2. Tilt the board down to lock against the hold-down bar.
3. Tighten the two M4 screws at the front of the board.
4. Plug in all connectors.

### 8.1.15 Module Replacement



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

#### To Remove:

1. Unplug all connectors on the module, noting re-connection points.
2. Slide the module to the right to disengage the communication buss.  
**Note:** you may have to move adjacent modules out of the way.
3. Using a flat-blade screwdriver, unlatch both the top and bottom orange catch on the module and pull the module off of the DIN rail.

#### To Replace:

1. Snap the module onto the DIN rail.
2. Slide the module to the left until it is flush.
3. Slide any modules that were re-positioned during removal until flush.
4. Plug in all connectors.

### 8.1.16 Opening Modules

**CAUTION**

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

There are various electrical components located within the modules. To open a module, use two fingers to pull straight up on the top (lid) of the module. Position your fingers toward the outside edge (not the center) of the module. Do not use a tool as it could damage the module's plastic casing.

### 8.1.17 Control Panel Replacement

**CAUTION**

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

The entire control panel and shell is replaced as a unit. To remove the control panel, loosen the four M4 Phillips-head attachment screws and unplug the ribbon cable from the V6 Base Module.

## 8.2 Procedures for SR5/10


### 8.2.1 Removing the Hopper Lid Assembly, SR5/10



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Open the hopper lid.
2. Using a Phillips-head screwdriver, remove the four button-head retaining screws located in the corners of the lid assembly.
3. Lift the lid assembly up and off of the hopper cover.



### 8.2.2 Removing the Hopper Cover, SR5/10



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Remove the orange access cover of the filter and shutoff assembly, located on the front of the unit.
2. Using a 2.5mm Phillips-head screwdriver, loosen the four button-head retaining screws which secure the hose connector plate to the hopper cover.
3. Rotate the top of the hose connector plate away from the ASU and pull it up to disengage the mounting tabs.
4. Remove the two Phillips-head screws from the base of the hopper collar.
5. Remove the two Phillips-head screws from the top side of the back wall of the electronics cabinet.
6. Gently pull the hopper cover up and off the ASU.


### 8.2.3 Removing the Piston Pump, SR5/10



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. The pump must be at operation temperature.
2. Turn the unit off. Remove all air pressure lines to the unit.
3. Using the drain valve on the filter manifold, remove all adhesive pressure.
4. Remove the orange access cover of the filter and shutoff assembly.
5. Turn the filter and shutoff assembly to the OFF (close, to left) position to prevent that the adhesive flows out of the tank (shutting-off the adhesive flow).
6. At the rear of the unit, remove the piston pump guard.
7. Remove three M6 socket-head cap screws that secure the piston pump to the filter manifold.
8. Lift the pump straight up and out of the filter manifold.
9. Unplug the circular electrical connector for piston pump, disconnect the air tubing and remove the pump from the unit.



## 8.3 Procedures for SR22/45


### 8.3.1 Removing the Hopper Lid Assembly, SR22/45



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Open the hopper lid.
2. Using a Phillips-head screwdriver, remove the four button-head retaining screws located in the corners of the lid assembly.
3. Lift the lid assembly up and off of the hopper cover.



### 8.3.2 Removing the Hopper Cover, SR22/45

Refer to illustrations on previous page.



#### **CAUTION**

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. Turn the unit OFF.
2. Open the cabinet lid.
3. Remove the access panel of the filter and shutoff assembly on the front of the unit.
4. Remove the hopper lid. This step is recommended because the hopper lid gasket will need to be reseated properly during reassembly.
5. Remove the six M4 screws that secure the hopper cover to the cabinet. See illustration for location on previous page.
6. Remove the two cable ties that secure the hose/head harnesses to the hopper cover tabs.
7. Lift the hopper cover off of the cabinet and hopper.

To Install the Hopper Cover:

1. Lower the cover onto the hopper and cabinet making sure not to snag any wiring from the drop-in grids (if installed) and the hose/head harnesses.
2. On the rear corner of the unit, ensure that the hidden M4 stud engages the hole in the top of the rear panel. See illustration. No fastener is required at this location.
3. Install M4 mounting screws and secure hose/head harnesses to cover tabs using cable ties.
4. Position the lid gasket on the hopper and install the lid assembly.




### 8.3.3 Removing the Piston Pump, SR22/45



#### CAUTION

Heed all advices given in "Precautions for Disassembly and Re-Assembly Procedures" in Chapter 8.1.

1. The pump must be at operation temperature.
2. Turn off the pump. Remove all air pressure lines to the unit.
3. Using the drain valve on the filter manifold, remove all adhesive pressure.
4. Turn the unit off. Fully open the electrical cabinet lid.
5. Remove the motor access panel.
6. Disconnect the air line to the pump and the circular electrical connector for piston pump from the unit.
7. Remove the shaft guard.
8. Turn the filter and shutoff assembly to the OFF (horizontal, close) position to prevent that the adhesive flows out of the tank (shutting-off the adhesive flow)
9. Remove the three M6 screws that attach the pump to the pump manifold.
10. Pull the pump out of the manifold. Rotate the pump slightly to the vertical position to clear the electrical cabinet lid..





# Chapter 9

## Available Options & Accessories

### 9.1 Service Kits

#### Filter Kits

Each filter kit contains three O-rings (size -127, -124 and -020), one easy-spin filter cartridge and silicone lubricant.

- PN 117147 Service Kit containing a 100-mesh filter.
- PN 117145 Service Kit containing a 40-mesh filter.

#### Hopper/ Manifold & Premelt Sensor Kits,

- **For SR5/10:**  
**DCL= PN 117152:** contains 1x RTD Sensor Asy PT100 PN 117081 (w. ferrule), 1x terminal block 107881.  
**NDSN= PN 117416:** contains RTD Sensor Asy Ni120, ferrule and terminal block.
- **For SR22/45:**  
**DCL=PN 123643:** it is the RTD Sensor Asy PT100 with the 2-pin connector (terminal block not needed).  
**NDSN= PN 123702:** contains RTD Sensor Asy Ni120 with 2-pin connector.

#### Manifold Heater Kit: PN 117154, for SR5/10

The Manifold Heater Kit, for SR5/10, contains:  
1x 775W heater asy PN 117083 (w. ferrule), 1x terminal block 107881.

#### Manifold Rebuild Kit: PN 117201 (requires Filter Kit also), for SR5/10

The Manifold Service Kit (requires Filter Service Kit also), for SR5/10, contains:  
1x RTD Sensor Asy PT100 PN 117081, 1x 775W heater asy PN 117083, 9x O-ring 014 N00181, 2x O-ring 020 N00187, 6x O-ring 111 N00196, 4x O-ring 904 N01702, 2x terminal block 107881.

#### Piston Pump Repair Kit: PN 117257, for SR5/10

Service kit contains the following items needed to rebuild the 12:1 piston pump:

Part Number	Description	Qty	Part Number	Description	Qty
L16569	Bearing & Shaft Seal Assy.	1	N03812	O-ring, 125	1
108700	High-temp lube, TFE Krytox	1	A69X134	O-ring 128	1
116033	Inlet Check Valve Assy.	1	116023	Spring, Outlet Check	1
116024	Seat, Outlet Check	1	111339	Ball, SST, 0.312 dia.	1
116877	Ring, Retaining, Ext.	1			

#### Piston Pump Air motor Repair Kit: PN 117256, for SR5/10

Service kit contains seals, wear ring and lubricant for the piston pump's air motor.

#### Piston Pump Master Repair Kit: PN 117258, for SR5/10

Master service kit contains both the Air motor Repair Kit and the Piston Pump Repair Kit, contents listed above.

**Solenoid Valve Replacement Kit: PN 117264, for SR5/10**

The Solenoid Valve Replacement Kit contains 1x 3-way, 24 VDC solenoid valve assembly 117194 with connector, mounting screws and instructions for pump stroke re-calibration.

**Pump Control Printed Circuit Board Replacement Kit: PN 117265, for SR5/10**

The Pump Control PCB Replacement Kit, SR5/10, contains the pump's control PCB 115801, mounting screws and instructions for pump stroke re-calibration.

**Pump Electrical Enclosure Service Kit: PN 117266, for SR5/10**

Service kit contains a piston pump enclosure assembly (see drawings under Ch. 10 for contents and illustration) and instructions for pump stroke re-calibration.

**Pressure Relief Valve Repair Kit: PN 109982**

Contains the following three items (a PN N00179 O-ring 012, a N01601 O-ring 908 and a N05733 Backup Ring, 012) needed to repair the following relief valves:

- **PN 101840** Mechanical pressure relief valve, 100-1000 Psi (6.8 - 68 bar), and
- **PN 115540** Pneumatic pressure relief valve, up to max. 1000 Psi (68 bar).

## 9.2 Pressure Relief Valves

**PN 101840** Mechanical pressure relief valve, 100-1000 Psi (6.8 - 68 bar)  
**PN 115540** Pneumatic pressure relief valve, up to max. 1000 Psi (68 bar).

## 9.3 Analog Pressure Gauge Kit: PN 101175

An optional analog pressure gauge can be mounted on the outlet filter manifold, either pre or post filter. Reading the adhesive pressure at the manifold, rather than in-line on a hose, allows for more precise monitoring of system pressure. It is also useful for troubleshooting and maintenance.

## 9.4 NDSN Compatible ASU

This adhesive supply unit is a drop-in replacement for NDSN units. It is built with NDSN hose and head-compatible harnesses and utilizes Nickel Iron RTD sensors in the hopper and manifold.

## 9.5 ASU Roll Cart: PN 108838

A gray enamel, flush top cart of welded steel construction (24" x 30", 1800 lb. capacity). Includes two rigid and two swivel, locking 5" casters.

## 9.6 Flow Control: PN 104890

The flow control valve (installed between the outlet filter manifold and the hose) adjusts adhesive output, resulting in a more even flow.

## 9.7 Harting Connector Set: PN 115879

The addition of a Harting connection provides dedicated hardware for making terminal connections. The male and female 18 pin connector simplifies installations and makes them safe and reliable and provides one connection for all electrical devices.

## 9.8 Piston Pump Line Speed Tracking: PN 117144

The assembly controls line speed changes and adjusts adhesive volume output proportionately. It follows a 0-10V or 4-20mA input signal proportional to line speed.

## 9.9 Swirl Kits

Dual Swirl Kit for SR5/10: PN 117245

Dual Swirl Kit for SR22/45: 123672

Quad Swirl Kit for SR22/45: 123673

Used with hand-held applicators, the swirl kit allows quick coverage of a wide area with sprayed adhesive. A dual swirl kit is used with two hand-held applicators, while a quad swirl kit is used with four applicators. A trigger signal starts and stops the pump.

## 9.10 400V & 480V Step Down Transformer Kits

The kits convert incoming power from 480V Delta (without neutral) to 240V and can be configured for two, four or six hose/ head zones. A maximum of 1800W is available to each set of two hoses and two heads.

**NOTE:** Refer to separate manual for Transformers.

## 9.11 Controller Options

### Signal Isolator: PN 117143

A signal isolator conditions a parent machine's production line's DC speed voltage or current reference to allow the ASU to track the application's line speed. It accepts 0-10V, 0-5V, 4-20mA inputs and outputs a proportional 0-10V signal to DynaControl's electronics.

### System Status Light Kit: PN 116848

Remote monitoring of system status is made easier with this four-color stack light. Wired into the controller, the lights illuminate to indicate "Power On", "Ready" and "Alarm". An audible signal accompanies the "Alarm" light. The alarm may also be wired to indicate either high/low temperature, low adhesive level or open/short sensor.

### Pendant Control Assembly: PN 117237

The pendant control option provides keypad mobility via either a 13' or 26' cable. The pendant HMI replaces the built-in controller of the standard Dynamelt SR ASU and has magnets on its back side for mounting.

### V6 Communications Adapters

- V6 EtherNet/IP Kit PN 117381
- V6 Profibus Kit PN 117485
- V6 ProfiNet Kit PN 121436
- V6 CC link Kit PN 825747

The V6 communications bus module adapts the DMSR ASU to full remote operation so that all system parameters can be transmitted and received.

### Multi-ASU System w. Central HMI Kit: PN 118939

This option allows several ASUs (a maximum of ten) to be controlled by one V6 HMI touch panel, mounted in one of the units. Each ASU to be controlled is installed with a kit, which contains a cable, a RS232 converter and hardware.

## 9.12 Level Sensor Kits

Level Sensor Kit for SR5/10: PN 150020

Level sensor Kit for SR22/45: PN 123670

An optional level sensor kit can be mounted to monitor the adhesive level in the hopper. This kit includes the Probe Asy (PN 117476) and the Sensor Control Asy (PN 117477).

## 9.13 Water resistant hose electrical connector cover kit, PN 111276

This is a protective cover for Amphenol socket connector 15-pos.

## 9.14 Water resistant cover kit for NDSN hose connector, PN 110783

This is a protective cover for NDSN receptacle 12-pos.

## 9.15 Premelt-Grid Options

### 9.15.1 Premelt-grid for SR5/10



**NOTE**


The grid part number will change based on based on voltage and/or DynaControl or NDSN connector selection.

Premelt-grid Description	Grid PN Dynatec	Grid PN NDSN
2 - 200-240V - 1 Phase - 115759 - 2 Hose Kit	119423	119509
2 - 200-240V - 1 Phase - 115759 - 4 Hose Kit		
2 - 200-240V - 1 Phase - 115759 - 6 Hose Kit		
3 - 400V - 3 Phase WYE - 115765 - 2 Hose Kit	119424	119510
3 - 400V - 3 Phase WYE - 115765 - 4 Hose Kit		
3 - 400V - 3 Phase WYE - 115765 - 6 Hose Kit		
4 - 200-240V - 3Phase DELTA - 115763 - 2 Hose Kit	119422	119508
4 - 200-240V - 3Phase DELTA - 115763 - 4 Hose Kit		
4 - 200-240V - 3Phase DELTA - 115763 - 6 Hose Kit		
5 - 480VAC - 3 Phase DELTA - 115759 - 2 Hose Kit	119650	119653
5 - 480VAC - 3 Phase DELTA - 115765 - 4 Hose Kit	119651	119654
5 - 480VAC - 3 Phase DELTA - 115765 - 6 Hose Kit	119652	119655
6 - 400V - 3 Phase DELTA without Neutral - 115759 - 2 Hose Kit	119650	119653
6 - 400V - 3 Phase DELTA without Neutral - 115765 - 4 Hose Kit	119651	119654
6 - 400V - 3 Phase DELTA without Neutral - 115765 - 6 Hose Kit	119652	119655

NOTE: See drawing 119422 Rev. C on next page.

REV. NO.	119422	REV.	1	DATE	11.12.14
REVISIONS					
REV.	NO.	DESCRIPTION	DATE	BY	APPROVED
N14021	A	ORIGINAL RELEASE	11.12.14	PLD	
N14021	B	ADD NDSN GRD GRP TO COMPLETE NPR	01.08.14	LF	
ECN1598	C	122795 MMS 115769	15SEP22	JEWS	

THIS DRAWING IS THE PROPERTY OF DYNATEC.  
DO NOT REPRODUCE OR DISCLOSE TO  
OTHERS WITHOUT EXPRESS WRITTEN  
CONSENT OF DYNATEC.




**NOTES:**


1. TRIM GRID HEATER LEAD WIRES TO LENGTH INDICATED. TERMINATE LEAD WIRES WITH SOCKET CONTACTS 113268 (ITEM 9) AND ASSEMBLE INTO CONNECTOR BODY 115701 (ITEM 10).
2. PRIOR TO ASSEMBLY OF GRID TO HOPPER, LUBRICATE ALL O-RINGS WITH HIGH TEMP O-RING LUBE (ITEM 4).
3. PRIOR TO ASSEMBLY, COAT SENSOR (ITEM 5), SENSOR ADAPTER (ITEM 6), AND THE INDICATED HALF OF THE BOTTOM SURFACE OF THE V6 AUX. POWER BOARD (ITEM 13) WITH HEAT TRANSFER COMPOUND (ITEM 7).
4. GRID HEATER LEAD WIRES CONNECT TO HEADER X1 ON AUX. POWER BOARD 115733 (ITEM 12).
5. GRID SENSOR LEAD WIRES CONNECT TO HEADER LABELED Z.1 ON V6 TEMP MODULE 115735, SUPPLIED WITH ASU.
6. RIBBON CABLE 106394 (ITEM 12) CONNECTS TO HEADER X7 ON AUX. POWER BOARD 115733, AND TO HEADER X11 ON V6 TEMP MODULE 115735.
7. HARNESS ITEM 14 PROVIDES POWER FROM HEADER X11 ON THE V6 BASE POWER MODULE 115732 - SUPPLIED WITH THE ASU - TO THE AUX. POWER BOARD 115733 (ITEM 13), SPADE CONNECTORS X3, X4, & X5. SEE THE HARNESS CONNECTION DETAIL BELOW AND/OR WIRING DIAGRAM 115894, SHT. 2, FOR ADDITIONAL CONNECTION DETAILS.

**GRID GROUP TABULATION**


GRID GROUP	POWER SUPPLY	HARNESS, ITEM 14	SENSOR ASSY
119422	240VAC, 3-PH DELTA	117500	105279
119423	240VAC, 1-PH	115766	105279
119424	400VAC, 3-PH WYE	122795	105279
119508	240VAC, 3-PH DELTA,NDSN	117500	110720
119509	240VAC, 1-PH,NDSN	115766	110720
119510	400VAC, 3-PH WYE,NDSN	122795	110720




REF. CAPTIVE SCREW USED FOR ASSEMBLY,  
3.0mm HEX SKT, 2-PLACES.



HARNESS 115766 - 240VAC SINGLE PHASE




HARNESS 117500 - 240VAC 3 PHASE DELTA



HARNESS 122795 - 400VAC 3 PHASE WYE

14. HARNESS FROM V6 BASE POWER MODULE TO AUX. POWER BOARD.  
THE SPADE CONNECTOR ON AUX. POWER BOARD 115733 (ITEM 13) TO WHICH EACH HARNESS LEAD WIRE IS TO ATTACH IS NOTED NEXT TO EACH WIRE.

REV.	NO.	DESCRIPTION	DATE	BY	APPROVED
14	SEE TAB	1	EA	HARNESS, MAIN TO AUX POWER BOARD	
13	115733	1	EA	PCB ASSY, V6 AUX POWER	
12	106394	1	EA	CABLE ASSY, RIBBON, 10C, 9.5 LG	
11	108297	4	EA	SCREW, HEX HD W/ SER FLNG, M6x1.25 x 20	
10	115701	1	EA	CONNECTOR, 2-POS, .200, FEM, AMP	
9	113268	2	EA	CONTACT, SOCKET, AMP 60619-1	
8	105100	2	EA	SCREW, PH HD, #4-40 UNC x .50	
7	001V061	A/R	REF	COMPOUND, HEAT TRANSFER	
6	036E043	1	EA	SENSOR ADAPTER, W/ FLANGE	
5	SEE TAB	1	EA	SENSOR ASSY	
4	001U002	A/R	REF	LUBE, SILICONE, DOW 112	
3	N00192	1	EA	O-RING, -.032, VITON	
2	N00181	4	EA	O-RING, -.014, VITON	
1	036H003	1	EA	GRID, PRE-MELT, DM S10	



DYNATEC 115733 11.12.14 DMSR 10L	APPROVALS DATE 11.12.14	<b>Dynatec</b> MEMPHISVILLE, TN <b>GRID GROUP,          DMSR 10L ASU</b>	U/W EA PARTS P SOURCE GROUP
DO NOT SCALE DRAWING	COMPUTER DESIGNED/CHARACTERIZED GRID GRP,DMSR,240VAC,3PH	REV. NO. <b>119422</b> SCALE 1:1 CAD DRAWING	SHEET 1 OF 1



**9.15.2 Premelt-grid for SR22/45, 240/400Y, DCL PN 123658, NDSN PN 123659**




**NOTES**

- These grid groups are to be used only on Melters with the following voltages:  
240V-1PH  
240V-3PH Delta  
400V-3PH WYE
- Refer to schematic 115894 for wiring connections at the next assembly level.

Item	PN	Description	Qty
1	104802	Premelt grid 2500W	1
2	107525	Support	1
3	106174	Adapter for sensor	1
4	123643	RTD Sensor Asy PT100, Ø.187x1.25", DCL (for DCL control, grid group PN 123658)	1
	123702	RTD Sensor Asy Ni120, Ø.187x1.25", NDSN (for NDSN control, grid group PN 123659)	1
5	N00181	O-ring 014	4
6	N00192	O-ring 019	1
7	108297	Screw M8x20mm	4
8	001V061	Heat transfer compound	A/R*
9	001U002	Silicone lube	A/R*
10	115701	Connection 2-pos. female	1
11	113268	Contact, female	2

A/R\* = As required.



Use this location for support.

### 9.15.3 Premelt-grid for SR22/45, 400D/480D, DCL PN 123660, NDSN PN 123661




**NOTES**

- These grid groups are to be used only on Melters with the following voltages:  
400V-3PH Delta  
480V-3PH WYE
- Refer to schematic 115894 and also the appropriate Transformer schematic for wiring connections at the next assembly level.

Item	PN	Description	Qty
1	104802	Premelt grid 2500W	1
2	107525	Support	1
3	106174	Adapter for sensor	1
4	123643	RTD Sensor Asy PT100, Ø.187x1.25", DCL (for DCL control, grid group PN 123658)	1
	123702	RTD Sensor Asy Ni120, Ø.187x1.25", NDSN (for NDSN control, grid group PN 123659)	1
5	N00181	O-ring 014	4
6	N00192	O-ring 019	1
7	108297	Screw M8x20mm	4
8	001V061	Heat transfer compound	A/R*
9	001U002	Silicone lube	A/R*
10	N05889	Terminal, insulation, 1/4" female spade, 16-14GA	2

A/R\* = As required.



Use this location for support.


### 9.16 Pressure Transducer Kit

Pressure Transducer Kit, Rev.B, PN 116878 (for SR5/10)


A pressure transducer is an electronic probe that allows the melted adhesive's pressure to be processed by the ASU's control system. They are used to monitor system operating pressures and their limits. They troubleshoot clogged nozzles and filters.

Item	Part Number	Description	Quantity
1	107539	Rubber grommet, ID 3/4	2
2	113827	Mounting bracket	1
3	N00182	O-ring 015	1
4	078A164	Screw 10-24x1/2	2
5	812340 *	Pressure Transducer 4-20mA BSPP	1
6	042X158	Cable asy, 25'	1
7	104226	Ferrule 20AWG	2
8	117375	Cable tie	2
17	117389	Cabinet lid asy	1
18	123376	Pump access door	1
19	115785	Panel & hinge asy, left	1


\* see drawing on next page.



**Wiring schematic for Pressure Transducer Kit all unit sizes:**



**Pressure Transducer 4-20mA BSPP, PN 812340**



## 9.17 Air Control Kit PN 100055

4

3

2



1

DWG. NO. 100055 SH 1 REV. K


THIS DRAWING IS THE PROPERTY OF ITW/DYNATEC. DO NOT REPRODUCE OR DISCLOSE TO OTHERS WITHOUT EXPRESS WRITTEN CONSENT OF ITW/DYNATEC.

REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
02163	G	ADDED ITEM 4	10.14.02	BB	
02584	H	ITEM 5 WAS 100380	10.30.02	BB	
02640	J	CORRECT VIEW OF FILTER	1.31.03	BB	
E436	K	SHOW ITEM 14 AS SPARE; ADD NOTE 2	07.09.19	JC	

REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
	A	ORIGINAL RELEASE	04.22.94	CN	
	B	REQ. VALVE WAS 100041	05.10.94	CN	
	C	N06438 WAS N07677, QTY WAS 20FT 100380 WAS N02774 ITEM 6 WAS 100081 ITEM 12 WAS N01067	07.08.94	CN	
	D	1. WAS N02535 2. QTY WAS 20; 3. WAS N00754 4. WAS N02745; 5. WAS VLV, SDL 6. QTY WAS 5; 7. WAS N06412 8. WAS N06435; 9. WAS N00093 10. QTY WAS 3; 11. WAS N00092	08.26.94	CN	
	E	QTY WAS 5	01.12.95	JT	
00095	F	ITEM 14 WAS QTY 1, ADDED ITEM 3	2.10.00	BB	



SEE NOTE 1



PNEUMATIC DIAGRAM FOR A-HEAD & S-HEAD CONTROL (24VDC)

**NOTE:**  
 1. AIR LINES TO HEAD ARE TO BE CUT TO 3.5-4.0 INCHES LONG.  
 2. BAG ALL LOOSE ITEMS WITH FILTER/REGULATOR ASSY AND MARK WITH ITW DYNATEC PART NUMBER FOR CUSTOMER USE.

ITEM	PART NUMBER	QTY.	U/M	DESCRIPTION
16				
15				
14	N06430	3	EA	FTG,CONN,M,BRS
13				
12				
11	N06504	1	EA	FTG,TEE,UNION,BRS,PUSH-IN
10				
9				
8	N04264	3	EA	CABLE TIE ANCHOR, ADH BKD
7	REQ. VALVE ASSY	1	EA	ASY,VLV,SDL
6				
5	105610	1	EA	FLTR,ASY,A/C
4	100055-REF	1	REF	DWG ASSY INSTR
3	N04531	1	EA	FTG,TEE,STREET,#04
2	N00318	10	EA	CABLE TIE,.09X3.62 LG WYL
1	N06438	10	FT	TUBING,NYLON,.2500

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE FRACTIONS DECIMALS ANGLES		FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		 HENDERSONVILLE, TN	U/M
USED ON	APPROVALS	DATE	STATUS		EA
NEXT ASSY.	DRAWN	4.22.94	P	KIT, FILTER, COALES	SOURCE
	CHECKED	4.22.94	P		P
	APPROVED				GROUP
DO NOT SCALE DRAWING	SCALE 1:1	CAD DRAWING	SHEET 1 OF 1	DWG. NO. 100055 REV. K 100	

4




3

2

1

THIS DRAWING IS THE PROPERTY OF ITW/DYNATEC.  
DO NOT REPRODUCE OR DISCLOSE TO  
OTHERS WITHOUT EXPRESS WRITTEN  
CONSENT OF ITW/DYNATEC.

REVISIONS				
REV	DATE	DESCRIPTION	REF DOC	BY
A	2.26.98	ORIGINAL RELEASE	N97062	JCZ
B	4.10.02	ITEM 2 WAS 105607	02196	BB
C	10.30.02	DELETED ITEMS 4-9, REVISED NOTES	02584	BB
D	10.14.09	ITEM 3 WAS 048J008	09290	BB
E	26JUL19	NOTE 1 DETAILED FLUSH PLUG INSTALL, NO LONGER NECESSARY	ECN 471	ALM



**E** NOTES:

1.

2.

3. ATTACH THE "DO NOT OIL" TAG (ITEM 2) TO THE FILTER/REGULATOR ASSY USING THE CABLE TIE (ITEM 3).

4.

MOUNTING NUT AND BRACKET ARE SUPPLIED WITH FILTER/REGULATOR ASSY (ITEM 1) AND MAY OR MAY NOT BE USED ON ASSEMBLY LINE. IF NOT USED, BAG WITH FILTER/REGULATOR ASSY AND MARK WITH ITW DYNATEC PART NUMBER FOR CUSTOMER USE.



3	N00318	1	EA	CABLE TIE,.09X3.62 LG WY
2	103053	1	EA	TAG,OIL FREE
1	100380	1	EA	FLTR/REG ASY,COALESCING
ITEM	PART NUMBER	QTY	U/M	DESCRIPTION

PARTS LIST				ITW Dynatec HENDERSONVILLE, TN		U/M EA
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .010 ± .5				FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		<b>STATUS</b> A <b>SOURCE</b> G <b>GROUP</b> 20
USED ON DYNAMELT & DYNAMINI	APPROVALS JCZ	DATE 2.26.98	<b>FILTER/REGULATOR ASSEMBLY</b>			
NEXT ASSY. —	CHECKED JCZ	DATE 2.26.98				
DO NOT SCALE DRAWING	COMPUTER DESCRIPTION(24 CHARACTERS) FLTR/REG AS,DMS/DMIN	SIZE C	DWG. NO. 105610	REV. E		
SCALE 1:1		CAD DRAWING		SHEET 1 of 1		

THIS DRAWING IS THE PROPERTY OF ITW/DYNATEC.  
DO NOT REPRODUCE OR DISCLOSE TO  
OTHERS WITHOUT EXPRESS WRITTEN  
CONSENT OF ITW/DYNATEC.

DWG. NO. 100380 SHT. 1 REV. C

REVISIONS					
REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
02584	C	REVISED AND REDRAWN	10.30.02	BB	



ITEM	PART NUMBER	QTY.	U/M	DESCRIPTION
7	—	1	EA	BRACKET, MOUNTING
6	—	1	EA	NUT, MOUNTING
5	—	1	EA	GAUGE, PRESSURE
4	—	1	EA	PLUG, FLUSH, 1/8 NPT
3	072X228	1	EA	FITTING, PIPE NIPPLE, 1/4 NPT
2	100081	1	EA	FILTER, COALESCING, 1/4 NPT
1	N02774	1	EA	FILTER/REGULATOR, 1/4 NPT

NOTES:

- VENDOR: FLUID POWER; VENDOR P/N CQ491
- ITEMS 4-7 ARE SUPPLIED UNASSEMBLED AND BAGGED WITH THE FILTER/REGULATOR ASSEMBLY.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		ITW Dynatec HENDERSONVILLE, TN		U/M
FRACTIONS	DECIMALS	ANGLES				EA
±	.XX±.010 .XXX±.005	±.5				
USED ON	APPROVALS	DATE	DRAWN BB 10.30.02		FILTER/REGULATOR ASSEMBLY, COALESCING	STATUS
	CHECKED					P
NEXT ASSY.	COMPUTER DESCRIPTION(24 CHARACTERS)	SIZE	DWG. NO.	REV.	GROUP	
105610	FLTR/REG ASY,COALESCING	B	100380	C		
DO NOT SCALE DRAWING	SCALE 1:1	CAD DRAWING	SHEET 1 of 1			



## Chapter 10

# Component Illustrations and Bill of Materials

---



### **WARNING**

All parts must be periodically inspected and replaced if worn or broken. Failure to do this can affect equipment's operation and can result in personal injury.

This chapter contains the component illustrations (exploded-view drawings) for each assembly of the Dynamelt SR ASU. These drawings are useful for finding part numbers as well as for use when maintaining or repairing the equipment.

**Note: Most common screws, nuts and washers called out in the manual are not for sale and they can be obtained locally at your hardware Store. Specialty fasteners are available by contacting ITW Dynatec's Customer Service.**

## 10.1 SR5/10 Melter Drawings and BOMs

### 10.1.1 Cabinet Assembly, SR5/10

Item	Part Number	Description	Quantity
1	115730	Base Frame Assy	1
2	115744	Electronics Backplane	1
3	115760	Electronics Cabinet Door Assy	1
4	115762	Hopper Shroud Assy, 5L	1
	115814	Hopper Shroud Assy, 10L	1
5	115764	Shut Off Access Door, 5L	1
	115731	Shut Off Access Door, 10L	1
6	115770	Main Top, Molded	1
7	115776	Hopper Collar	1
8	115777	Lid Liner	1
9	115785	Front Panel Assy	1
10	115789	Bracket, Access Panel Mount	1
11	115836	Stiffener Plate, Main Top	1
13	115840	Manifold Drip Tray	1
14	115790	Pump Access Panel, PP	1
15	115835	Hose Connector Plate, DynaControl	1
	115839	Hose Connector Plate, NDSN	1
16	115778	Lid Hinge Rod	1
17	115838	Incoming Power Access	1
18	115833	Regulator Panel, PP	1
19	115772	Lid Top	1
22	680159	Screw M4x8 with washer	40
24	115896	Raceway Cover	1
26	101156	Screw M6x20	4
27	115719	V6 LCD Control Panel Assy	1
28	107389	Screw M4x8 with washer	9

Use nine screws (PN 107389)  
to assemble items 7&8




Illustration: Cabinet Assembly

**10.1.2 Electronics Assembly, SR5/10**

Item	Part Number	Description	Quantity
4	115729	Din Rail	1
5	115808	Power Board Bracket	1
6	115823	Main ON/OFF Disconnect Switch, 63 A	1
9	115732	V6 Power Module	1
10	115738	Power Supply 24VDC, 35W	1
11	115733	V6 Auxiliary Power Module	2
12	115734	V6 Base Module	1
13	115735	V6 Temperature Module	1
15	118125	V6 Ethernet Module, Option	1
16	680159	Screw M4x8 Phillips with washer	10
17	115719	V6 LCD Control Panel Assy	1
18	105162	Screw M3x6 Phillips	2
19	106328	Screw M4x16 Zinc	3
21	117143	Signal Isolator V6, Option	1
22	117477	Level Sensor Control Assy	1
23	105251	Terminal block, Dual,10A	1
24	105252	Endplate for 105251	1
25	117370	Swirl Trigger Board Kit, Option	1
26	105256	End Stop, Din Rail, ES35	2
29	115015	Screw M4x10	2




Illustration: Electronics Assembly, Piston Pump

**10.1.3 Hopper (Tank) Assembly, SR5/10**

Item	Part Number	Description	Quantity
1	See table below	Hopper	1
2	104166	Switch asy, Overtemperature Thermostat	1
3	115717 #	Filter and shutoff assembly, SR5/10	1
5	107389	Screw, M4x8mm, with washer	3
7	See table below	RTD Sensor Assy	1
8	114852	Gasket	1
9	105097	Screw, M6x30mm	2
10	117415	Harness, DMSR Hopper Sensor	1
11	817984 *	Nut M22	1
12	817985 *	Fitting plug M22	1
13	001V061	Heat transfer compound	A/R*
14	001V078	High-temp lube, TFE, Krytox (not shown)	A/R*
15	107324	Antiseize Compound	A/R*
	**	Optional Grid Group, SR10 (not shown)	1

A/R\* = As required.

\* Items 11 and 12 are only to be used, when no level sensor assembly is being used.

\*\* See Heating Grid Options under Ch. 9 Available Options and Accessories.

# see separate drawing/BOM.

**Hopper (Tank) asy Table:**

Hopper Asy *	Description	Item 1 Hopper	Item 7 Sensor
115829	Hopper Asy, 5-Liter Base, DCL	115809	PN 117081, RTD Sensor Asy, PT100, Ø.1875x1.25", DynaControl
115868	Hopper Asy, 10-Liter Base, DCL	115810	PN 117081, RTD Sensor Asy, PT100, Ø.1875x1.25", DynaControl
117411	Hopper Asy, 5-Liter Base, NDSN	115809	PN 117414, RTD Sensor Asy, Ni120, Ø.1875x1.25", NDSN
117412	Hopper Asy, 10-Liter Base, NDSN	115810	PN 117414, RTD Sensor Asy, Ni120, Ø.1875x1.25", NDSN

**NOTES:**

- Item 2: Apply 001V061 thermal-cote (item 13) to back side of O/T thermostat.
- Item 3: Lube O-rings with 001V078 (item 14).  
Apply 107324 antiseize (item 15) to threads.  
Torque to 15-20 ft-lbs (20-27 Nm).
- Item 9: Apply 107324 antiseize to threads. Torque to 2-3 ft-lbs (2.7-4 Nm).
- Item 7: Apply 001V061 thermal-cote to RTD sensor.
- Torque all M4 fasteners to .5 - .7 ft-lbs (0.7-0.9 Nm).
- Item 10: Sensor harness to be attached to lead wires of sensor asy (item 7).




Illustration: Hopper Assembly, SR5/10

**10.1.4 Filter Manifold Assembly, Piston Pump, DCL PN 115715 and NDSN PN 117447**

Item	Part Number	Description	Quantity
1	115714	Manifold, Piston Pump	1
2	N01703	Fitting, Plug, #4, O-Seal (includes PN N01702 O-ring)	6
3	101624	Fitting, Adapter, G1/4, 6J, (includes PN N00196 O-ring)	see table below
4	101625	Fitting, Plug, G1/4, 6mm (includes PN N00181 O-ring)	see table below
5	814018	Nut, Filter DMS Easy Spin	1
6	814009	Filter cartridge, Easy Spin, 100-mesh	1
7	812816	O-ring 127	1
8	A69x133	O-ring 124	1
9	N00187	O-ring 020	1
10	115540	Pneumatic Pressure valve, up to max. 1000 Psi (68 bar), Cp 208, 14:1, 2-stage, 1/4"-tube	1
11	115822	Drain Chute asy	1
13	808344	Screw M4x12mm	2
14	117083	Heater Assy, with heater 12.5X143MM, 240V, 775W	1
15	117081	RTD Sensor Asy, PT100, Ø.1875x1.25", DynaControl	1
	117414	RTD Sensor Asy, Ni120, Ø.1875x1.25", NDSN	1
16	107881	Terminal block, 2 Pos, Ceramic	2
17	115851	Harness, Heater manifold	1
19	100908	Screw M4x24mm	2
20	104852	Screw M10x12mm	1
21	101833	Screw 10-32x.50	1
22	106328	Screw M4x16mm	5
23	107389	Screw M4x8mm w. Washer	1
24	119425	Nut, Hex Jam, 9/16-18	1
25	001U002	Silicone lube	A/R*
26	107324	Antiseize compound	A/R*
27	001V061	Heat-transfer compound	A/R*
28	N08024	Fitting, cap #06,37deg	2

A/R\* = As required.

**Manifold assembly table:**

Number of Hoses on Melter	Item 3 PN 101624 Qty	Item 4 PN 101625 Qty
2	2	9
4	4	7
6	6	5







Illustration: Manifold Assembly, Piston Pump

**10.1.5 Filter and Shutoff Asy, SR5/10, PN 115717**

**NOTE:** This assembly drawing is shown for reference only! The filter and shutoff assembly must be ordered as entire assembly. Only the O-rings and the lube can be ordered separately.

Item	Part Number	Description	Quantity
1	-	Stem	1
2	N00181	O-ring 014	1
3	-	Nut	1
4	N00210	O-ring 912	1
5	-	Knob	1
6	-	Roll pin 1/8x13/16	1
7	-	Roll pin 1/8x1	1
8	-	Filter cartridge (tube)	1
9	001V078	High-temp lube, TFE, Krytox GPL206 (not shown)	A/R*


A/R\* = As required.

**NOTES:**

1. Coat O-rings (items 2 and 4) with high-temp lubricant (item 9) prior to assembly.
2. Knob (item 5) must be positioned with arrows in the orientation shown at assembly.
3. Grind ends of roll pin (item 7) flush with outside diameter of filter cartridge (tube) (item 1).

### 10.1.6 Level Sensor Kit, SR5/10, PN 150020 (Optional)

Item	Part Number	Description	Quantity
1	117476	Probe asy, level sensor	1
2	117477	Level sensor control amplifier asy	1
3	115859	Harness, ground	1
4	109813	Screw M4x12mm	2
	001U002	Silicone lube (not shown)	1



**10.1.7 Piston Pump Drive, SR5/10, PN 116857**

Item	Part Number	Description	Quantity
1	105134	Spacer	4
2	-	5 Liter Hopper asy (shown for reference)	1
3	115704	Manifold tube asy	1
4	115715 *	Filter Manifold Assembly Piston Pump	1
5	115816	Piston Pump Guard	1
6	115891	Piston Pump Manifold Insulator	1
7	115865 *	Air Regulator Assembly	1
8	117499 *	Pneumatic Piston Pump 12:1 Assembly, DMSR Service	1
9	680159	Screw M4x8 Phillips	2
10	117156	Screw M10x110	3
11	117376	Fitting	1
12	111898	Grommet	1
13	105061	Stud M8x50	4
14	105126	Lock nut M8	4
15	N00688	Washer	4
16	107389	Screw M4x8 Phillips with washer	2

\* see separate drawing and/or BOM.

**NOTES:**

- Item 13: Apply thread primer 102289 and thread locker hi-temp 108669 to threads that install into the hopper assy.  
Tighten M8 studs to 6-7 ft-lbs (8-9.5 Nm).  
Tighten M8 nuts to 6-7 ft-lbs (8-9.5 Nm).
- Item 10: Apply antiseize compound 107324 to threads.  
Tighten to torque of 6-7 ft-lbs (8-9.5 Nm).
- Item 3: Lubricate O-rings with silicone lube 001U002 or lube Krytox 001V078.
- Tighten all M4 screws to maximum of 8.4 ft-lbs (11.4 Nm).




Illustration: Piston Pump Drive, PN 116857

## 10.2 SR22/45 Melter Drawings and BOMs

### 10.2.1 Cabinet Assembly, SR22/45

Item	Part Number	Description	Quantity
1	123369	Base frame	1
2	123629	Divider panel	1
3	115838	Plate	1
4	117389	Cabinet lid asy	1
5	115785	Panel & Hinge asy, left	1
6	100617	Rear panel	1
7	123376	Access door	1
8	680159	Screw M4x8mm	32
9	107391	Nut M4	3
10	101156	Screw M6x20mm	2
11	105164	Flat washer #8	2
12	-	-	-
13	115760	El. cabinet door	1
14	123628	Panel, inner access	1
15	123630	Cover SR22	1
	123631	Cover SR45	1
16	123375	Access panel, filter and shutoff assembly	1
<b>17</b>	<b>123639</b>	<b>Lid assembly (including items 18 – 25)</b>	<b>1</b>
18	123635	Collar	1
19	123636	Rod	1
20	123637	Liner	1
21	123638	Lid	1
22	107389	Screw M4x8mm	11
23	114858	Seal	1
24	110742	Handle	1
25	115051	Screw M4x10mm	2
26	115719	V6 LCD Control panel asy	1
27	123419	Backplane, PP	1
28	123806	Brace, connector panel	1
29	106328	Screw M4x16mm	5
30	123498	Cover for filter manifold	1





Illustration: Cabinet Assembly, SR22/45

**10.2.2 Electronics Assembly, SR22/45**

Item	Part Number	Description	Quantity
1	115732	V6 Main power board	1
2	123381	Disconnect switch, 3-pole, 63A	1
3	115734	V6 Base module	1
4	115735	V6 Temperature module	1
5	123646	Wiring Harness, Hoe/Head	2-6
6	115738	Power Supply, 24VDC, 35W	1
7	123380	Probe asy, V6 level sensor	1
8	117477	Control amplifier, V6 level sensor	1
9	115719	V6 LCD Control panel asy	1
10	115733	V6 AUX power board	2
11	117143	Signal isolator, 24VDC	1
12	117381	V6 Ethernet kit	1





### 10.2.3 Hopper (Tank) Assembly, SR22/45

Item	Part Number	Description	Quantity
1	See table below	Hopper	1
2	102752 #	Filter and shutoff assembly, SR22/45	1
3	N00094	Plug screw	1
4	105097	Screw, M6x30mm	1
5	104166	Switch asy, Overtemperature Thermostat	1
6	107389	Screw, M4x8mm, with washer	3
7	817985 *	Fitting plug M22	2
8	817984 *	Nut M22	2
9	150254	Blank plate asy	See table below
10	N00188	O-ring 022	1
11	See table below	RTD Sensor Asy	1
12	105061	Socket head stud M8x50mm	4
13	102411	Terminal boot, silicone	4
-	001V061	Heat transfer compound (not shown)	A/R*
-	001V078	High-temp lube, TFE, Krytox (not shown)	A/R*
-	107324	Antiseize Compound (not shown)	A/R*
-	**	Optional Grid Group, SR22/45 (not shown)	1

A/R\* = As required.

\* Items 7 and 8 are only to be used, when no level sensor assembly is being used.

\*\* See Heating Grid Options under Ch. 9 Available Options and Accessories.

# see separate drawing/BOM.

#### Hopper (Tank) asy Table:

Hopper Asy PN *	Description	Item 1 Hopper PN	Item 9 Quantity	Item 11 Sensor PN
123466	Hopper Asy, 22-Liter Base, DCL	123462	1	PN 123643, RTD Sensor Asy PT100, Ø.187x1.25", DCL
123467	Hopper Asy, 45-Liter Base, DCL	123463	2	PN 123643, RTD Sensor Asy PT100, Ø.187x1.25", DCL
123703	Hopper Asy, 22-Liter Base, NDSN	123462	1	PN 123702, RTD Sensor Asy Ni120, Ø.187x1.25", NDSN
123704	Hopper Asy, 45-Liter Base, NDSN	123463	2	PN 123703, RTD Sensor Asy Ni120, Ø.187x1.25", NDSN





Illustration: Hopper Assembly, SR22/45

**10.2.4 Piston Pump Manifold Assembly, DCL, SR22/45, PN 123427**

Item	Part Number	Description	Quantity
1	123278	Piston pump manifold	1
2	N01703	Fitting, socket plug, SAE #4	1
3	101625	Plug G1/4 (BSPP)	1
4	106328	Screw M4x16mm	3
5	069X064	O-ring 041	1
6	123465	Insulation	1
7	104072	Allen stud, M10x100mm	4
8	104158	Hex nut, low profile, M10	4




**10.2.5 Filter Manifold Assembly, Piston Pump, DCL, SR22/45**

Item	Part Number	Description	Quantity
1	123438	Filter manifold, single	1
2	101624	Fitting 1/4 BSPP x #6 JIC male	see table below
3	101625	Plug G1/4 (BSPP)	see table below
4	N08024	Cap, #6 JIC	see table below
5	104852	Screw M10	1
6	101833	Screw 10-32X1/2"	1
7	814018	Filter nut	1
8	812816	O-ring 127	1
9	A69X133	O-ring 124	1
10	N00187	O-ring 020	1
11	814009	Filter cartridges 100-mesh	1
12	115540	Pneumatic pressure relief valve up to max. 1000 Psi (68 bar)	1
13	N00185	O-ring 018	2
14	N00192	O-ring 032	1
15	810250	Screw M8x110mm	3

A/R\* = As required.

**Manifold assembly table:**

Number of Hoses on Melter	Item 2 PN 101624 Qty	Item 3 PN 101625 Qty	Item 4 PN N08024 Qty
2	2	8	2
4	4	6	4
6	6	4	6




### 10.2.6 Filter and Shutoff Asy, SR22/45, PN 102752

**NOTE:** This assembly drawing is shown for reference only! The filter and shutoff assembly must be ordered as entire assembly. Only the O-rings and the lube can be ordered separately.

Item	Part Number	Description	Quantity
1	-	Filter cartridge (tube)	1
3	-	Stem	1
4	N00210	O-ring 912	1
5	-	Knob	1
6	N00181	O-ring 014	1
7	-	Roll pin 1/8x1	2
8	-	Nut	1
9	001V078	High-temp lube, TFE, Krytox GPL206 (not shown)	A/R*

A/R\* = As required.




**NOTES:**

1. Coat O-rings (items 4 and 6) with high-temp lubricant (item 9) prior to assembly.
2. Knob (item 5) must be positioned with arrows in the orientation shown at assembly.
3. Grind ends of roll pin (item 7) flush with outside diameter of filter cartridge (tube) (item 1).

**10.2.7 Level Sensor Kit, SR22/45, PN 123670 (Optional)**


Item	Part Number	Description	Quantity
1	123380	Probe asy, level sensor, SR22/45	1
2	117477	Level sensor control amplifier asy	1
3	109813	Screw M4x12mm	2
4	115859	Harness, ground	1
5	001U002	Silicone lube	1



### 10.2.8 Piston Pump Drive, SR22/45

Item	Part Number	Description	Quantity
1	123376	Access door, pump	1
2	N00188	O-ring 022	1
3	123628	Inner access panel	1
4	680159	Screw M4x8mm	9
5	123427 *	Piston Pump Manifold asy	1
6	117499 *	Pneumatic Piston Pump 12:1 Assembly, DMSR Service	1
7	115865 *	Air Regulator Assembly	1
8	117376	Fitting, 1/4" tube x 1/4 NPT female	1
9	N06504	Fitting, union tee, 1/4" tube	1
10	-	Tubing, PTFE, 1/4"OD x 1/8" ID	-

\* see separate drawing and/or BOM.



## 10.3 All SR Melters Drawings and BOMs

### 10.3.1 Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499

(PN 116125 is uncalibrated)

Item	Part Number	Description	Quantity
01	116854	Body, Piston Pump	1
02	116033	Inlet Check Valve Asy	1
02a	116032	Seat, Inlet Check Valve	1
02b	N00004	Ball, Bearing, 5/8" Dia.	1
02c	N04483	Spring	1
02d	L16532	Retainer	1
02e	N06967	Retaining Ring	1
03	116025	Shaft Asy	1
03a	116875	Shaft/Pin Asy, Pump	1
03b	111339	Ball, Bearing, 5/16" Dia.	1
03c	116023	Spring	1
03d	116024	Seat, Outlet Check Valve	1
03e	116877	Retaining Ring	1
04	L16569	Seal Cartridge Asy	1
05	116855	Retainer, Seal Cart Asy	1
06	116876	Screw M5x12mm	1
07	116026	Tie Rod, Cylinder, M6	4
08	116028	Spacer Tube	1
09	117205	Lower Cylinder Head Asy, 5/16" Tube	1
09a	117191	Cylinder Head, Lower, 5/16" Tube	1
09b	116068	Seal, Rod	1
09c	N06006	O-ring -224	1
10	116067	Piston Asy	1
10a	116614	Piston/Magnet Asy	1
10b	116072	Seal, Piston	2
10c	116073	Wear Ring, Piston	1
11	116031	Cylinder Tube, Composite	1
12	117193	Transfer Tube, 5/16"	1
13	117204 *	Electrical Enclosure / Upper Cylinder Head Asy, 5/16" Tube	1
14	A69x134	O-ring -128	1
15	N03812	O-ring -125	1
16	117173	Screw M6x25mm	3
17	108700	High-temp lube, TFE Krytox	A/R*
18	108669	Thread locker, Hi-temp, red	A/R*
19	116619	Lube, Magnalube-G (Piston seal)	A/R*
20	115816	Cover, Pump Shaft	1
21	107389	Screw M4x8mm	2
22	N00175	O-ring -008	2
23	N06006	O-ring -224	1

\* see separate drawing and/or BOM.

A/R\* = As required.







Illustration: Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499

### 10.3.2 Electrical Enclosure Assembly, PN 117204

(a sub-assembly of Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499)

Item	Part Number	Description	Quantity
1	117192	Enclosure	1
2	117194	3-way solenoid asy, 24V	2
3	116075	Screw 2-56x.75	4
4	110420	Muffler 1/8 NPT	2
5	072X529	Fitting, straight, 1/4 tube x 1/8 NPT	1
6	115801	PCB asy, V6-Hall	1
7	116497	Screw M3x8mm	3
8	116592	Fitting, cable clamp, M8x5mm	1
9	117202	Cable asy	1
10	106873	Connector	1
11	N07430	Terminal ring	1
12	-	-	-
13	106324	Flat washer M6	4
14	116071	Hex nut M6	4
15	116037	Cover	1
16	116078	Screw M3x10mm	4



Wiring connection, PN 117204






Illustration: Electrical Enclosure Assembly, PN 117204

**10.3.3 Air Regulator Assembly, PN 115865**

Item	Part Number	Description	Quantity
1	115842	Solenoid 24VDC	1
2	115846	Gauge 40mm	1
3	N06436	Fitting, El. 1/8NPTx1/4 tube	1
4	115713	Fitting, Connection 1/8FPTx1/4 tube	1
5	N06412	Fitting, El. 1/4NPTx1/4 tube	2
6	115833	Bracket	1
7	N07677	Tubing TFE.25 OD / .125 ID	0.33'

NOTES:

1. Apply thread sealant PN N02937 or Teflon tape PN 111457 to all pipe threads without pre-installed sealant.
2. Tighten to following torque:  
 1/8 NPT tighten to 3.7-5.2 ft-lbs (5-7 Nm)  
 1/4 NPT tighten to 8.1-9.6 ft-lbs (11-13 Nm).



## 10.4 Piston Pump Line Speed Tracking Kit, PN 117144




Item	Part Number	Description	Quantity
1	113370	Pressure Transducer I/P, 4-20mA, 1/4NPT	1
2	680159	Screw M4x8mm with washer	4
3	N06412	Fitting 1/4MPT / 1/4 tube	2
4	113373	Pressure gauge 0-160, 1/8NPT	1
5	117143	Signal isolator V6	1
6	111898	Grommet	1
7	N06504	Fitting, union tee, 1/4 tube	1
8	042X016	Wire, TFE, red, 18GA, 260C	1
9	042X021	Wire, TFE, black, 18GA, 260C	1
10	117696	Harness	1
11	N07677	Tubing, TFE, .25 OD x .125 ID	1.25ft
12	111457	Tape, TFE seal, .25W	A/R*

A/R\* = As required.

See drawing on next page.

THIS DRAWING IS THE PROPERTY OF HYDRA-MATIC.  
DO NOT REPRODUCE OR DISCLOSE TO  
OTHERS WITHOUT EXPRESS WRITTEN  
CONSENT OF HYDRA-MATIC.

REVISION HISTORY				
ECR	REV	DESCRIPTION	DATE	APPROVED
N09082	A	INITIAL RELEASE	2.20.12	CRF
12173	B	ADD HARNESS 117696	6.26.12	CRF
14145	C	UPDATE PNEUMATIC SCHEMATICS	04.06.15	JC
C1280	D	REMOVE ITEM 13 (117699)	11.28.18	JC



LINE SPEED FOLLOWING FOR PISTON PUMP

**FACTORY SETTINGS:**


SET PUMP TYPE TO "VARIABLE SPEED"  
PRESS THE "WRENCH" ICON BUTTON.  
SCROLL TO PUMP CONFIGURATION AND PRESS THE INPUT KNOB TO SELECT.  
CHANGE PUMP TYPE TO "VARIABLE SPEED" AND PRESS THE INPUT KNOB TO CONFIRM.  
RETURN TO MAIN MENU.

SET DIPSWITCHES ON 117143 SIGNAL ISOLATOR:  
OPEN COVER ON SIDE OF SIGNAL ISOLATOR.  
SET DIPSWITCHES AS FOLLOWS:  
ALL SWITCHES SHOULD BE IN THE "DOWN" OR "0" POSITION.  
SW1 POSITION 6 SHOULD BE IN THE "UP" OR "1" POSITION FOR 4-20mA OUTPUT.  
SW1 POSITION 4 SHOULD BE IN THE "UP" OR "1" POSITION FOR 0-10V INPUT.


**SIGNAL ISOLATOR STATUS LED:**  
LED IS ON - DEVICE HAS POWER AND IS FUNCTIONING PROPERLY.  
LED IS OFF - DEVICE IS NOT CONNECTED TO POWER.  
LED IS BLINKING - DIPSWITCHES ARE SET INCORRECTLY.

**IP TRANSDUCER DOES NOT REQUIRE ADJUSTMENT.**

**FIELD ADJUSTMENT:**  
USE THE MINIMUM AND MAXIMUM PUMP SPEED SETTINGS ON THE PUMP CONTROL SCREEN TO ADJUST PUMP OUTPUT PRESSURE.  
SEE THE OPERATIONS MANUAL FOR MORE DETAIL.



SET SIGNAL ISOLATOR'S  
DIP SWITCHES TO  
4-20mA OUTPUT



- NOTES:
- USE TEFLON TAPE (ITEM 12) ON ALL FITTING THREADS THAT DO NOT HAVE TAPE OR THREAD SEALANT APPLIED.
  - CONNECT AIR LINE AS SHOWN IN THE PNEUMATIC CONNECTION DIAGRAM AND ROUTE AS SHOWN IN THE DRAWING VIEWS.
  - CONNECT WIRING AS SHOWN IN THE WIRING DIAGRAM AND ROUTE WIRES FROM THE IP TRANSDUCER AS SHOWN IN THE DRAWING VIEWS.


ITEM	PART NUMBER	QTY	UM	DESCRIPTION
12	111457	A/N	EA	TAPE, TFE SEAL, .25W
11	N07677	1.25	FT	TUBING, TFE, .26 OD X .125I
10	117696	1	EA	HARN.PP LINE SP TRK KIT, SIGNAL ISO INPUT
9	042X021	1	FT	WIRE, TFE, BLACK, 18GA, 200C
8	042X016	1	FT	WIRE, TFE, RED, 18GA, 200C
7	N06504	1	EA	FTG UNION TEE, 1/4" TUBE
6	111898	1	EA	GROM, .38ID, .50DX, .09, RBR
5	117143	1	EA	SIGNAL ISOLATOR V6
4	113373	1	EA	GAUGE, PRSR, 0-160, 1/8NPT
3	N06412	2	EA	FTG, EL, 1/4NPTX1/4TUBE
2	000169	4	EA	SCR, PHP, M4.0, 7X3, BLK, W/WASHER
1	113370	1	EA	XDCR, IP, 4-20mA, 1/4NPT

Parts List

<p>FOR MACHINING STANDARDS AND SYMBOLS SEE HYDRA-MATIC SPEC. A00800</p> <p>SR SERIES</p> <p>DATE: 2.20.12</p> <p>BY: CRF</p>	<p><b>mwDYNAMATIC</b></p> <p>RENDERSHVILLE, TN</p> <p><b>KIT, PISTON PUMP</b></p> <p><b>LINE SPEED TRACKING</b></p> <p>117144</p>	<p>ITEM: EA</p> <p>REV: P</p> <p>SCALE: D</p> <p>DATE: 11/28/18</p> <p>BY: JC</p>
--	---	---

### 10.5 Pressure Gauge Kit, PN 101175

Item	Part Number	Description	Quantity
1	101174	Pressure gauge, 1000psi (68 bar)	1
2	103330	Fitting, adaptor, 1/4 BSPP x 1/4 NPT	1
	105914	Fitting, adaptor, 3/8 BSPP x 1/4 NPT	1
4	104325	Fitting, adaptor, #6 x 1/4 NPT	1
5	101624	Fitting, adaptor, #6 x 1/4 BSPP	1
6	103623	Fitting, adaptor, #6 x 3/8 BSPP	1
7	N07830	Fitting, 90°, #66 male x #6 female	1
8	102987	Insulator cuff	1
9	101248	Warning label (not shown)	1



---


## **10.6 System Status Lights (Stacklight) Assembly, (optional), PN 116848 Rev.H**



THIS DRAWING IS THE PROPERTY OF M/DYNAMICS. DO NOT REPRODUCE OR DISCLOSE TO OTHERS WITHOUT EXPRESS WRITTEN CONSENT OF M/DYNAMICS.


443	H	ADD COMMON TERMINAL	07.08.18	LAB
		REVISE BOM TO DYNAMICS	07.08.18	LAB

REV.	NO.	DESCRIPTION	DATE	BY	APPROVED
A		ORIGINAL RELEASE			
B	8.3.11	WIRE SCHEMATIC UPDATED	8.3.11	DWH	
C	12.08.11	CHNG 048H415 TO 807053	3.13.12	DPF	
D	15.01.18	ADDED CUSTOMER CONTACTS	1.26.18	DH	
E	15.10.15	ADD ITEMS 37-40	09.08.15	JC	
F	15.10.15	ITEM 20 WAS 078C021	12.16.15	JC	
G	17.08.17	ITEM 13 WAS 115738	11.08.17	DK	




- NOTES:
- USE EXISTING HARDWARE FROM MANUFACTURER TO MOUNT THE GROUND TERMINAL
  - MOUNT COMPONENTS ON PANEL OUT OF BDX
  - MAKE ALL WIRING CONNECTIONS TO THE BOX COMPONENTS BEFORE MOUNTING THE PANEL IN THE BOX
  - MOUNT PANEL USING EXISTING HARDWARE FROM THE MANUFACTURER
  - USE 1 14GA FERRULE (BOTH WIRES FIT) TO CONNECT THE JUMPER WIRES AND LEAD WIRES TO THE LIGHT BASE #4 TERMINAL. 18GA CAN BE USED FOR THE JUMPER WIRE TO #5 TERMINAL.
  - FOLLOWING ITEMS TO BE PACKAGED SEPARATELY:
    - 2X BOM 12 (RELAYS)
    - 2FT EACH BOM 31,32,34,35 (RED, BLK, VIOLET, ORANGE)
  - SEE ALL DIAGRAM NOTES
  - USE WIRING SCHEMATIC FOR WIRING GUIDE

DRILL LIGHT BASE USING EXISTING BOSSES:





- MOUNT RELAYS ON DIN-RAIL INSIDE ASU LEFT FROM V6-BASE MODULE OR ON ITEM 37 TO THE RIGHT OF THE LOW LEVEL SENSOR AS SHOWN.

TERMINAL RAIL SHOULD HAVE 2 ENCLOSED SLOTS WHEN CUT. MOUNTED INSIDE STACKLIGHT WITH BOM: 2X 8,9,10,11



TERMINAL RAIL SHOULD HAVE 2 ENCLOSED SLOTS WHEN CUT.



REV.	QTY	DESCRIPTION	UNIT	QTY	DESCRIPTION
E	40	106892	2	EA	WSHR.FLAT.M3.BLK
E	39	105162	2	EA	SCR.M3X6.PHILLIPS
E	38	808445	4	EA	SCR.SHC.M3-0.5X8.ZP
E	37	117369	1	EA	BRKT.SWIRL.TRIGGER BOARD
E	36	042X007	15	FT	WIRE.TFE.18GA.1000V.WHT
E	35	042X025	17	FT	WIRE.TFE.VIOLET.18GA.260
E	34	042X233	17	FT	WIRE.TFE.ORANGE.18GA.260
E	33	109530	17	FT	WIRE.TFE.18GA.BLU.260
E	32	042X016	18.75	FT	WIRE.TFE.18GA.RED
E	31	042X021	19	FT	WIRE.TFE.18GA.BLK
E	30	103246	15	FT	WIRE.TFE.18GA.LT.BLUE
E	29	N06989	15	FT	WIRE.TFE.18GA.GRN/YEL
E	28	104229	2	EA	FERRULE.UNINSUL.14 AWG
E	27	104228	18	EA	FERRULE.UNINSUL.16 AWG
E	26	N02992	2	EA	NUT.HEX.#06-32UNC.SM.PAT
E	25	106236	2	EA	WSHR.LOCK.EXT.Tooth.M4
E	24	N05238	2	EA	SCR.CAP.SOC.HD.#6-32X1.5
E	23	116841	1	EA	LT.AS.W/G/B/R/ALARM.24V
E	22	N06946	4	EA	TERM.SPADE.22-18GA.#06IN
E	21	N02537	1	EA	TERM.RING.22-18 #8 INSUL
E	20	N06942	3	EA	TERM.SPADE.16-14GA.#06IN
E	19	048J018	2	EA	BUSH.PLAST.CAP.1/2" COND
E	18	N01144	2	EA	CONDUIT LOCKNUT. 1/2 NPT
E	17	048J093	2	EA	CGB.CABLE.GRIP..25-.38
E	16	048J024	10	FT	SLVG.BLK.SILICONE.3/8
E	15	105327	2	EA	WSHR.LOCK.INT.Tooth.M3
E	14	103405	2	EA	SCR.M3X0.5X6.SHC
E	13	121168	1	EA	PWR.SUPPLY.24V.0.240V.IN.25W
E	12	821247	3	EA	RELAY.OPDT.24VDC
E	11	078C089	2	EA	FLAT.WASHER.#12.SAF
E	10	078D018	2	EA	10-32 HEX NUT
E	9	N04302	2	EA	WSHR.LOCK.EXT.T.#10
E	8	N01735	2	EA	SCR.PAN.HD.10-32 X 0.375
E	7	105256	2	EA	END.STOP.DIN.RAIL.ESS35
E	6	103440	1	FT	JMPR.BAR.70.FOR.048F154
E	5	105254	1	EA	ENDPLATE.FOR.105253
E	4	105253	2	EA	BLK.TERM.SINGLE.RK254.20
E	3	048F104	.374	FT	RAIL.TERM.MOUNT.H32
E	2	116847	1	EA	PANEL.MACH.6x6
E	1	116846	1	EA	ENCL.MACH.6x6

REV.	QTY	DESCRIPTION	UNIT	QTY	DESCRIPTION
1	1	116846	1	EA	ENCL.MACH.6x6
2	1	116847	1	EA	PANEL.MACH.6x6
3	.374	048F104	FT	RAIL.TERM.MOUNT.H32	
4	2	105253	EA	BLK.TERM.SINGLE.RK254.20	
5	1	105254	EA	ENDPLATE.FOR.105253	
6	1	103440	FT	JMPR.BAR.70.FOR.048F154	
7	2	105256	EA	END.STOP.DIN.RAIL.ESS35	
8	2	N01735	EA	SCR.PAN.HD.10-32 X 0.375	
9	2	N04302	EA	WSHR.LOCK.EXT.T.#10	
10	2	078D018	EA	10-32 HEX NUT	
11	2	078C089	EA	FLAT.WASHER.#12.SAF	
12	3	821247	EA	RELAY.OPDT.24VDC	
13	1	121168	EA	PWR.SUPPLY.24V.0.240V.IN.25W	
14	2	103405	EA	SCR.M3X0.5X6.SHC	
15	2	105327	EA	WSHR.LOCK.INT.Tooth.M3	
16	10	048J024	FT	SLVG.BLK.SILICONE.3/8	
17	2	048J093	EA	CGB.CABLE.GRIP..25-.38	
18	2	N01144	EA	CONDUIT LOCKNUT. 1/2 NPT	
19	2	048J018	EA	BUSH.PLAST.CAP.1/2" COND	
20	3	N06942	EA	TERM.SPADE.16-14GA.#06IN	
21	1	N02537	EA	TERM.RING.22-18 #8 INSUL	
22	4	N06946	EA	TERM.SPADE.22-18GA.#06IN	
23	1	116841	EA	LT.AS.W/G/B/R/ALARM.24V	
24	2	N05238	EA	SCR.CAP.SOC.HD.#6-32X1.5	
25	2	106236	EA	WSHR.LOCK.EXT.Tooth.M4	
26	2	N02992	EA	NUT.HEX.#06-32UNC.SM.PAT	
27	18	104228	EA	FERRULE.UNINSUL.16 AWG	
28	2	104229	EA	FERRULE.UNINSUL.14 AWG	
29	15	N06989	FT	WIRE.TFE.18GA.GRN/YEL	
30	15	103246	FT	WIRE.TFE.18GA.LT.BLUE	
31	19	042X021	FT	WIRE.TFE.18GA.BLK	
32	18.75	042X016	FT	WIRE.TFE.18GA.RED	
33	17	109530	FT	WIRE.TFE.18GA.BLU.260	
34	17	042X233	FT	WIRE.TFE.ORANGE.18GA.260	
35	17	042X025	FT	WIRE.TFE.VIOLET.18GA.260	
36	15	042X007	FT	WIRE.TFE.18GA.1000V.WHT	
37	1	117369	EA	BRKT.SWIRL.TRIGGER BOARD	
38	4	808445	EA	SCR.SHC.M3-0.5X8.ZP	
39	2	105162	EA	SCR.M3X6.PHILLIPS	
40	2	106892	EA	WSHR.FLAT.M3.BLK	

FOR MACHINING SPECIFICATIONS AND DIMENSIONS SEE DRAWING 116846

APPROVALS: DATE: 3.10.11

DESIGNER: DAH

STACKLIGHT, ASSY, 24V

DATE: 11.08.17

SCALE: 1:1

CAD DRAWING

REV: 1

116848

11/20

## 10.7 Recommended Spare Part Lists


**As a general rule, we recommend that you keep on hand** the same quantity of following parts as listed on the BOMs:

- *Heaters*
- *RTDs, Temperature Sensors*
- *Pressure Sensors*
- *O-rings, Sealings*
- *Filters*
- *Kits*
- *Pumps*
- *Optional Parts; refer to Ch.9.*

### 10.7.1 SR5/10 Melter Drawings and BOMs

#### 10.7.1.1 Electronics Assembly, SR5/10

Item	Part Number	Description	Quantity
6	115823	Main ON/OFF Disconnect Switch, 63 A	1
9	115732	V6 Power Module	1
10	115738	Power Supply 24VDC, 35W	1
11	115733	V6 Auxiliary Power Module	2
12	115734	V6 Base Module	1
13	115735	V6 Temperature Module	1
15	118125	V6 Ethernet Module, Option	1
17	115719	V6 LCD Control Panel Assy	1
21	117143	Signal Isolator V6, Option	1
22	117477	Level Sensor Control Assy	1
23	105251	Terminal block, Dual, 10A	1
25	117370	Swirl Trigger Board Kit, Option	1



**10.7.1.2 Hopper (Tank) Assembly, SR5/10**


Item	Part Number	Description	Quantity
2	104166	Switch asy, Overtemperature Thermostat	1
3	115717 #	Filter and shutoff assembly, SR5/10	1
7	117081	RTD Sensor Asy, PT100, Ø.1875x1.25", DynaControl	1
	117414	RTD Sensor Asy, Ni120, Ø.1875x1.25", NDSN	1
8	114852	Gasket	1
13	001V061	Heat transfer compound	A/R*
14	001V078	High-temp lube, TFE, Krytox (not shown)	A/R*
15	107324	Antiseize Compound	A/R*

A/R\* = As required.

# see separate drawing/BOM.

**NOTES:**


- Item 2: Apply 001V061 thermal-cote (item 13) to back side of O/T thermostat.
- Item 3: Lube O-rings with 001V078 (item 14).  
Apply 107324 antiseize (item 15) to threads.  
Torque to 15-20 ft-lbs (20-27 Nm).
- Item 7: Apply 001V061 thermal-cote to RTD sensor.



### 10.7.1.3 Filter Manifold Assembly, Piston Pump, DCL PN 115715 and NDSN PN 117447

Item	Part Number	Description	Quantity
6	814009	Filter cartridge, Easy Spin, 100-mesh	1
7	812816	O-ring 127	1
8	A69x133	O-ring 124	1
9	N00187	O-ring 020	1
10	115540	Pneumatic Pressure valve, up to max. 1000 Psi (68 bar), Cp 208, 14:1, 2-stage, 1/4"-tube	1
14	117083	Heater Assy, with heater 12.5X143MM, 240V, 775W	1
15	117081	RTD Sensor Assy, PT100, Ø.1875x1.25", DynaControl	1
	117414	RTD Sensor Assy, Ni120, Ø.1875x1.25", NDSN	1
25	001U002	Silicone lube	A/R*
26	107324	Antiseize compound	A/R*
27	001V061	Heat-transfer compound	A/R*

A/R\* = As required.




### 10.7.1.4 Filter and Shutoff Asy, SR5/10, PN 115717

**NOTE:** This assembly drawing is shown for reference only! The filter and shutoff assembly must be ordered as entire assembly. Only the O-rings and the lube can be ordered separately.

Item	Part Number	Description	Quantity
2	N00181	O-ring 014	1
4	N00210	O-ring 912	1
9	001V078	High-temp lube, TFE, Krytox GPL206 (not shown)	A/R*

A/R\* = As required.




**NOTES:**

1. Coat O-rings (items 2 and 4) with high-temp lubricant (item 9) prior to assembly.

### 10.7.1.5 Level Sensor Kit, SR5/10, PN 150020 (Optional)

Item	Part Number	Description	Quantity
1	117476	Probe asy, level sensor	1
2	117477	Level sensor control amplifier asy	1
	001U002	Silicone lube (not shown)	1



### 10.7.1.6 Maintenance-Kits, SR5/10


Item	PN	Description	Quantity
	117152	Hopper/ Manifold & Premelt Sensor Kit, for SR5/10, contains: 1x RTD Sensor Asy PT100 PN 117081 (w. ferrule), 1x terminal block 107881	1
	117201	Manifold Service Kit (requires Filter Service Kit also), for SR5/10, contains: 1x RTD Sensor Asy PT100 PN 117081, 1x 775W heater asy PN 117083, 9x O-ring 014 N00181, 2x O-ring 020 N00187, 6x O-ring 111 N00196, 4x O-ring 904 N01702, 2x terminal block 107881.	1
	117264	Solenoid Valve Replacement Kit, SR5/10, contains 1x 3-way, 24 VDC solenoid valve assembly 117194 with connector, mounting screws and instructions for pump stroke re-calibration.	1
	117154	Manifold 1x Heater Kit, for SR5/10, contains: 1x 775W heater asy PN 117083 (w. ferrule), 1x terminal block 107881	1
	117265	Pump Control PCB Replacement Kit, SR5/10, contains the pump's control PCB 115801, mounting screws and instructions for pump stroke re-calibration.	1



### 10.7.2 SR22/45 Melter Drawings and BOMs

#### 10.7.2.1 Electronics Assembly, SR22/45

Item	Part Number	Description	Quantity
1	115732	V6 Main power board	1
2	123381	Disconnect switch, 3-pole, 63A	1
3	115734	V6 Base module	1
4	115735	V6 Temperature module	1
6	115738	Power Supply, 24VDC, 35W	1
7	123380	Probe asy, V6 level sensor	1
8	117477	Control amplifier, V6 level sensor	1
9	115719	V6 LCD Control panel asy	1
10	115733	V6 AUX power board	2
11	117143	Signal isolator, 24VDC	1






### 10.7.2.2 Hopper (Tank) Assembly, SR22/45

Item	Part Number	Description	Quantity
2	102752 #	Filter and shutoff assembly, SR22/45	1
5	104166	Switch asy, Overtemperature Thermostat	1
10	N00188	O-ring 022	1
11	123643	RTD Sensor Asy PT100, Ø.187x1.25", DCL	1-2
	123702	RTD Sensor Asy Ni120, Ø.187x1.25", NDSN	1-2
-	001V061	Heat transfer compound (not shown)	A/R*
-	001V078	High-temp lube, TFE, Krytox (not shown)	A/R*
-	107324	Antiseize Compound (not shown)	A/R*


A/R\* = As required.

# see separate drawing/BOM.




**10.7.2.3 Piston Pump Manifold Assembly, DCL, SR22/45, PN 123427**

Item	Part Number	Description	Quantity
5	069X064	O-ring 041	1



### 10.7.2.4 Filter Manifold Assembly, Piston Pump, DCL, SR22/45

Item	Part Number	Description	Quantity
8	812816	O-ring 127	1
9	A69X133	O-ring 124	1
10	N00187	O-ring 020	1
11	814009	Filter cartridges 100-mesh	1
12	115540	Pneumatic pressure relief valve up to max. 1000 Psi (68 bar)	1
13	N00185	O-ring 018	2
14	N00192	O-ring 032	1




### 10.7.2.5 Filter and Shutoff Asy, SR22/45, PN 102752

**NOTE:** This assembly drawing is shown for reference only! The filter and shutoff assembly must be ordered as entire assembly. Only the O-rings and the lube can be ordered separately.

Item	Part Number	Description	Quantity
4	N00210	O-ring 912	1
6	N00181	O-ring 014	1
9	001V078	High-temp lube, TFE, Krytox GPL206 (not shown)	A/R*

A/R\* = As required.




**NOTES:**

1. Coat O-rings (items 4 and 6) with high-temp lubricant (item 9) prior to assembly.

### 10.7.2.6 Level Sensor Kit, SR22/45, PN 123670 (Optional)


Item	Part Number	Description	Quantity
1	123380	Probe asy, level sensor, SR22/45	1
2	117477	Level sensor control amplifier asy	1
5	001U002	Silicone lube	1



### 10.7.2.7 Piston Pump Drive, SR22/45

Item	Part Number	Description	Quantity
2	N00188	O-ring 022	1
6	117499 *	Pneumatic Piston Pump 12:1 Assembly, DMSR Service	1

\* see separate drawing and/or BOM.



### 10.7.2.8 Maintenance-Kits, SR22/45

Item	PN	Description	Quantity
	123643	Hopper/ Manifold & Premelt Sensor Kit, SR22/45 (PN 123643 is the RTD Sensor Asy PT100 with the 2-pin connector (terminal block not needed))	1

### 10.7.3 All SR Melters Drawings and BOMs

#### 10.7.3.1 Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499

(PN 116125 is uncalibrated)

Item	Part Number	Description	Quantity
02	116033	Inlet Check Valve Asy	1
04	L16569	Seal Cartridge Asy	1
09c	N06006	O-ring -224	1
10b	116072	Seal, Piston	2
10c	116073	Wear Ring, Piston	1
14	A69x134	O-ring -128	1
15	N03812	O-ring -125	1
17	108700	High-temp lube, TFE Krytox	A/R*
18	108669	Thread locker, Hi-temp, red	A/R*
19	116619	Lube, Magnalube-G, Piston Seal	A/R*
22	N00175	O-ring -008	2
23	N06006	O-ring -224	1

A/R\* = As required.





Illustration: Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499



### 10.7.3.2 Electrical Enclosure Assembly, PN 117204


(a sub-assembly of *Pneumatic Piston Pump 12:1 Assembly, DMSR Service, PN 117499*)

Item	Part Number	Description	Quantity
2	117194	3-way solenoid asy, 24V	2
6	115801	PCB asy, V6-Hall	1



### 10.7.3.3 Air Regulator Assembly, PN 115865

Item	Part Number	Description	Quantity
1	115842	Solenoid 24VDC	1
7	N07677	Tubing TFE.25 OD / .125 ID	0.33'



### 10.7.4 Piston Pump Line Speed Tracking Kit, PN 117144

Item	Part Number	Description	Quantity
1	113370	Pressure Transducer I/P, 4-20mA, 1/4NPT	1
5	117143	Signal isolator V6	1

### 10.7.5 Other Parts & Kits

**Note:** For optional parts/kits, refer to Ch.9.

#### 10.7.5.1 Lubricants and Fluids

Item	PN	Description	Quantity
	001V061	Heat transfer compound, 2.0 ounce (59 ml) container	1
	001V078	High-temp lube, TFE, Krytox, 0.5kg container	1
	108700	High-temp lube, TFE Krytox, 0.25 ounce (7.4 ml) single use tube	
	107324	Antiseize Compound, 0.5kg container	1
	001U002	Silicone lube, 5.3 ounce (157 ml) resealable tube	1
	108689	Silicone lube, 0.25 ounce (7.4 ml) single use tube (tube not resealable)	1
	N02937	Thread Sealant, 16 ounce (473 ml) container	1
	L15653	Kit, Flushing Fluid, 1 gallon (3,78 l) container	1
	116619	Lube, Magnalube-G, (piston seal), 3/4 ounce (22 ml) tube	1
	108669	Thread locker, Hi-temp, red	1

#### 10.7.5.2 Filter-Kits

Item	PN	Description	Quantity
	117147	Filter Service Kit, 100 mesh (standard)	2
	117145	Filter Service Kit, 40 mesh	2

#### 10.7.5.3 Electrical Parts


Item	Part Number	Description	Quantity
	112568	Fuse, 10AF, fast-acting (Power and Aux Power PCBs)	20
	119975	Fuse, 12AF, fast-acting (Power and Aux Power PCBs)	5
	108566	Fuse, 6.3AT, time-delay (Power PCB)	5



# Chapter 11

## System Schematics & Engineering Drawings

### 11.1 Head Schematic, PN 103117, Rev.B, DynaControl




NOTES:

1. All wire MIL-W-22759/10 or 12, minimum 600 Volts, 260 °C.
2. Solenoid(s) voltage and timing method depends on application.
3. RTD will be platinum 100 Ohm.

## 11.2 Hose Schematic, PN 101082, Rev.G, DynaControl

ASU to Applicator




**NOTES:**

1. All wiring is routed through the hose.
2. Wire sizes shown are for no. 6 and no. 8 hoses up to 24 ft. in length. For larger diameter and longer hoses, heater lead wires are 16 AWG. Other wire sizes and colors may be changed in special hoses, per customer request.

## **11.3 Schematics DM-SR all sizes, PN 115894 Rev. S**


NGSM	A	ORIGINAL RELEASE	02.09.12	DH	12097	D	ETHERNET/IP OPTION ADDED (P5)	05.08.12	DH	13224	F	PN ON PAGE 6 CORRECTED	08.05.13	DH	13365	J	PROFIBUS/ETHERCAT OPT. ADDED	01.10.14	DH	14130	L	AUX INPUTS CHANGED TO PNP	07.17.14	DH	15040	P	FUSE RATINGS CHANGED	06.15.15	DH	ECN1598	S	SR22 & SR45 ADDED	08.28.20	DH
12063	B	PAGE 3 CORRECTED	03.01.12	DH	12387	E	CHANGED TO DYNATEC LEVEL DET.	12.05.12	DH	13287	G	STACK LITE SCHEMATIC CORREC.	9.23.13	DH	14051	K	24VDC GROUNDED	03.05.14	DH	14152	M	SMRL BOARD REV. C (POL 'P')	10.09.14	DH	15172	Q	BASE MOD. REV. K	09.08.16	DH					
12097	C	LINE FILTER/Y-CAPS ADDED	03.19.12	DH	12276		PAGE 6 ADDED			13207	H	LEVEL CONTROL SCHEM. CORREC.	10.22.13	DH	14070	K	'HEADLESS' OPTION ADDED	03.26.14	DH	15024	N	NEUTRAL TERM. POSITION MOVED	03.23.15	DH	15172	R	PROFINET OPTION ADDED	03.26.18	DH					

THIS DRAWING IS THE PROPERTY OF ITW DYNATEC. DO NOT REPRODUCE OR DISCLOSE TO OTHERS WITHOUT EXPRESS WRITTEN CONSENT OF ITW DYNATEC.



**PAGE INDEX**

PAGE 1: POWER BOARDS  
 PAGE 2: POWER SUPPLY CONFIGUR.  
 PAGE 3: CONTROLLER BOARDS  
 PAGE 4&5: OPTIONS AND VARIATIONS  
 PAGE 6: BOARD INTERCONNECTIONS




<b>SCHEM, DM-SR05-45</b>		TOLERANCES (UNLESS OTHERWISE SPECIFIED)		<b>ITW Dynatec</b> HENDERSVILLE, TN	
COMPUTER DESCRIPTION(25 CHARACTERS)	NEXT ASSY.	STATUS	SIZE	DRAWN BY:	CHECKED BY:
SCHEM, DM-SR05-45		S	B	D. HEERDT	
FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		SOURCE	REV.	DATE:	SHEET OF SHEETS
				11.10.10	1 6
				DRAWING NO.	115894



THIS DRAWING IS THE PROPERTY OF ITW DYNATEC. DO NOT REPRODUCE OR DISCLOSE TO OTHERS WITHOUT EXPRESS WRITTEN CONSENT OF ITW DYNATEC.


DWG. NO. 115894		SH 2 REV S			
REVISIONS					
REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
15026	L	NEUTRAL TERMINAL MOVED	3.23.15	DH	
ECN1598	S	TRANSFORMER CONFIG ADDED	01.28.20	DH	

### SINGLE PHASE 230V





#### VOLTAGE CONFIGURATION PLUG


P/N 115724  
BLACK






#### AUX POWER BOARD WIRING




### 3 PHASE 230V (DELTA)






P/N 115725  
VIOLET




### 3 PHASE 400V (WYE)



P/N 115726  
YELLOW





### 3 PHASE 400/480V (DELTA) Transformer Units




#### 2 Hose Units:

P/N 115724  
BLACK





SR5 & SR10 Only



#### 4 & 6 Hose Units:

P/N 115726  
YELLOW




<b>SCHEM, DM-SR</b>		<b>ITW Dynatec</b> HENDERSONVILLE, TN	
DM-SR VOLTAGE CONFIGURATION		DRAWN BY: D. HEERDT	
COMPUTER DESCRIPTION(25 CHARACTERS)		CHECKED BY: _____	
NEXT ASSY.		THIS PAGE	
SCHEM, DM-SR V6		NEXT PAGE	
FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		DATE: 11.10.10	
SOURCE: REV. S		SHEET 2 OF SHEETS 6	
DRAWING NO. 115894			

THIS DRAWING IS THE PROPERTY OF ITW DYNATEC. DO NOT REPRODUCE OR DISCLOSE TO OTHERS WITHOUT EXPRESS WRITTEN CONSENT OF ITW DYNATEC.


DWG. NO.	115894	REV. 3	REV. S
REVISIONS			
REL.	REV.	DESCRIPTION	DATE BY APPROVED
ECN1598	S	SR22 & SR45 ADDED	08.28.20 DH

OPERATOR PANEL (NOT INSTALLED WHEN HEADLESS OPTION SELECTED)




<b>SCHEM, DM-SR05-45</b>		TOLERANCES (UNLESS OTHERWISE SPECIFIED)		<b>ITW Dynatec</b> HENDERSONVILLE, TN	
DO NOT SCALE DRAWING		U/M		DM-SR05-45 CONTROL MODULES	
COMPUTER DESCRIPTION(25 CHARACTERS)	NEXT ASSY.	STATUS	SIZE	DRAWN BY:	CHECKED BY:
SCHEM, DM-SR05-45		S	B	D. HEERDT	
FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		SOURCE	REV.	DATE:	SHEET OF SHEETS
		S		11.10.10	3 6
				DRAWING NO.	115894



### NORDSON COMPATIBLE RECEPTACLE



NOTE: PLACE SHUNT JUMPER ON TEMP MODULE / JTAG HEADER PIN 9&10




### SIGNAL ISOLATOR OPTION FOR GEAR PUMP



#### DIP-SWITCH CONFIGURATION

Input	Output
SW1 1 2 3 4	SW1 5 6 7 8
0÷20 mA	0÷10 V
4÷20 mA	0÷10 V (DEFAULT)
0÷10 V	
2÷10 V	
0÷5 V	
1÷5 V	


### LINE SPEED FOLLOWING FOR PISTON PUMP




SET SIGNAL ISOLATOR'S DIP SWITCHES TO:  
 0-10V INPUT  
 4-20mA OUTPUT

NOTE: CHANGE PUMP TYPE TO VARIABLE %.


### HOPPER LOW LEVEL DETECTION




### STACK LITE OPTION (DETAILS ON PAGE 11-9)



### DIGITAL PRESSURE READOUT OPTION




### TRIGGER SWITCH PUMP ENABLE (SINGLE APPLICATOR)




NOTE: CHANGE ACCEL/DECELERATION PARAMETERS C1-01/C1-02 to 1sec.

DWG. NO.	115894	REV. 5			
REVISIONS					
REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
18041	R	PROFINET OPTION ADDED	03.26.18	DH	

## PENDANT CONTROL OPTION



## COMMUNICATION OPTIONS



KIT - P/N 117381



KIT - P/N 117485




KIT - P/N 118753




KIT - P/N 121436

## 'HEADLESS' OPTION


UNIT IS REMOTELY CONTROLLED BY A MASTER UNIT CONNECTED VIA ETHERNET  
NO OPERATOR PANEL INSTALLED ON THIS UNIT



## SWIRL KIT OPTION / PUMP ENABLE KIT



## HARTING™ CONNECTOR





NOTE: CHANGE ACCEL/DECELERATION PARAMETERS C1-01/C1-02 to 1sec.

SCHEM, DM-SR05-45		TOLERANCES (UNLESS OTHERWISE SPECIFIED)			
DO NOT SCALE DRAWING		U/M	SIZE	DM-SR05-45 OPTIONS AND VARIATIONS	
COMPUTER DESCRIPTION (25 CHARACTERS)	NEXT ASSY.	STATUS	SIZE	DRAWN BY:	CHECKED BY:
SCHEM, DM-SR05-45		S	B	D. HEERDT	
FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		SOURCE	REV.	DATE:	SHEET
		S	S	05.25.11	5
					6
					DRAWING NO. 115894


THIS DRAWING IS THE PROPERTY OF ITW DYNATEC. DO NOT REPRODUCE OR DISCLOSE TO OTHERS WITHOUT EXPRESS WRITTEN CONSENT OF ITW DYNATEC.

REV. NO.		115894		SH 6 REV S	
REVISIONS					
REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
NGSM	A	ORIGINAL RELEASE	02.09.12	DH	
12276		THIS PAGE ADDED	12.05.12	DH	
13224	F	HARNESS PN CORRECTED	08.05.12	DH	
13287	G	STACK LITE SCHEMATIC CORRECTED	09.23.13	DH	
13365	J	PROFIBUS/ETHERCAT OPT. ADDED	01.10.14	DH	
14051	K	24VDC GROUNDED	03.05.14	DH	
14130	L	AUX INPUTS CHANGED TO PNP	07.17.14	DH	
14152	M	SWIRL BOARD REV.C (POL. 'P')	10.09.14	DH	
15040	P	FUSE RATING CHANGED	06.15.15	DH	
15172	Q	BASE MOD REV. K	09.08.16	DH	
18041	R	PROFINET OPTION ADDED	03.26.16	DH	
20.1272	S	SR22/45 ADDED	08.26.20	DH	



\*GEAR PUMP MODELS ONLY

\*6 HOSE UNIT SHOWN



SEE PAGE 2

<b>SCHEM,DM-SR05-45</b>		TOLERANCES (UNLESS OTHERWISE SPECIFIED)		<b>ITW Dynatec</b> HENDERSVILLE, TN	
DO NOT SCALE DRAWING		U/M		DM-SR05-45 INTERCONNECTIONS	
COMPUTER DESCRIPTION (25 CHARACTERS)	NEXT ASSY.	STATUS	SIZE	DRAWN BY:	CHECKED BY:
SCHEM, DM-SR05-45		S	B	D. HEERDT	
FOR MACHINING STANDARDS AND SYMBOLS, SEE ITW/DYNATEC SPEC. A05800		SOURCE	REV.	DATE:	SHEET OF SHEETS
				11.10.10	6 6
					DRAWING NO. 115894





# Chapter 12

## Appendix

### 12.1 DynaControl V6 / Fieldbus Options

The V6 Fieldbus options allows any V6-based unit to be monitored and controlled remotely.

Available options are:

- Profibus
- ProfiNet
- Ethernet/IP
- CC-Link

Although those fieldbuses are different in several aspects, the data exchange between the remote controller (typically PLC) and the hot melt equipment is always the same. The data exchange is based on parameter tables (Input and Output Data).

The structure of the I/O tables allows easy access to commonly used information but also access to more in depth parameters if required.

The first half of the I/O tables are used to exchange important:

Input:

- ASU control: on/off/Standby
- Pump control: on/off pump speed
- Local or remote access

Output:

- System Status: ready, heating, warnings, alarm etc.
- Pump status: Run, Hold, actual pump speed
- Level indication
- Pressure read out

Those parameters are directly accessible without special PLC logic.

The second half of the I/O tables are used for block transfer. The block transfer can be used to exchange more detailed information. This is an on-demand transfer and requires PLC code to manage the transfer.

Following Blocks are available:

- Detailed system status
- Actual Temperature for each zone
- Read back of temperature set points
- Current temperature status
- Actual pressure for secondary transducers
- Temp. zone sequencing and zone on/off
- Pump speed manual setpoints
- Pump speed automatic scaling
- Pressure loop parameters

If parameters have to be changed that are not available within the predefined Blocks above, it is possible to create custom blocks. With this it is possible to access virtually every internal parameter. Since this requires special knowledge this is out of the scope of the standard documentation. If required a special technical instruction sheet is available on request.

Local access vs. remote access:

Once the system is controlled via field bus, the fieldbus takes priority over parameter change via HMI. In order to make local changes (on ASU's HMI) possible the PLC can grant access to those parameters. The access is separated into global control and Line speed control.

## 12.2 Signal Isolator



## Signal Isolator, V6, PN 117143

### General Description

The isolated converter DAT 4531 D is able to measure voltage and current signals. In function of programming, the measured values are converted in a current or voltage signal. The device guarantees high accuracy and performance stability both versus time and temperature.

The programming is made by dip-switch located in the window on the side of the enclosure. By means of dip-switches it is possible to select the input type and range and the output type without recalibrate the device.

Moreover, by Personal Computer the user can program all of the device's parameters for his own necessity.

The 1500 Vac galvanic isolation on all ways (input, output and power supply) eliminates the effects of all ground loops eventually existing and allows the use of the converter in heavy environmental conditions found in industrial applications.

The DAT 4531 D is in compliance with the standard 89/336/CEE on the Electromagnetic Compatibility. It is housed in a plastic enclosure of 12.5 mm thickness suitable for DIN rail mounting in compliance with EN-50022 and EN-50035 standards.

### User Instructions

The converter must be powered by a direct voltage applied to the terminals Q and R.

The input channel measures the value from the sensor connected to the terminals I, L and G and transmits the output measure on the terminals N and M.

The input and output connections must be made as shown in the section "Connections".

It is possible to configure the converter on field by dip-switch or Personal Computer as shown in the section "Programming".


The configuration by dip-switches can be made also if the device is powered (Note: after the configuration the device takes some seconds to provide the right output measure).

### Light Signalling


LED	COLOR	STATE	DESCRIPTION
PWR	GREEN	ON	Device powered.
		OFF	Device not powered
		BLINKING	Wrong dip-switches setting

**Programming**

**Configuration by DIP-Switches**



- 1) Open the suitable door on the side of the device. Refer to TAB.1.
- 2) Set the input type by the dip-switch SW1 [1..4].
- 3) Set the output type by the dip-switch SW1 [6..8].
- 4) Set the options type by the dip-switch SW1 [5].



**NOTE:**

It is also possible to set the dip-switches using the wizard of the configuration software following the procedure described in the section "Configuration by PC" until the step 6 and clicking on "Switch".

**DIP-Switch Configuration Tables**

TAB.1 - Settings


Input	Output	Options
SW1 1 2 3 4	SW1 6 7 8	SW1 5 Out:
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Default *	<input type="checkbox"/> <input type="checkbox"/> 0÷20 mA	<input type="checkbox"/> Direct
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 0÷20 mA	<input type="checkbox"/> <input type="checkbox"/> 4÷20 mA	<input type="checkbox"/> Reverse
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 4÷20 mA	<input type="checkbox"/> <input type="checkbox"/> 0÷10 V	
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 0÷10 V	<input type="checkbox"/> <input type="checkbox"/> 2÷10 V	
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 2÷10 V	<input type="checkbox"/> <input type="checkbox"/> 0÷5 V	
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 0÷5 V	<input type="checkbox"/> <input type="checkbox"/> 1÷5 V	
<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> 1÷5 V		

**NOTES:**

\* If the dip-switches SW1 [1..4] are all set in the position 0 ("Default"), the device will follow the configuration programmed by PC (Input and output type and options).

\* Eventual wrong dip-switches settings will be signalled by the blinking of the LED "PWR".

## 12.3 Pressure Transducer



The WE series of Gefran, are pressure transmitters for using in High temperature environment.

The main characteristic of this series is the capability to read temperature of the media up to 315°C.

The constructive principle is based on the hydraulic transmission of the pressure.

The fluid-filled system assures the temperature stability.

The physical measure is transformed in a electrical measure by means the strain-gauge technology.

#### MAIN FEATURES

- Pressure ranges from:  
0-35 to 0-1000 bar / 0-500 to 0-15000 psi
- Accuracy:  $< \pm 0.25\%$  FSO (H);  $< \pm 0.5\%$  FSO (M)
- Fluid-filled system for temperature stability
- Oil filling meets FDA requirements CFR 178.3620 and CFR 172.878
- Oil filling volume:  
WE0 (30mm<sup>3</sup>); WE1, WE2, WE3 (40mm<sup>3</sup>)
- 1/2-20UNF, M18x1.5 standard threads; other types available on request
- Other diaphragms available on request
- Autozero function on board / external option
- Drift Autocompensation function (SP version)
- 17-7 PH corrugated diaphragm with GTP+ coating

*GTP+ (advanced protection)*

*Coating with high resistance against corrosion, abrasion and high temperature*

#### AUTOZERO FUNCTION

All signal variations in the absence of pressure can be eliminated by using the Autozero function.

This function is activated by closing a magnetic contact located on the transmitter housing.

The procedure is permitted only with pressure at zero.

#### AUTOCOMPENSATES INFLUENCE OF MELT TEMPERATURE

Thanks to internal self-compensation, the WSP series transmitter cancels the effect of pressure signal variation caused by variation of Melt temperature.

This reduces at the minimum the read error caused by heating of the filling fluid (typical of all sensors built with "filled" technology).

#### TECHNICAL SPECIFICATIONS


Accuracy (1)	H $< \pm 0.25\%$ FSO (100...1000 bar) M $< \pm 0.5\%$ FSO (35...1000 bar)
Resolution	Infinite
Measurement range	0..35 to 0..1000bar 0..500 to 0..15000psi
Maximum overpressure (without degrading performances)	2 x FS 1.5 x FS above 500bar/7500psi
Measurement principle	Extensimetric
Power supply	10...30Vdc
Maximum current absorption	32mA
Insulation resistance (at 50Vdc)	>1000 MOhm
Output signal Full Scale (FSO)	20mA
Zero balance (tolerance $\pm 0.25\%$ FSO)	4mA
Zero signals adjustment (tolerance $\pm 0.25\%$ FSO)	"Autozero" function
Span adjustment within $\pm 5\%$ FSO	See Manual
Maximum allowed load	See diagram
Response time (10...90% FSO)	~ 1ms
Output noise (RMS 10-400Hz)	< 0.025% FSO
Calibration signal	80% FSO
Output short circuit ingress and reverse polarity protection	YES
Compensated temperature range	0...+85°C
Operating temperature range	-30...+105°C
Storage temperature range	-40...+125°C
Thermal drift in compensated range: Zero / Calibration / Sensibility	< 0.02% FSO/°C
Diaphragm maximum temperature	315°C / 600°F
Zero drift due to change in process temperature (zero)	< 0.04 bar/°C
Zero drift temperature for Autocompensated version (SP) within the temperature range 20°C-315°C inclusive the drift temperature of the housing	< 0.005 bar/°C 100 ≤ p < 500 bar 0.0022 %FS/°C p ≥ 500 bar
Standard Material in contact with process medium	Diaphragm: • 17-7PH corrugated diaphragm with GTP+ Stem • 17-4 PH
Thermocouple (model WE2)	STD: type "J" (isolated junction)
Protection degree (with 6-pole female connector)	IP65

FSO = Full scale output

(1) BFSL method (Best Fit Straight Line): includes combined effects of Non-Linearity, Hysteresis and Repeatability.


# MECHANICAL DIMENSIONS

## WE0




D1	<b>1/2 - 20UNF</b>
D2	$\phi 7.8 - 0.05$ [ $\phi 0.31$ - 0.002 ]
D3	$\phi 10.5 - 0.025$ [ $\phi 0.41$ - 0.001 ]
D4	$\phi 10.67$ [ $\phi 0.42$ ]
D5	$\phi 12.7$ [ $\phi 0.5$ ]
A	5.56 - 0.26 [ 0.22 - 0.01 ]
B	11.2 [ 0.44 ]
C	15.74 [ 0.62 ]
Ch	16
[Hex]	[ 5/8 ]

## WE2




## WE1



D1	<b>M18x1.5</b>
D2	$\phi 10 - 0.05$ [ $\phi 0.394$ - 0.002 ]
D3	$\phi 16 - 0.08$ [ $\phi 0.63$ - 0.003 ]
D4	$\phi 16 - 0.4$ [ $\phi 0.63$ - 0.016 ]
D5	$\phi 18$ [ $\phi 0.71$ ]
A	6 - 0.26 [ 0.24 - 0.01 ]
B	14.8 - 0.4 [ 0.58 - 0.016 ]
C	19 [ 0.75 ]
Ch	19
[Hex]	[ 3/4 ]

## WE3




Exposed capillary	
D1	1/2-20UNF
D2	.307/.305" [7.80/7.75mm]
D3	.414/.412" [10.52/10.46mm]
A	.125/.120" [3.18/3.05mm]
B	.318/.312" [8.08/7.92mm]
C	.81" [20.6mm]

**NOTE :** dimensions refer to rigid stem length option "4" (153 mm – 6")


**WARNING :** For installation use a maximum tightening torque of 56 Nm(500 in-lb)

# ELECTRICAL CONNECTIONS

## CURRENT OUTPUT (4...20mA, two wires)



6 pin connector  
VPT07RA10-6PT2  
(PT02A-10-6P)



8 pin connector  
PC02E-12-8P Bendix



## MAGNETIC AUTOZERO


6-pin	8-pin
A	B
C	A
B	D
D	C
E - F	E - F
	G - H

Shield drain wire is tied to connector via cable clamp

## EXTERNAL AUTOZERO


6-pin	8-pin
A	B
C	A
B	D
D	C
E - F	E - F
	G - H

## LOAD DIAGRAM



The diagram shows the optimum ratio between the load and supply voltage of the 4...20mA transmitter. For a correct use, choose any combination of load resistance and supply voltage, in the shaded area.

## AUTOZERO FUNCTION



The Autozero function is activated through a magnetic contact (external magnet supplied with the sensor). See the manual for a complete Autozero function explanation.

# ACCESSORIES

### Connectors

- 6-pin mating connector (IP65 protection degree)
- 8-pin mating connector

### Extension cables

- 6-pin connector with 8m (25ft) cable
- 6-pin connector with 15m (50ft) cable
- 6-pin connector with 25m (75ft) cable
- 6-pin connector with 30m (100ft) cable
- 8-pin connector with 8m (25ft) cable
- 8-pin connector with 15m (50ft) cable
- 8-pin connector with 25m (75ft) cable
- 8-pin connector with 30m (100ft) cable
- Other lengths

### Accessories

- Mounting bracket
- Dummy plug for 1/2-20UNF
- Dummy plug for M18x1.5
- Drill kit for 1/2-20UNF
- Drill kit for M18x1.5
- Cleaning kit for 1/2-20UNF
- Cleaning kit for M18x1.5
- Fixing pen clip
- Autozero pen

### Thermocouple for WE2 model

- Type "J" (153mm - 6" stem)

CON300  
CON307

C08WLS  
C15WLS  
C25WLS  
C30WLS  
E08WLS  
E15WLS  
E25WLS  
E30WLS  
consult factory

SF18  
SC12  
SC18  
KF12  
KF18  
CT12  
CT18  
PKIT309  
PKIT312

TTER 601

Cable color code 6 wires		Cable color code 8 wires	
Conn.	Wire	Conn.	Wire
A	Red	A	White
B	Black	B	Red
C	White	C	Green
D	Green	D	Black
E	Blue	E	Blue
F	Orange	F	Orange
		G	n.c.
		H	n.c.

# ORDER CODE

W - - - - - 000

Autocompensation (*)	<b>SP</b>
Standard	-

(\*) available for ranges > to 100bar  
 (\*) not available for WE3 version

<b>OUTPUT SIGNAL</b>	
4...20mA	<b>E</b>

<b>CONFIGURATION</b>	
Rigid stem	<b>0</b>
Rigid stem + flexible	<b>1</b>
With thermocouple	<b>2</b>
Exposed capillary	<b>3</b>

<b>CONNECTOR</b>	
Standard	
6 pin	<b>6</b>
8 pin	<b>8</b>

<b>ACCURACY CLASS</b>	
0.25% FSO (ranges ≥ 100 bar/1500 psi)	<b>H</b>
0.5% FSO	<b>M</b>

RANGE			
bar		psi	
35	<b>B35U</b>	500	<b>P05C</b>
50	<b>B05D</b>	750	<b>P75D</b>
70	<b>B07D</b>	1000	<b>P01M</b>
100	<b>B01C</b>	1500	<b>P15C</b>
200	<b>B02C</b>	3000	<b>P03M</b>
350	<b>B35D</b>	5000	<b>P05M</b>
500	<b>B05C</b>	7500	<b>P75C</b>
700	<b>B07C</b>	10000	<b>P10M</b>
1000	<b>B01M</b>	15000	<b>P15M</b>

000= Standard version  
 Special or customized versions available on request

<b>E</b>	External autozero
-	Magnetic autozero

<b>FLEXIBLE LENGTH</b> (mm / inches)	(*)	
<b>Standard (WE0)</b>	<b>0</b> none	
<b>Standard (WE1, WE2)</b>	<b>D</b>	457mm 18"
	<b>E</b>	610mm 24"
	<b>F</b>	760mm 30"
<b>Standard (WE3)</b>	<b>L</b>	711mm 28"
<b>Available on request</b>	<b>A</b>	76mm 3"
	<b>B</b>	152mm 6"
	<b>C</b>	300mm 12"

<b>RIGID STEM LENGTH</b> (mm / inches)	(*)	
<b>Standard (WE0, WE1, WE2)</b>	<b>4</b>	153mm 6"
	<b>5</b>	318mm 12.5"
<b>Standard (WE3)</b>	<b>0</b>	none
<b>Available on request</b>	<b>1</b>	38mm 1.5"
	<b>2</b>	50mm 2"
	<b>3</b>	76mm 3"
	<b>6</b>	350mm 14"
	<b>7</b>	400mm 16"
	<b>8</b>	456mm 18"

(\*) max combined stem/flexible length is 914mm - 36"

<b>THREAD</b>	
Standard	
<b>1</b>	1/2 - 20 UNF
<b>4</b>	M18 x 1.5

### Examples

**WE2-6-M-B07C-1-4-D-000**

Melt pressure transmitter with type "J" thermocouple, 4...20mA output, 6-pin connector, 1/2-20UNF thread, 700 bar full scale, 0,5% accuracy class, 153 mm (6") rigid stem, 457mm (18") flexible capillary.

**WSPM0-6-M-P03M-1-4-0-000**

Melt pressure transmitter autocompensated version, rigid stem, 4...20mA output, 6-pin connector, 1/2-20UNF thread, 3000 psi full scale, 0,5% accuracy class, 153 mm (6") rigid stem.

Sensors are manufactured in compliance with:

- EMC compatibility directive
- RoHS directive

Electrical installation requirements and Conformity certificate are available on our web site: [www.gefran.com](http://www.gefran.com)

**GEFRAN** reserves the right to make any kind of design or functional modification at any moment without prior notice.

**GEFRAN spa**  
 via Sebina, 74  
 25050 PROVAGLIO D'ISEO (BS) - ITALIA  
 tel. 0309888.1 - fax. 0309839063  
 Internet: <http://www.gefran.com>







## 12.4 Manual Revisions

Revision	Page/ Chapter	Update description
Rev.3.18	27	Pumps removed Filter removed (40, 80, 150, 200-mesh) Accessories changed
	77, 123, 130	Service kits for filter removed.
	90	V6 zone tables added.
	124	Pressure relief valves options added.
	125	V6 ProfiNet Kit PN 121436 added.
	132	Sheet Metal Assembly, 5 & 10 L Units, PN 115881 – item 29 = 117268 Gasket, hopper collar – removed.
	134	PN 117382 replaced with 118125.
	136	Note to items 11 and 12 added.
	153	DynaControl V6 Fieldbus options added.
Rev.8.18	27	Designation Matrix updated according to PLS.
	Ch.9	Swirl kit and signal isolator options added.
Rev.11.18	29	Designation Matrix updated according to Configurator.
	Ch.2 and Ch.6	Cleaning recommendation added.
Rev.2.19	Ch.5	V6 LCD: CV% added to Info screen.
	Ch.10	Manifold Assembly DCL PN 115715 and NDSN PN 117447 updated.
Rev.4.19	Ch.10	Piston Pump Line Speed Tracking Kit, PN 117144D updated.
	Ch.10	Pressure Gauge Kit, diaphragm seal, PN 101175N added.
	Ch.10	Level Sensor Kit, PN 150020A added
Rev.10.19	Ch.5	V6 LCD display updated.
Rev.10.20	Ch.6.5	Filter replacement updated.
Rev.11.20	Ch.3&7	Description of fuse 112568 to 10AF and fuse 119975 to 12AF updated. PCBs illustrations 115732D and 115733D to 10AF and 12AF updated.
Rev.5.21	-	SR22/45 versions added.
	Ch.5.2.5	Hi/Lo Tolerance (P2) setting updated.
Rev.6.21	-	Filter and Shutoff assemblies and functions updated.
Rev.8.21	Ch.10.2	Cabinet Assembly, SR22/45, updated.
Rev.9.21	Ch.3.2	The weights for SR22 and 45 added under Specifications.
Rev.1.22	Ch.10.2	Hopper (Tank) Assembly, SR22/45 updated.
Rev.10.22	Ch.9	Premelt grid 119422 Rev. C drawing updated (Harness 115769 for 400V replaced by 122795).
	Ch.11.3	Schematics 115894 Rev. S updated.
Rev.11.22	Ch.3.2	Specifications: Maximum operating temperatures of 218°C (425°F) added.
Rev.12.22	Ch.6.5	Filter replacement updated.
Rev.4.23	Ch.1	EC Declaration of Conformity updated.
Rev.5.23	Ch.10.2	Cabinet and Electronics assemblies SR22/45 updated with the new rear panel.
Rev.7.23	P.1	Manual language added.
Rev.4.24	Ch.3.2.2	Specifications / Lid opening dimensions added.
Rev.3.25	Ch.10.2.1	Lid asy PN 123639 (item 17) added to Cabinet Assembly, SR22/45.

**ITW Dynatec Service Parts and Technical Service:**

<b>AMERICAS</b>	<b>EUROPE, MIDDLE EAST &amp; AFRICA</b>	<b>ASIA PACIFIC</b>	
<p>ITW Dynatec 31 Volunteer Drive Hendersonville, TN 37075 USA Tel. +1.615.824.3634 info@itwdynatec.com service@itwdynatec.com</p>	<p>ITW Dynatec Industriestrasse 28 40822 Mettmann Germany Tel. +49.2104.915.0 info@itwdynatec.de service@itwdynatec.de</p>	<p>ITW Dynatec No.2 Anzhi Street SIP, Suzhou, 215122 China Tel. +86.512.6289.0620 info@itwdynatec.cn service@itwdynatec.cn</p>	<p>ITW Dynatec Tsukimura Building 5th Floor 26-11, Nishikamata 7-chome Ota-ku, Tokyo 144-0051, Japan Tel. +81.3.5703.5501 info@itwdynatec.co.jp service@itwdynatec.co.jp</p>